

# Vision SDK

## (v03.01.00)

### Linux User Guide

**Copyright © 2014 Texas Instruments Incorporated. All rights reserved.**

Information in this document is subject to change without notice. Texas Instruments may have pending patent applications, trademarks, copyrights, or other intellectual property rights covering matter in this document. The furnishing of this documents is given for usage with Texas Instruments products only and does not give you any license to the intellectual property that might be contained within this document. Texas Instruments makes no implied or expressed warranties in this document and is not responsible for the products based from this document.

## IMPORTANT NOTICE

Texas Instruments and its subsidiaries (TI) reserve the right to make changes to their products or to discontinue any product or service without notice, and advise customers to obtain the latest version of relevant information to verify, before placing orders, that information being relied on is current and complete. All products are sold subject to the terms and conditions of sale supplied at the time of order acknowledgment, including those pertaining to warranty, patent infringement, and limitation of liability.

TI warrants performance of its products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are utilized to the extent TI deems necessary to support this warranty. Specific testing of all parameters of each device is not necessarily performed, except those mandated by government requirements.

Customers are responsible for their applications using TI components.

In order to minimize risks associated with the customer's applications, adequate design and operating safeguards ought to be provided by the customer so as to minimize inherent or procedural hazards.

TI assumes no liability for applications assistance or customer product design. TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right of TI covering or relating to any combination, machine, or process in which such products or services might be or are used. TI's publication of information regarding any third party's products or services does not constitute TI's approval, license, warranty or endorsement thereof.

Reproduction of information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations and notices. Representation or reproduction of this information with alteration voids all warranties provided for an associated TI product or service, is an unfair and deceptive business practice, and TI is neither responsible nor liable for any such use.

Resale of TI's products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service, is an unfair and deceptive business practice, and TI is not responsible nor liable for any such use.

Also see: Standard Terms and Conditions of Sale for Semiconductor Products.  
[www.ti.com/sc/docs/stdterms.htm](http://www.ti.com/sc/docs/stdterms.htm)

Mailing Address:

Texas Instruments  
Post Office Box 655303  
Dallas, Texas 75265

Copyright © 2014, Texas Instruments Incorporated

## TABLE OF CONTENTS

---

<b>1</b>	<b>Introduction .....</b>	<b>4</b>
1.1	References .....	4
<b>2</b>	<b>Installation Overview .....</b>	<b>4</b>
2.1	PC Requirements.....	4
2.2	Software Requirements.....	4
2.3	Hardware Requirements.....	5
2.4	Software Installation & Setup .....	5
<b>3</b>	<b>Build.....</b>	<b>9</b>
3.1	Build Linux Vision SDK for Video Capture and Display use-cases .....	9
3.2	Build Linux Vision SDK for AVB Capture, Decode and Display UCs .....	11
3.3	Build Linux Vision SDK for LCD display (M4 Display) .....	11
<b>4</b>	<b>Run .....</b>	<b>12</b>
4.1	Board Setup .....	12
4.2	Preparing SD card & Boot.....	12
4.3	Run demos.....	14
<b>5</b>	<b>Revision History .....</b>	<b>17</b>

## 1 Introduction

Vision Software Development Kit (Vision SDK) is a multiprocessor software development package for TI's family of ADAS SoCs. The software framework allows users to create different ADAS application data flows involving video capture, video pre-processing, video analytics algorithms, and video display. The framework has sample ADAS data flows which exercises different CPUs and HW accelerators in the ADAS SoC and shows customer how to effectively use different sub-systems in the SoC. Framework is generic enough to plug in application specific algorithms in the system.

Vision SDK is currently targeted for the TDA2xx family of SoCs

This document particularly explains Linux part of vision SDK where A15 is supposed to run Linux as target OS while other cores in the SOC run SYSBIOS. Build environment is also assumed to be Linux and user should be familiar with basics of Linux to follow this document.

### 1.1 References

Refer additional documents for more information about Vision SDK.

Refer Index.html under <INSTALL\_DIR> folder, this file helps navigating through Vision SDK documentations effectively

## 2 Installation Overview

This chapter provides a brief description on the system requirements (hardware and software) and instructions for installing Vision SDK.

### 2.1 PC Requirements

Installation of this release needs a Linux Ubuntu 14.04 machine.

**IMPORTANT NOTE:** If you are installing Ubuntu on a virtual machine, ensure it's a 64 bit Ubuntu.

### 2.2 Software Requirements

All software packages required to build and run the Vision SDK are included as part of the SDK release package except for the ones mentioned below.

#### 2.2.1 A15 Compiler, Linker

The Linux installer for the linaro tools should be downloaded from below link

[https://releases.linaro.org/components/toolchain/binaries/5.3-2016.02/arm-linux-gnueabi/gcc-linaro-5.3-2016.02-x86\\_64\\_arm-linux-gnueabi.tar.xz](https://releases.linaro.org/components/toolchain/binaries/5.3-2016.02/arm-linux-gnueabi/gcc-linaro-5.3-2016.02-x86_64_arm-linux-gnueabi.tar.xz)

The tools need to be installed in \$INSTALL\_DIR/ti\_components/os\_tools/linux/linaro location.

**IMPORTANT NOTE:** A15 Compiler and linker MUST be installed before initiating the build else compilation will fail. Also make sure the compiler is installed at the exact path mentioned above after installation of vision sdk.

Use following steps to install the toolchain

```
$> cd $INSTALL_DIR/ti_components/os_tools/linux/linaro
```

```
$> tar -xvf gcc-linaro-5.3-2016.02-x86_64_arm-linux-gnueabi.tar.xz
```

**IMPORTANT NOTE:** Ensure the toolchain is for 32 / 64 bit machine as per configuration of installation machine

If your machine is 64 bit and you have downloaded toolchain from link above

Execute following step on installation machine

```
$>sudo apt-get install ia32-libs lib32stdc++6 lib32z1-dev lib32z1 lib32ncurses5
lib32bz2-1.0
```

### 2.2.2 Linux kernel, uboot, sgx driver and target file system

In this vision sdk release kernel, uboot, sgx & target filesystem downloaded/cloned. Links to download/clone are mentioned in software installation [section 2.4](#)

### 2.2.3 Other mandatory software packages for build

Ensure these packages/tools are installed on the installation machine

**uname, sed, mkimage, dos2unix, dtrx, mono-complete, git, lib32z1 lib32ncurses5 lib32bz2-1.0 libc6:i386 libc6-i386 libstdc++6:i386 libncurses5:i386 libz1:i386 libc6-dev-i386 device-tree-compiler mono-complete**

To install

```
$>sudo apt-get install <package_name>
```

On ti-baseline 14.04 ubuntu package can be installed using the script

**hlos/scripts/linux/setup-linux-build-env.sh**

### 2.2.4 Code Composer Studio

CCS version 6.0.1.00040 or higher shall be used to debug cores which are running Bios. CCS can be downloaded from the below link-

[http://processors.wiki.ti.com/index.php/Download\\_CCS](http://processors.wiki.ti.com/index.php/Download_CCS)

Remove all default gels before connecting the bios core

## 2.3 Hardware Requirements

Please refer \$INSTALL\_DIR/vision\_sdk/docs/VisionSDK\_UserGuide.pdf

**IMPORTANT NOTE:** This release supports vision sdk only on

TDA2x Rev E or higher version of EVMs

TDA2ex Rev C or higher version of EVMs

TDA2px EVMs

## 2.4 Software Installation & Setup

Download PROCESSOR\_SDK\_VISION\_XX\_XX\_XX\_XX\_setuplinux.bin

```
$> bash
```

```
$> ./PROCESSOR_SDK_VISION_XX_XX_XX_XX_setuplinux.bin
```

Accept license agreement and give <installation\_directory\_absolute\_path> e.g. /home/username/foldername/PROCESSOR\_SDK\_VISION\_XX\_XX\_XX\_XX

```
$> cd <installation_directory_absolute_path>
```

```
$> export INSTALL_DIR=<installation_directory_absolute_path>
```

### 2.4.1 One time PC set up

If you are setting up git first time you need to setup your .gitconfig and gitproxy with as shown below

**IMPORTANT NOTE:** These steps are just indicatory. You may have to figure out arguments (e.g. paths for .gitconfig / git-proxy.sh / arguments to corkscrew) based on your particular system Network. Given below is TI network proxy setting

1. Edit .gitconfig

```
$>vi /home/<username>/.gitconfig
[core]
    gitproxy = none for ti.com
    gitproxy = /home/<username>/git-proxy.sh
```

save and exit (ESC + :wq)

2. Create git-proxy.sh

```
$>vi /home/<username>/git-proxy.sh
exec /usr/bin/corkscrew proxy01.ext.ti.com 80 $*
```

save and exit (ESC + :wq)

**You should see following output if the setup is successful**

```
$> git config --list
core.gitproxy=none for ti.com
core.gitproxy=/home/<username>/git-proxy.sh
```

## 2.4.2 Install Linux Components

### 2.4.2.1 Essential Components kernel, uboot, sgx, and file system

**IMPORTANT NOTE:** Steps below are absolutely mandatory and pre-cursors before you move to building vision sdk

You can choose to perform steps 1 – 4 in parallel through different terminals, these need not be sequential, to open terminal use Ctrl + Alt + t

Script at [vision\\_sdk/build/hlos/scripts/linux/setup\\_linux.sh](#) will do the basic setup (only steps 1 - 3). Run the script from <INSTALL\_DIR>/vision\_sdk/build

```
$> ./hlos/scripts/linux/setup_linux.sh
```

File System needs to be download, not a part of basic setup setup\_linux.sh ([refer section](#))

Note: Script will apply patches only if placed in default location as per release.

\$INSTALL\_DIR/ti\_components/os\_tools/linux/kernel/linux-kernel-addon/

#### 2.4.2.1.1 Clone kernel

```
$> cd $INSTALL_DIR/ti_components/os_tools/linux/kernel
$> git clone git://git.ti.com/glsdk/infoadas-kernel.git omap
$> cd omap/
$> git checkout -b kernel_dev tags/REL_VISION_SDK_03_01_00_00
```

memcache.ko source

There is additional kernel module needed for vision\_sdk, ensure the source lies under \$INSTALL\_DIR/ti\_components/os\_tools/linux/kernel/linux-kernel-addon/memcache, this comes by default with installation.

Cmem package needs to be installed from another git

```
$> cd $INSTALL_DIR/ti_components/os_tools/linux/kernel/cmcm
```

```
$> git clone git://git.ti.com/ipc/ludev.git
$> cd ludev/
$> git checkout -b cmem_dev d6d3e84
Or
$> git checkout tags/4.12.00.00
```

#### 2.4.2.1.2 Clone u-boot

```
$> cd $INSTALL_DIR/ti_components/os_tools/linux/u-boot
$> git clone git://git.ti.com/gl sdk/infoadas-u-boot.git u-boot
$> cd u-boot/
$> git checkout -b uboot_dev tags/REL_VISION_SDK_03_01_00_00
```

#### 2.4.2.1.3 Clone sgx drivers

```
$> cd $INSTALL_DIR/ti_components/os_tools/linux/sgx
$> git clone git://git.ti.com/graphics/omap5-sgx-ddk-linux.git
$> cd omap5-sgx-ddk-linux/
$> git checkout -b sgx_dev fd47e44
```

#### 2.4.2.1.4 Download and untar file system

Download file system from this location

[http://downloads.ti.com/infotainment/esd/jacinto6/processor-sdk-linux-automotive/03\\_03\\_00\\_03/exports/tisdk-rootfs-image-dra7xx-evm.tar.xz](http://downloads.ti.com/infotainment/esd/jacinto6/processor-sdk-linux-automotive/03_03_00_03/exports/tisdk-rootfs-image-dra7xx-evm.tar.xz)

And keep under following directory

**\$INSTALL\_DIR/ti\_components/os\_tools/linux/targetfs**

Untar file system

```
$> bash
$> export INSTALL_DIR=<installation_directory_absolute_path>
$> cd $INSTALL_DIR/ti_components/os_tools/linux/targetfs
$> chmod 777 ../targetfs
```

**NOTE: Only targetfs folder needs to have full permission not the files within**

```
$> tar xf tisdk-rootfs-image-dra7xx-evm.tar.xz
$> exit
```

**Note:**(for M4 Display): HDMI display and 10.1" LG lcd is only supported.

#### 2.4.2.2 Optional Components ipumm, Codec Engine and Framework components

Certain configurations require ipumm. Ipumm can be cloned from the below mentioned git repo along with codec engine and framework components.

**NOTE:** These are optional and default vision\_sdk\_linux build does not need these.

**Note:** Optional components are not setup as part of setup\_linux.sh script

##### 2.4.2.2.1 Clone ipumm

```
$> cd $INSTALL_DIR/ti_components/codecs
$> git clone git://git.ti.com/ivimm/ipumm.git
$> cd ipumm/
```

```
$> git checkout -b ipumm_dev cd93550
```

#### **2.4.2.2.2    *Codec\_Engine***

```
$> Install codec engine ver codec_engine_3_24_00_08 in the following folder  
<INSTALL_DIR>/ti_components/codecs/  
Package can be downloaded from  
http://software-  
dl.ti.com/dsps/dsps\_public\_sw/sdo\_sb/targetcontent/ce/3\_24\_00\_08/index\_FDS.html
```

#### **2.4.2.2.3    *Framework Components***

Download FC version x\_xx\_xx\_xx from below link and use when set IPUMM=yes in the build configuration. The FC version packaged along with VSDK is a patched version for IVA-HD profiling and that patched version will not work with IPUMM.

Note: FC Path and version supported in release can be refer from tools\_path.mk in  
<INSTALL\_DIR>/vision\_sdk/build

[http://software-  
dl.ti.com/dsps/dsps\\_public\\_sw/sdo\\_sb/targetcontent/fc/3\\_40\\_02\\_07/index\\_FDS.html](http://software-dl.ti.com/dsps/dsps_public_sw/sdo_sb/targetcontent/fc/3_40_02_07/index_FDS.html)

#### **2.4.2.2.4    *Opencil supported package***

These below package will be needed for OpenCL build and debugging dsp opencil code  
Kernel repositories required

dsptop package needs to be installed from another git

```
$> cd $INSTALL_DIR/ti_components/os_tools/linux/kernel  
$> git clone git://git.ti.com/sdo-emu/dsptop.git  
$> cd dsptop/  
$> git checkout -b dsptop_dev 0aedcab
```

gdbc6x package needs to be installed from another git

```
$> cd $INSTALL_DIR/ti_components/os_tools/linux/kernel  
$> git clone git://git.ti.com/sdo-emu/gdbc6x.git  
$> cd gdbc6x/  
$> git checkout -b gdbc6x_dev df0b8f6
```

Filesystem patches for opencil

```
Copy "opencil_fs_patches.tar.gz" from  
$INSTALL_DIR/ti_components/os_tools/linux/kernel/linux-kernel-addon/fs-patches  
into $ INSTALL_DIR/ti_components/os_tools/linux/targetfs and untar  
tar -xvzf opencil_fs_patches.tar.gz
```

### **2.4.3    *Un-installation***

```
$> rm -rf $INSTALL_DIR
```



### 3 Build

**Important Note:** In this release reference to variations in platform names would be found, basically they resemble same platform for informational-adas

Tda2xx as dra7x or vice versa

Tda2ex as dra72 or vice versa

Tda2ex 17x17 as dra71 or vice versa

Tda2px as dra76 or vice versa

For building binaries follow these steps

#### 3.1 Build Linux Vision SDK for Video Capture and Display use-cases

*Note: If you are trying this after 3.2 ensure you do a 'make clean' and manually delete \$INSTALL\_DIR/vision\_sdk/binaries/\$(MAKEAPPNAME)/\$(MAKECONFIG) folder and then proceed*

1. You must have followed all the steps in software installation and setup [section 2.4](#) before you proceed

2. Select make config in Rules.make

##### **TDA2XX**

```
MAKECONFIG=tda2xx_evm_linux_all
```

##### **TDA2EX**

```
MAKECONFIG=tda2ex_evm_linux_all
```

##### **TDA2EX 17x17**

```
MAKECONFIG= tda2ex_17x17_evm_linux_all
```

##### **TDA2PX**

```
MAKECONFIG=tda2px_evm_linux_all
```

3. Select the Lens Module used for the camera:

For TDA2xx, copy the binary files CALMAT.bin and CHARTPOS\_RUBICON.BIN to SD Card from vision\_sdk/apps/tools/surround\_vision\_tools/Srv\_LUTs/TDA2X/

For TDA2PX, copy vision\_sdk/apps/tools/Lens\_params/LENS\_imi.BIN, vision\_sdk/apps/tools/surround\_vision\_tools/Srv\_LUTs/TDA2X/CALMAT.bin and vision\_sdk/apps/tools/surround\_vision\_tools/Srv\_LUTs/TDA2X/CHARTPOS\_RUBICON.BIN to SD Card.

4. Build the Linux dependencies, this will build kernel, u-boot and sgx drivers & memcache.ko

NOTE: This step is needed only first time you build or if you make any changes to u-boot/kernel/sgx drivers, otherwise this can be skipped.

```
$> cd $INSTALL_DIR/vision_sdk/build
$> make linux
$> make linux_install
```

5. Build the sdk

```
$>make -s -j depend
$>make -s -j
```

Executing “**make -s -j depend**” will build all the necessary components (PDK drivers, EDMA drivers) and “**make -s -j**” will build the Vision SDK framework and examples.

**IMPORTANT NOTE:** For incremental build, make sure to do "gmake -s -j depend" before "gmake -s -j" when below variables specified in \vision\_sdk\\$(MAKEAPPNAME)\configs\\$(MAKECONFIG)\\*\_cfg.mk are changed

- when PROC\_\$(CPU)\_INCLUDE is changed
- when DDR\_MEM is changed
- when PROFILE is changed
- when ALG plugin or usecase is enabled or disabled in \vision\_sdk\\$(MAKEAPPNAME)\configs\\$(MAKECONFIG) \\*\_cfg.mk
- when any .h or .c file in TI component is installed in ti\_components is changed
- when any new TI component is installed in ti\_components
- when some links are added or removed

6. Step 5 will ensure your firmware binaries and linux application's .out are copied into your targetfs i.e.

\$INSTALL\_DIR/ti\_components/os\_tools/linux/targetfs/lib/firmware and  
\$INSTALL\_DIR/ti\_components/os\_tools/linux/targetfs/opt/vision\_sdk  
respectively.

It will also execute make linux\_install to copy all binaries needed to boot into \$INSTALL\_DIR/vision\_sdk/binaries/\$(MAKEAPPNAME)/<MAKECONFIG>/hlos/linux/boot and \$INSTALL\_DIR/ti\_components/os\_tools/linux/targetfs/boot

7. The file system under \$INSTALL\_DIR/ti\_components/os\_tools/linux/targetfs now can be used as either NFS or rootfs on sd card.

- a. Tar the file system and keep it in  
\$INSTALL\_DIR/vision\_sdk/binaries/\$(MAKEAPPNAME)/<MAKECONFIG>/hlos/linux/boot folder.

**Important Note:** With 4.4 kernel filesystem 4GB and above card is required.

```
$>export INSTALL_DIR=<installation_directory_absolute_path>
$>cd $INSTALL_DIR/ti_components/os_tools/linux/targetfs
$>tar cvf tisd-k-rootfs-image-dra7xx-evm.tar.xz ./*
$>mv ./tisd-k-rootfs-image-dra7xx-evm.tar.xz
$INSTALL_DIR/vision_sdk/binaries/$(MAKEAPPNAME)/<MAKECONFIG>/hlos/linux/boot
$>exit
```

### 3.1.1 NFS + SD boot

**Important Note:** You need to keep file system in two places (idiosyncrasy of 4.4 kernel). The zImage and dra7-evm-infoadas.dtb/dra72-evm-infoadas.dtb/dra71-evm-infoadas.dtb is picked up from /boot folder on the sd card always while firmware binaries are picked up from \$

\$INSTALL\_DIR/ti\_components/os\_tools/linux/targetfs /lib/firmware

\$INSTALL\_DIR/ti\_components/os\_tools/linux/targetfs is used as NFS

For NFS to work, \$INSTALL\_DIR/ti\_components/os\_tools/linux/targetfs needs to be exported from /etc/exports of installation machine.

Refer [section 4.2](#) to prepare SD card for NFS.

Note: NFS Boot is failing in case of TDA2ex 17x17 for this release

### 3.1.2 SD only boot

The tarred file system needs to be flashed on sd card along with uboot and uenv.txt refer [section 4.2](#)

## 3.2 Build Linux Vision SDK for AVB Capture, Decode and Display UCs

*Note: if you are trying this after 3.1, ensure you do a 'make clean' and manually delete \$INSTALL\_DIR/vision\_sdk/binaries/\$(MAKECONFIG) folder and then proceed*

**NOTE: AVB is not supported on tda2px in this release**

- You must have followed all the steps in software installation and setup [section 2.4](#)
- Ensure that** A15\_TARGET\_OS := Linux and NDK\_PROC\_TO\_USE=ipu2 in \vision\_sdk\\$(MAKEAPPNAME)\configs\\$(MAKECONFIG)\cfg.mk
- IMP:** Patch the dra7-evm.dts (or dra72-evm-common.dtsi for TDA2ex/TDA2ex 17x17) from kernel (ti\_components/os\_tools/linux/kernel/omap/arch/arm/boot/dts) as shown below

#### Change below

```
&mac {
    status = "okay";
to
&mac {
    status = "disabled";
```

Basically you need to disable mac from Kernel so VSDK can use it exclusively.

- Build the linux dependencies, this will build kernel, u-boot and sgx drivers
- NOTE:** This step is needed only first time you build or if you make any changes to u-boot/kernel/sgx drivers, otherwise this can be skipped.

```
$> cd $INSTALL_DIR/vision_sdk/build
$> make linux -j
$> make linux_install -j
$> make -s -j depend
$> make -s -j
```

- Disable all cores in \vision\_sdk\\$(MAKEAPPNAME)\configs\\$(MAKECONFIG)\cfg.mk except IPU1\_0, IPU2 and A15 using PROC\_<CORE\_NAME>\_INCLUDE
- Refer steps 4 to 7 in [section 3.1](#)

## 3.3 Build Linux Vision SDK for LCD display (M4 Display)

*Note: Only TDA2xx and TDA2ex support 10.1" LG LCD.*

- You must follow all the steps in software installation and build.
- Change the dbt picked in the uenv.txt from  
fdtfile=dra7-evm-infoadas.dtb → fdtfile= dra7-evm-infoadas-lcd-lg.dtb for tda2xx  
fdtfile=dra72-evm-infoadas.dtb → fdtfile=dra72-evm-infoadas-lcd-lg.dtb for tda2ex

## 4 Run


### 4.1 Board Setup

Refer corresponding setup documents from  
\$INSTALL\_DIR/vision\_sdk/docs/VisionSDK\_UserGuide\_TDAxxx.pdf

*Note: The setup is different for 1ch / 4ch LVDS capture + SGX display and AVB->Decode->SgxDisplay usecase.*

#### 4.1.1 Capture switch setting

Video Config pins needs to set for different capture inputs







**VIDEO CONFIG switch settings (SW3 on TDA2xx Vision Application Board (set for Ov10635 in Original version of CPLD))**

Capture Type	Hardware controlled pin settings Vision Application Board (Rev C CPLD) (default cpld image)							
	1	2	3	4	5	6	7	8
OV10635	OFF	ON	OFF	ON	OFF	ON	OFF	ON
LVDS	OFF	OFF	ON	OFF	OFF	ON	OFF	ON
HDMI	OFF	OFF	ON	ON	OFF	ON	OFF	ON

### 4.2 Preparing SD card & Boot

1. Connect micro SD card to installation machine
2. uenv.txt changes for boot
  - a. *NFS + SD boot*
    - i. Copy uenv\_nfs.txt at  
\$INSTALL\_DIR/vision\_sdk/build/hlos/scripts/linux to  
\$INSTALL\_DIR/vision\_sdk/binaries/\$(MAKEAPPNAME)/<MAKECONFIG>/hlos/linux/boot and rename it to uenv.txt
    - ii. Update uenv.txt in folder to have right nfs path & server path
  - b. *SD only boot – Nothing to be done*
    - i. Copy and renaming is taken care by the build system.
3. Ensure  
\$INSTALL\_DIR/vision\_sdk/binaries/\$(MAKEAPPNAME)/<MAKECONFIG>/hlos/linux/boot folder appears as shown in picture after build  
Ensure the built filesystem is copied from the location (section)  
\$INSTALL\_DIR/ti\_components/os\_tools/linux/targetfs

 tisd-k-rootfs-image-dra7xx-evm.tar.xz  
 MLO  
 u-boot.img  
 uenv.txt

- Format SD card and create two partitions (boot (FAT32) and rootfs(ext4)) using script below, <parent\_device\_name> can be found using "mount" command

```

$> bash
$> cd <INSTALL_DIR>/build
$> sudo ./hlos/scripts/linux/mksdboot.sh --device /dev/<parent_device_name> --appname <MAKEAPPNAME>
--makeconfig <MAKECONFIG>
$> exit
  
```

**(MAKEAPPNAME and MAKECONFIG should be same as set in Rules.make)**

- Disconnect SD card from installation machine and insert it into EVM micro SD slot.
- Set hardware pin settings for SD Boot

Make sure the Boot Mode Select Switch is set for the SD boot mode **on TDA2xx Base EVM**. This is done by setting the pins SYSBOOT (SW2+SW3) [0:15] to the below shown position

SYSBOOT	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
	SW2								SW3							
SW Pin	1	2	3	4	5	6	7	8	1	2	3	4	5	6	7	8
SW Position	ON	ON	ON	OFF	OFF	OFF	OFF	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	ON



**IMPORTANT NOTE:** Pin setting for J6 Rev G 2.0 Silicon is as mentioned below

SYSBOOT	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
	SW2								SW3							
SW Pin	1	2	3	4	5	6	7	8	1	2	3	4	5	6	7	8
SW Position	ON	ON	ON	OFF	OFF	OFF	OFF	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	<b>8 OFF</b>

- Power on the EVM, press power reset

### 4.3 Run demos

1. Log in as root on the UART console

```
$> dra7xx-evm login: root
```

```
root@dra7xx-evm:~#
```

Following errors may be seen on display and the message can be ignored.

Trying to boot from MMC1

reading dra7-ipu2-fw.lzop

spl\_load\_file\_fat: error reading file dra7-ipu2-fw.lzop, err - -1

spl: error reading image dra7-ipu2-fw.lzop, err - -1

Failed to load module: /usr/lib/gbm/gbm\_dri.so: cannot open shared object file: No such file or directory

failed to load module: /usr/lib/gbm/gbm\_gallium\_drm.so: cannot open shared object file: No such file or directory

2. Proceed on UART console & execute

#### **(TDA2XX/TDA2EX/TDA2EX 17x17)**

```
$> cd /opt/vision_sdk
$> ./camnodes.sh
$> ./load_ocl_kos.sh (needed only for openc1 usecases)
$> source ./openc1_env.sh (needed only for openc1 usecases)
$> source ./vision_sdk_load.sh
$> ./${MAKEAPPNAME}.out
Select the demo to run
```

#### **(TDA2XX – TIDA00455/OV490 multi-channel use-case)**

```
$> cd /opt/vision_sdk
$> ./camnodes.sh
$> ./load_ocl_kos.sh (needed only for openc1 usecases)
$> source ./openc1_env.sh (needed only for openc1 usecases)
$> source ./vision_sdk_load.sh
$> ./vision_sdk_ov490_pinmux.sh
$> ./${MAKEAPPNAME}.out
Select the demo to run
```

#### **(TDA2PX – ISS single/multi-channel use-case)**

```
$> cd /opt/vision_sdk
$> source ./vision_sdk_load.sh
$> ./${MAKEAPPNAME}.out
Select the demo to run
```

#### **(TDA2XX/TDA2EX – OpenVX use-case)**

```
$> cd /opt/vision_sdk
$> source ./vision_sdk_load.sh
$> Copy test_input folder from the
ti_components/open_compute/tiovx_01_00_01_00/conformance_tests/ to
/opt/opencv/test_input
$> export VX_TEST_DATA_PATH=/opt/opencv/test_input
```

```
$> ./$(MAKEAPPNAME).out  
Select the OPenVX demo to run
```

### **SGX Load bars and prints**

For SGX loads run the following

#### **Option 1:**

```
Run the demo as normal  
Option another terminal (telnet)  
cd /opt/vision_sdk  
./pvrscope -f 0
```

#### **Option 2:**

```
Follow below commands to run the demo  
cd /opt/vision_sdk  
./camnodes.sh  
source ./vision_sdk_load.sh  
./$(MAKEAPPNAME).out &  
sleep 10  
./pvrscope -f 0 &  
fg  
Enter demo option
```

**IMPORTANT NOTE:** Some kernel logs and errors failure message will appear while running "source ./vision\_sdk\_load.sh", this is caused when DSS interrupts are disabled on A15 using omapconf write, and these errors need be ignored as it would not harm the execution

#### **4.3.1 AVB usecases**

As we do not have AVB cameras, encoded video streams being streamed from Linux PC is used as AVB source.

**IMPORTANT NOTE:** Ensure Ethernet cable is connected to port Ethernet0 (Ethernet port close to HDMI), and run the avb talker application after you choose the demo option

##### **4.3.1.1 Running avb talker binary on host PC**

1. Copy \$INSTALL\_DIR/ti\_components/networking/avbtp\_talker/avbtp\_talker.sh and 1.AVI (input file) to host PC
2. On Host machine (connected to EVM by Ethernet cable), run following command  

```
$> cd <avb_talker_install_directory>  
$> ./avbtalker.sh 1.AVI 1.AVI 1.AVI 1.AVI
```

#### **4.3.2 3D surround view demos**

Refer VisionSDK\_UserGuide\_TDA2xx.pdf (section Hardware Requirements) & VisionSDK\_SurroundView\_DemoSetUpGuide.pdf to set-up the surround view demos and run the use-case.

Refer VisionSDK\_3D\_SurroundView\_Calibration\_UserGuide\_TDA2xx.pdf for 3D surround view calibration use-case.

Erase the calibration table, when run the demo first time on any new set-up after boot-up by

```
# rm -rf /home/root/.calibtable
```

**NOTE:** In case of green artifacts on display, try changing toggling polarity of capture using the script `./VipClockInversion.sh`

#### **4.3.3 TIDA00455/OV490 based capture, 3D surround view and SGX display**

Refer to section [4.3](#) for steps to run the use-case. In case of green artifacts on display, try changing toggling polarity of capture using the command `"omapconf write 0x4A002534 0x0"` or `"omapconf write 0x4A002534 0x5"`. 0x5 is the recommended setting – it might vary based on different OV490 firmwares/board versions/etc. This command can be run before running `$(MAKEAPPNAME).out` or while the use-case is running from another terminal by connecting via telnet.

#### **4.3.4 With UB964 EVM (CSI2 based capture only)**

Refer UB964 EVM (CSI2 based capture only) 2.3.1 section on bios user guide for CSI2 hardware setting for surround view settings.

**NOTE: For Tda2px refer**

**`$INSTALL_DIR/vision_sdk/docs/VisionSDK_UserGuide_TDA2px.pdf`**



## 5 Revision History

Version	Date	Revision History
1.0	30th June 2014	Initial Version
1.1	30th July 2014	Updated for vision sdk 2.03
1.2	17 th Dec 2014	Updated for 2.05
1.3	28 <sup>th</sup> Feb 2015	Updated for 2.06
1.4	12 <sup>th</sup> Oct 2015	Updated for 2.08
1.5	17 <sup>th</sup> March 2016	Updated for 2.09
1.6	28 <sup>th</sup> June 2016	Updated for 2.10
1.7	5 <sup>th</sup> December 2016	Clean up and Minor updates
1.8	11 <sup>th</sup> Jan 2017	Update for 4.4 kernel support
1.9	2 <sup>nd</sup> February 2017	Updated for 2.12
2.0	30 <sup>th</sup> March 2017	Updated for PSDK 3.2 migration
2.1	14 <sup>th</sup> April 2017	Updated for 2.12.02
2.2	29 <sup>th</sup> June 2017	Updates for 3.00.00
2.3	19 <sup>th</sup> July 2017	Updates as per e2e comments For bug id ADASVISION-1608
2.4	12 <sup>th</sup> Oct 2017	Updates for 3.01.00
2.5	13 <sup>th</sup> Oct 2017	Updates for TDA2px For requirement id ADASVISION-1080

« « « § » » »