

Vision SDK

(v03.07.01)

Frequently Asked Questions (FAQs)

Copyright © 2014 Texas Instruments Incorporated. All rights reserved.

Information in this document is subject to change without notice. Texas Instruments may have pending patent applications, trademarks, copyrights, or other intellectual property rights covering matter in this document. The furnishing of this documents is given for usage with Texas Instruments products only and does not give you any license to the intellectual property that might be contained within this document. Texas Instruments makes no implied or expressed warranties in this document and is not responsible for the products based from this document.

IMPORTANT NOTICE

Texas Instruments and its subsidiaries (TI) reserve the right to make changes to their products or to discontinue any product or service without notice, and advise customers to obtain the latest version of relevant information to verify, before placing orders, that information being relied on is current and complete. All products are sold subject to the terms and conditions of sale supplied at the time of order acknowledgment, including those pertaining to warranty, patent infringement, and limitation of liability.

TI warrants performance of its products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are utilized to the extent TI deems necessary to support this warranty. Specific testing of all parameters of each device is not necessarily performed, except those mandated by government requirements.

Customers are responsible for their applications using TI components.

In order to minimize risks associated with the customer's applications, adequate design and operating safeguards ought to be provided by the customer so as to minimize inherent or procedural hazards.

TI assumes no liability for applications assistance or customer product design. TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right of TI covering or relating to any combination, machine, or process in which such products or services might be or are used. TI's publication of information regarding any third party's products or services does not constitute TI's approval, license, warranty or endorsement thereof.

Reproduction of information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations and notices. Representation or reproduction of this information with alteration voids all warranties provided for an associated TI product or service, is an unfair and deceptive business practice, and TI is neither responsible nor liable for any such use.

Resale of TI's products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service, is an unfair and deceptive business practice, and TI is not responsible nor liable for any such use.

Also see: Standard Terms and Conditions of Sale for Semiconductor Products.
www.ti.com/sc/docs/stdterms.htm

Mailing Address:

Texas Instruments
Post Office Box 655303
Dallas, Texas 75265

Copyright © 2014, Texas Instruments Incorporated

TABLE OF CONTENTS

1	Frequently Asked Questions.....	4
1.1	Hardware Board Related FAQs	4
1.2	Stereo run related FAQs.....	5
1.3	Build, install, load, run related FAQs	6
1.4	PM and resource related FAQs.....	9
2	Revision History	11

1 Frequently Asked Questions

1.1 Hardware Board Related FAQs

Q. I selected a use-case and it hangs during initialization
Make sure you are running the SCV use-case on SCV hardware setup and LVDS use-case on LVDS hardware setup. For LVDS hardware use 12V and 7A supply only.
Q. Even after following all the steps I see a incorrect / distorted image on the LCD ?
The issue could be with the CPLD programming on the Vision Application Board. Contact TI local support for reprogramming the CPLD image. The CPLD controls the how the sensor data lines are routed to the VIP port of the SoC. By default CPLD is programmed for the SCV use-case.
Q. Sometimes I see a message "LCD not connected" on the UART console after running the use-case but I see normal display on the LCD
Ignore this message, the software / hardware is falsely reporting LCD is not connected.
Q. LVDS use-case init hangs on first try after power-cycle
Make sure all Sensors are connected as mentioned in earlier section. For LVDS hardware use 12V and 7A supply only.
Q. Sometimes LVDS setup hangs during use-case initialization second time after power-cycle
Suspecting this to be a board connectivity issue. Tighten the application / deserializer boards, Power cycle and retry. For LVDS hardware use 12V and 7A supply only.
Q. After CCS reload without power-cycle LVDS setup hangs during use-case initialization
Suspecting this to be a board connectivity issue. Power cycle, reset the board and retry.
Q. Sometimes when connecting to A15 via CCS we get a message "Router sub-path could not be accessed"
Power cycle, reset the board and JTAG emulator and retry.
Q. I select the LCD demo but I see only colors/color bar no display , logs show proper numbers
Please verify the LCD selected, is it 7" or 10". If its wrongly selected it LCD runs the default test.
Q. Sometimes application does not come to main menu after reloading from CCS
Power cycle before reloading application
Q. I selected a use-case and it displays green or blue color screen instead of video display on LCD
Please ensure you have selected proper display using 's' (setting option), Display

settings.
Q. On TDA3xx EVM my network application doesn't work when I enable FATFS through FATFS_PROC_TO_USE.
On TDA3xx due to pin mux configuration conflicts (same pins shared by SD and Ethernet), the SD and Ethernet can't be used simultaneously. To use Ethernet after NDK_PROC_TO_USE is set to, 'FATFS_PROC_TO_USE=none' should be also set and vice versa. The autorules_footer_cfg.mk makes sure the above is taken care. User should not override this configuration.
Q. When I use AR0140_TIDA00262 cameras on TDA3X/TDA2PX the image colors look unnatural and have purple cast.
If the AR0140_TIDA00262 camera modules are connected to UB964 revision 3 chip, then there is one line downshift is observed in the captured frame. To encounter the problem the bayer pattern should be changed from 'SYSTEM_DF_BAYER_GRBG' to 'SYSTEM_DF_BAYER_BGGR' in the "IssSensor_AR0140_TIDA_Init()" function defined in the \vision_sdk\apps\src\rtos\iss\src\sensor\ar0140\iss_sensor_ar0140.c file. Change info->dataFormat = SYSTEM_DF_BAYER_GRBG; to info->dataFormat = SYSTEM_DF_BAYER_BGGR;
Q. TDA3XX EVM:The ISS capture doesn't work with the UB960 EVM with 25 MHz crystal.
The CSI2 PHY clock should be set to 750 MHz. Pl. change the CSI PHY clock from 800 MHz to 750 MHz in '\vision_sdk\apps\src\rtos\iss\src\sensor\iss_sensor_tda3xx.c' file for either TIDA/IMI camera modules.
Q. How to use Non-IMI OV10635 cameras with Vision SDK?
The way to enable Non-IMI OV10635 cameras is to uncomment the #define BSPUTILS_LVDS_IMI2_CAM_ENABLE in pdk/packages/ti/drv/vps/examples/utility/src/bsputils_lvds.c in the PDK package. After doing so, build dependency by "make -j depend", "make -j" and test.
Q. HW modifications required for DS90UB960 EVM to work with DS90UB913A Cameras and TDA2Px EVM
When interfacing to DS90UB913A-Q1 and DS90UB933-Q1 serializers, the PoC filter needs to be adjusted to match the circuit shown in http://www.ti.com/lit/ug/snlu226a/snlu226a.pdf . Section 6.2 Power Over Coax Interface

1.2 Stereo run related FAQs

Q: Output of the stereo usecase is noisy, what can be done?
Ans: Ensure you have calibrated stereo sensors for the unit that you have. Stereo algorithm works on right and left images captured from stereo sensors and calculates disparities. If cameras are not calibrated the entire output won't be a correct depth map.
Q: When I connect mini USB to USB to my PC, I don't see anything on TeraTerm/HyperTerminal

Ans: Most likely you have missed installing FDTI chip drivers refer section 2.2.1

1.3 Build, install, load, run related FAQs

Q. My build is failing when I use gmake -s -j depend. I see wired folder not found error even if folder path is present .

Please verify which gmake is used. You need to point to xdc gmake , Run which gmake for git bash / where gmake for cmd.

Q. How do I speed up build and load time ?

Refer VisionSDK_UserGuide_BuildSystem.pdf on tips to reduce build time.

Q. How can I change build option from release to debug for a processor core?

In file `\vision_sdk\apps\configs\$(MAKECONFIG)\cfg.mk`, there is an option to set build type for each processor core. For ex: For DSP1, PROFILE_c66xdsp_1 can be set as release as debug.

Q. While building linux I see the error IPU1 is not included in build which is needed?

For Linux build primary core is ipu2/ipu1. In this release we have primary core as IPU2, thus the scripts throw it as error. This can be ignored

Q. I am using Windows 7 and when I build I get errors no permission to generate batch file?

Please check all the steps to build are followed , Try running as administrator .

Even if the issue exists there may be specific settings set for the PC.

There would be some makefile changes to be done.

CACLS \$(DEST_ROOT)/maketemp_configuro_cmd_\$(CORE).bat /E /P Everyone:F

To be replaced by

ICACLS \$(DEST_ROOT)/maketemp_configuro_cmd_\$(CORE).bat /grant Administrator:(OI)(CI)F

This is to be changed in rules_m4.mk rules_a15.mk rules_66.mk rules_arp32.mk

Q. Can the version of tools or other components be changed? If yes, how?

Please check with the support team if this release can work with versions other than the ones present in the release package. If yes, then component install path can be controlled via the file `\vision_sdk\tools_path.mk`. Paths for several tools and components used are provided in this file.

Q. Is Linux based build supported?

Linux based build can be supported, but it needs linux based compiler tools (GCC, M4, DSP, EVE cgtools) and XDC to be installed. Two installer packages are for released - one for windows with windows compiler tools and other for linux with linux compiler tools. Make sure to install the appropriate one depending on the machine you wish to compile on.

Q. In Surround View Demo I don't see proper display, whereas video from sensor shows proper data.

Yes , This issue is observed if previous Surround view demo calibration tables are not written completely to qspi memory.

You have to erase table from the qspi memory and recalibrate . Option is available runtime in the same demo.

Q. Is there any script to automate loading and running of cores via CCS
Yes, this is possible via CCS based debug server scripting (DSS). Refer to a sample script file located at \vision_sdk\build\rtos\scripts\launch_visionsdk_tdaNxx.js. Refer to comments in this file for customizing as required.
Q. How to ensure alignment when sharing data structures across cores
When data structures are accessed across cores, it's a good practice to ensure all elements are 32-bit – this ensures structures are 32-bit aligned. Alternately when defining data-structure programmer can take care of alignment by declaring 32-bit first, then 16-bit and later 8-bit data. This will ensure no packing.
Q. How to enable Dual A15 (SMP Bios) – TDA2xx ONLY
Set the build option "DUAL_A15_SMP_BIOS=yes" in \vision_sdk\apps\configs\\$(MAKECONFIG)\cfg.mk to enable both A15 cores of TDA2xx. Refer VisionSDK_UserGuide_BuildSystem.pdf for more details about this option.
Q. OCMC Ram1 heap is not usable in VISION_SDK by default. How it can be enabled
OCMC_CBUF based use-cases use OCMC_RAM1. When these are used, OCMC_RAM1 cannot be used as HEAP as the CBUF usage can destroy heap related data structures. If user wants to use, OCMC_RAM1 as heap, define UTILS_MEM_HEAP_OCMC_SIZE in utils_mem_cfg.h In that case, CBUF-based use-cases (SRV/DeWarp/Sub-FrameCopy) cannot be used.
Q. EVE self-branch instruction block - EVE1_VECS (Important Note – refer mem_segment_definition_512mb.xs)
In SBL, EVE self-branch instruction is inserted @ 0x80000000 if no AppImage for EVE (if EVE is not enabled in the build). This could overwrite the code/data loaded at 0x80000000. So Reserve a small memory block in the beginning of the DDR @0x8000 0000 for EVE self-branch instruction if no AppImage for EVE. If EVE is enabled, then the EVE VECS/DATA/CODE is placed @0x8000 0000, and hence we did not observe any issue. If EVE is disabled, then also DO NOT remove this EVE1_VECS section @0x80000000, which is used by SBL to place EVE self-branch instruction.
Q. AppImage flashing is failing for qspi in default configuration.
In default configuration the imae size is ~40MB. Whereas QSPI has support till 32 MB. In case of SRV usecase the LUT occupies some space. Hence disable unwanted usecase and rebuilds
Q. VSDK when build on VM with -j option gets stuck some times.
Use -jn option instead of -j where 'n' is the number of PC cores used to build the executable.
Q. VSDK build fails on Windows with "vision_sdk_PATH" value not found.
Set the path as below and then try the build. set Path=C:\PROCESSOR_SDK_RADAR_<version>\ti_components\os_tools\windows\xd

ctools_<version>_core;C:\windows\system32;C:\windows;C:\windows\System32\Wbem;C:\windows\System32\WindowsPowerShell\v1.0\	
Q. VSDK build fails on Windows command prompt	
Certain utilities used during the build should be called from XDCtool bin folder. Having the MinGW path or some other path which includes the utilities with same name could cause build errors due to version difference. Make sure to remove such paths from system PATH environment variable.	
Q. Warning message as app_alg_plugins/tda2px-evm/66/debug/GAlignLUT_tda3xx.oe66' given more than once in the same rule is seen in build.?	
GALIGN and SYNT both use same LUT present in a single file , If the files are compiled only under one algo , then if other algo is moved to different core there would undef error . to avoid this undef error the files are added for both the algo. Currently we are using both algo in same core hence re def warning should be ignored	
Q. Where to look for all the supported build options	
Please refer \vision_sdk\docs\FeatureSpecificUserGuides\VisionSDK_UserGuide_BuildSystem.pdf for all supported build options You can also refer \vision_sdk\apps\configs\<MAKECONFIG>\cfg.mk	
Q. OPENVX Graph pipeline is not working on TDA2Ex	
As TDA2Ex does not have DSP2 core. So it will not work.	
Q. IPU1_1 is not working with Autosar usecase	
IPU1_1 is not supported with Autosar config when all cores running BIOS IPC. Please use IPCLIB in order to support IPU1_1.	
Q. How to increase H264 encoding bitrate?	
Please change the below file vision_sdk\links_fw\src\rtos\links_ipu\iva\iva_enc\encLink_h264.c staticParams->videnc2Params.level = IH264_LEVEL_40; to staticParams->videnc2Params.level = IH264_LEVEL_42; Please go through the below link for the desired level http://blog.mediacoderhq.com/h264-profiles-and-levels/	
Q. How to add a new usecase in SDK	
How to add a new library and algorithm plugin in the SDK.	
Refer \vision_sdk\docs\FeatureSpecificUserGuides\VisionSDK_UserGuide_BuildSystem.pdf Section 6 for adding new UC and Alg plugin Section 8 for adding a new lib to application Customer can also refer one of the existing UC or Alg plugin of SDK to understand	

the integration steps and details.
Q. How to add a new memory map into VSDK or how can I modify the existing memory map of VSDK
Refer \\vision_sdk\docs\FeatureSpecificUserGuides\VisionSDK_UserGuide_MemoryMap.pdf for understanding VSDK memory map in detail and how to modify the same.
Q. How to enable DUAL MAC in NSP/Vision SDK
Follow below 2 steps: 1. Rebuild NSP package with DUAL MAC feature enabled Refer ti_components\networking\nsp_gmacsw_4_16_00_00\docs\nsp_gmacsw_4_16_00_00_user_guide.html for rebuilding NSP package with Dual MAC feature enabled 2. Apply BSP patch & Rebuild Vision SDK Apply BSP patch shared in vision_sdk\docs\Patches (0001-PAD-Mux-changes-to-enable-Dual-MAC.patch) to ti_components\drivers\pdk\packages\ti\drv\vpv repository & Follow User Guide to rebuild Vision SDK

1.4 Data Capture on cascade radar using Radar Studio

Q. How Cascade radar uses around 1 GB for shared location
For cascade radar 1023 MB from linux high mem starting from 0xC0000000 is reserved and which is not visible to IPU but visible to VPDMA and A15 core.

1.5 PM and resource related FAQs

Q. How to Enable/Disable CPUIDLE functionality. How is it advantages using CPUIDLE.
CPUIDLE functionality helps in power saving, When the core is executing idle instruction the ip are put in sleep/Standby mode.
Q. I see the core is halted at IDLE/WFI instruction every time when I load the symbols in release mode
This is because of Power Management and CPUIDLE enabled in Vision SDK. The core executes idle/wfi instruction when idle. It wakes up on interrupt and hence debug the code in release mode becomes difficult. When binaries are built in debug mode CPUIDLE is disabled.
Q. How can I debug when binaries are in release mode. The application doesn't step when in WFI/IDLE looks like hung state.
If in case debugging release mode binary is essential then, CPUIDLE needs to be disables for eliminating the WFI/IDLE issue, CPU_IDLE_ENABLED=no in \\vision_sdk\apps\configs\\$(MAKECONFIG)\cfg.mk file in vision_sdk
Q. A15 is a debug binary but still is see WFI instruction hit when we pause.
In case of Vision Sdk, A15 is build as debug binary; The PROFILE used to build is Release so PM will be included.

The Build Profile needs to debug to remove CPU_IDLE from the build.
Q. Does Vision Sdk use GP timer in their configurations which are those?
Yes, Vision Sdk does use the timers. Timer 1,2 5,6 9,11 are been used by SDK .
Q. Interrupts used by temperature utils
Vision Sdk uses interrupt no 61 for temperature Temperature Sensor Interrupt. A hot and cold events are triggered to the assigned interrupt number. Temperature hot and cold threshold can be set using api in utils_temperature.h
Q. Timers used by CPU cores to allow CPU load and BIOS Tick when CPUs are powered down
Vision SDK uses GP Timers for the cores (2 per ISA) to use a proxies for the BIOS Tick and TimeStampProvider. To know which timers are used for which CPU core on which device refer the VisionSDK_DevelopmentGuide Chapter 7.1.2
Q. The TDA2xx Vision SDK log on typing 'p' shows the following message: <pre>[IPU1-0] Name Bus (mV) Res (mOhm) Shunt (uV) Current (mA) Power (mW) [IPU1-0] ----- [IPU1-0] UTILS_PRCM_STATS: Reading the regulator data failed [IPU1-0] UTILS_PRCM_STATS: PM INA226 Power Read Failed !!</pre>
This is a harmless message which basically means the power measurement from TDA2xx to access INA226 registers has failed. If your intention is to measure power from TDA2xx, kindly make sure that the TDA2xx EVM is modified with the changes mentioned in VisionSDK_UserGuide_TDA2xx.pdf

2 Revision History

Version	Date	Revision History
1.0	25 Aug 2016	Initial Version. Collated FAQs from different user guides in a single file
1.1	2 nd Nov 2016	Updated for Release 2.11.00
1.2	7 th Feb 2017	Updated for Release 2.12.00
1.3	29 th Mar 2017	Updated for Release 2.12.02
1.4	28 th June	Updated for Release 3.0.0
1.5	16 th Oct 2017	Updated for Release 3.01.0
1.6	29 th Nov 2017	ADASVISION-1705 Fix added
1.7	23 rd Aug 2018	Removed CDDS link
1.8	7 th June 2019	Updated for Release 3.07
1.9	18 th July 2019	Updated for Release 3.07.01

« « « § » » »