MMWAVE MCUPLUS SDK User Guide



Product Release 4.7.1.4 Release Date: Jul 11, 2025 Document Version: 1.0

🖊 Texas Instruments

DOCUMENT LICENSE

This work is licensed under the Creative Commons Attribution-Share Alike 3.0 United States License (CC BY-SA 3.0). To view a copy of this license, visit http://creativecommons.org/licenses/by-sa/3.0/us/ or send a letter to Creative Commons, 171 Second Street, Suite 300, San Francisco, California, 94105, USA.

COPYRIGHT

Copyright (C) 2014 - 2025 Texas Instruments Incorporated - http://www.ti.com

DISCLAIMER


This mmWave SDK User guide is generic and contains details about all the mmWave devices that are supported by TI in general. However, note that not all mmWave devices may be supported in a given mmWave SDK release. Please refer to the mmWave SDK Release notes to understand the list of devices/platforms supported in a given mmWave SDK release.

NOTICE: This software product is used to configure TI's mmWave devices, including RF emissions parameters for such devices. Note that many countries or regions impose regulations governing RF emissions. Users are responsible for understanding local RF emission regulations and operating the product within those regulations.

CONTENTS

	f-box mmWave Experience
2. Syste	m Overview
	2.1. mmWave Suite 2.2. mmWave Demos
	2.3. External Dependencies
	2.4. Terms used in this document
	2.5. Related documentation/links
Gettir	ig started
	3.1. Hardware Setup (EVM Details)
	3.1.1. AWR294x (EVM_UG) 3.1.2. AWR2544 (EVM_UG)
	3.1.3. AWR2X44P (AWR2E44P EVM_UG, AWR2944P EVM_UG)
	3.2. Programming mmWave devices
	3.3. Loading images onto EVM
	3.3.1. Demonstration Mode
	3.3.2. CCS development mode
	3.4. Running the Demos 3.4.1. Power ON EVM
	3.4.2. mmWave Demo Visualizer - AWR294X and AWR2x44P
	3.4.3. Data Collection and Visualization - AWR2544
	3.5. mmWave SDK OOB Demo with LVDS Based Instrumentation
	3.6. mmWave SDK OOB Demo with Ethernet Streaming Enabled
	3.7. Configuration (.cfg) File Format
	3.8. Running the prebuilt unit test binaries (.xer5f, .xem4 and .xe66)3.9. SDK Clock Configurations
	3.9.1. AWR294x
	3.9.1.1. Default SBL clock configurations
	3.9.1.2. SBL clock configurations for BSS dynamic clocking feature
	3.9.1.3. Peripheral Clock Configurations
	3.9.2. AWR2544
	3.9.2.1. Default SBL clock configurations 3.9.2.2. SBL clock configurations for BSS dynamic clocking feature
	3.9.3. AWR2X44P
	3.9.3.1. Default SBL clock configurations
	3.9.3.2. SBL clock configurations for BSS dynamic clocking feature
	3.9.3.3. Peripheral Clock Configurations
	3.9.3.4. Ethernet configuration changes (Gigabit speed) To Articles
4. HUW-	4.1. How to identify the COM ports for mmWave EVM
	4.2. How to flash an image onto mmWave EVM
	4.2.1. Tool requirements on host PC:
	4.2.2. Python3 Setup
	4.2.3. Flash Procedure using UniFlash GUI (Applicable for AWR294x (not applicable for AWR2X44P))
	4.2.4. Flash Procedure using Python tools 4.3. How to connect mmWave EVM to CCS using JTAG
	4.3.1. Emulation Pack Update
	4.4. How to run mmWave demo with LVDS-based instrumentation
	4.5. How to Run MMWAVE SDK OOB Demo with Ethernet Streaming Enabled
	4.5.1. Setting up
	4.5.1.1. Connections
	4.5.1.2. Software 4.5.1.3. Capturing Detected Object Data over Ethernet using OOB Demo
	4.6. How to test AWR2544 OOB demo with integrated PTP stack during development
	4.6.1. Hardware Setup
	4.6.2. Software
	4.7. How to use Custom Flash Device
	4.8. How to optimize MSS_L2 memory for SBL over ethernet example (sbl_qspi_enet)
	4.9. How to erase flash memory4.10. How to configure Automotive PHY
	4.10. How to configure Automotive PHY 4.10.1. OOB demo changes for Auto PHY with osc_clk_out_eth
	4.10.1. OOB denio changes for Add PPPP with 050_cik_odd_eth 4.11. How to enable BSS Logger in OOB Demo (AWR2544)
	4.12. How to migrate examples from package to package (AWR2x44P)
	4.13. How to enable using the same application after R5F core reset
	4.14. Developing using SDK
	4.14.1. Build Instructions





- 6.8.2. Inter-frame debugging
- 6.8.3. Using non-real time chain test code
- 6.8.4. Viewing hardware registers
- 6.8.5. Viewing expressions/memory in real time
- 6.9. Shared memory
- 6.10. Size of Enum

LIST OF FIGURES

3.7.1.1.1. Figure 2: Chirp Diagram

- 4.1.1.1.1 Figure 3: mmWave EVM PC Connectivity Device Manager COM Ports
- 5.1.1.1.1. Figure 4: Autonomous mmWave sensor (Standalone mode)
- 5.1.1.1.2. Figure 5: SDK Layered block diagram
- 5.2.1.1.1. Figure 6: Typical mmWave radar processing chain
- 5.2.1.1.2. Figure 7: Typical mmWave radar processing chain using mmWave SDK components
- 5.2.1.1.4. Figure 8: Scalable data processing chain using mmWave SDK
- 5.3.1.1.1. Figure 9: Typical mmWave radar control flow
- 5.3.1.2.1. Figure 10: mmWave Isolation mode: Detailed Control Flow (Init sequence)
- 5.3.1.2.2. Figure 11: mmWave Isolation mode: Detailed Control Flow (Config sequence)
- 5.3.1.2.3. Figure 12: mmWave Isolation mode: Detailed Control Flow (start sequence)



5.3.1.3.1. Figure 13: mmWave Co-operative Mode: Detailed Control Flow (Init sequence)
5.3.1.3.2. Figure 14: mmWave Co-operative Mode: Detailed Control Flow (Config sequence)
5.3.1.3.3. Figure 15: mmWave Co-operative Mode: Detailed Control Flow (Start sequence)
5.3.2.1.1. Figure 16: Typical mmWave Detection Processing Layers
5.3.2.2.1. Figure 17: Data processing flow with local domain control (init/config)
5.3.2.2.2. Figure 18: Data processing flow with local domain control (start/chirp/frame/stop)
5.3.2.3.2. Figure 20: Data processing flow with remote domain control (start/chirp/frame/stop)
5.3.2.4.1. Figure 21: Distributed Data processing flow and control (init/config)
5.3.2.4.2. Figure 22: Distributed Data processing flow and control (start/chirp/frame/stop)
5.5.4.1.1. Figure 24: mmWave API - Internal software design
5.5.6.1.2. Figure 26: DPU - typical call flow

5.5.7.1.1. Figure 27: Datapath manager (DPM) - internal software design

LIST OF TABLES

3.7.1.1.2. Table 1: mmWave SDK Demos - CLI commands and parameters
3.9.1.1.1. Table 1: mmWave SDK Demos - Clock configurations
3.9.1.2.1. Table 2: mmWave SDK Demos - Clock configurations for BSS dynamic clocking
3.9.2.1.1. Table 1: mmWave SDK Demos - Clock configurations
3.9.2.2.1. Table 2: mmWave SDK Demos - Clock configurations
3.9.3.2.1. Table 1: mmWave SDK Demos - Clock configurations
3.9.3.2.1. Table 2: mmWave SDK Demos - Clock configurations

🦊 Texas Instruments

1. Out-of-box mmWave Experience

To experience the mmWave technology offered by TI, you will need to procure the following

- Hardware
 - 1. mmWave TI EVM
 - 2. Power supply cable as recommended in TI EVM user guide 3. PC
- Software
 - 1. Pre-flashed mmWave Demo running on TI EVM (See instructions in this user guide on how to update the flashed demo)
 - 2. Chrome browser running on PC

Next, to visualize the data flowing out of TI mmWave devices, follow these steps

- 1. Connect the EVM to a power outlet via the power cable and to the PC via the included USB cable. EVM should be powered up and connected to PC now.
- 2. On your PC, browse to https://dev.ti.com/gallery/view/mmwave/mmWave_Demo_Visualizer in Chrome browser and follow the prompts to install one-time software. [No other software installation is needed at this time]
- 3. The Visualizer app should detect and connect to your device via COM ports automatically (except for the very first time where users will need to confirm the selection via OptionsSerial Port). Select the right Platform and SDK version and start your evaluation!
 - a. Hint: Use HelpAbout to know your Platform and SDK version

AWR2544 Visualizer

Download Visualizer from https://www.ti.com/tool/download/MMWAVE-MCUPLUS-SDK/<version>

User Guide: mmwave_mcuplus_sdk_<ver>/mmwave_mcuplus_sdk_<ver>/docs/mmWave_Demo_Visualizer_UserGuide.pdf

For details on how to evaluate, any troubleshooting needs and/or to understand the know-how behind these steps, continue reading this SDK User Guide...

If the flashed demo on the EVM is an old version and you would like to upgrade to latest demo, continue reading this SDK User Guide...

2. System Overview

The mmWave SDK is split in two broad components: mmWave Suite and mmWave Demos.

2.1. mmWave Suite

mmWave Suite is the foundational software part of the mmWave SDK and would encapsulate these smaller components:

- Drivers (Part of the MCU PLUS SDK)
- DPL (Part of the MCU PLUS SDK)
- mmWaveLink and Firmware (Part of the Device Firmware Package DFP)
- mmWave API
- · Data processing layer (manager, processing units)
- Board Setup and Flash Utilities

2.2. mmWave Demos

SDK provides demos that depict the various control and data processing aspects of a mmWave application. Data visualization of the demo's output on a PC is provided as part of these demos. These demos are example code that are provided to customers to understand the inner workings of the mmWave devices and the SDK and to help them get started on developing their own application.

• mmWave Processing Demo with TI Gallery App - "mmWave Demo Visualizer"

2.3. External Dependencies

All tools/components needed for building mmWave sdk are included in the mmwave sdk installer. But the following external components (for debugging) are not included in the mmWave SDK.

- CCS (for debugging)
- SysConfig (for building and developing applications)

Please refer to the mmWave SDK Release Notes for detailed information on these external dependencies and the list of platforms that are supported.

2.4. Terms used in this document

Terms used	Comment
xWR	This is used throughout the document where that section/component/module applies to both AWR and IWR variants
BSS	This is used in the source code and sparingly in this document to signify the RADARSS. It is also interchangeably referred to as the mmWave Front End. Note that this term will only be used in the context of AWR294X and AWR2544 SoCs.
MSS	Master Sub-system. It is also interchangeably referred to as Cortex R5F.
DSS_CM4	DSP Sub-system Cortex M4. It is also interchangeably referred to as HWA_CM4 or M4.
DSS	DSP Sub-system. It is also interchangeably referred to as DSS or C66x core.

2.5. Related documentation/links

Other than the documents included in the mmwave_mcuplus_sdk package the following documents/links are important references.

SoC links:

```
    Automotive mmWave Sensors
```

- Industrial mmWave Sensors
- Evaluation Modules (Gen1) (EVM) links:
 - Automotive Evaluation modules (Booster Pack, DEVPACK)
 - Industrial Evaluation modules (Booster Pack, ISK)



3. Getting started

The best way to get started with the mmWave SDK is to start running one of the various demos that are provided as part of the package. TI mmWave EVM comes pre-flashed with the mmWave demo. However, the version of the pre-flashed demo maybe older than the SDK version mentioned in this document. Users can follow this section and upgrade/run the flashed demo version. The demos (source and pre-built binaries) are placed at mmwave_mcuplus_sdk_<ver>/ti/demo/<platform>/mmw/ folder.

mmWave Demo

This demo is located at mmwave_mcuplus_sdk_<ver>/ti/demo/<platform>/mmw folder. The millimeter wave demo shows some of the radar sensing and object detection capabilities of the SoC using the drivers in the mmWave SDK (Software Development Kit). It allows user to specify the chirping profile and displays the detected objects and other information in real-time. A detailed explanation of this demo is available in the demo's docs folder and can be browsed via mmwave_mcuplus_sdk_<ver>/ docs/mmwave_sdk_module_documentation.html. This demo ships out detected objects and other real-time information that can be visualized using the TI Gallery App - 'mmWave Demo Visualizer' hosted at -https://dev.ti.com/gallery/view /mmwave/mmWave_Demo_Visualizer. The version of the mmWave Demo running on TI mmWave EVM can be obtained from the Visualizer app using the HelpAbout menu.

Device	Demo Directory	Binary prefix	Platform selection in Visualizer	mmwavelink Library	DFP Firmware
AWR294X	TDMA, DDMA and TDMA ENET:. ti\demo\awr294x\mmw\	awr294x_mmw_demo	AWR294X	mmwave_dfp_02_04_ <ver>\ti \control\mmwavelink\lib</ver>	mmwave_dfp_02_04_ <ver>\firmware \radarss\xwr29xx_radarss_metarprc. bin</ver>
AWR2544	TDMA, DDMA: ti\demo\awr2544\mmw\ ti\demo\awr2544\mmw_csitx\	awr2544_mmw_demo_pm awr2544_mmw_demo_pm awr2544_mmw_csitx_demo	NA	mmwave_dfp_02_04_ <ver>\ti \control\mmwavelink\lib</ver>	mmwave_dfp_02_04_ <ver>\tirmware \radarss\xwr25xx_radarss_metarprc. bin</ver>
AWR2X44P	TDMA, DDMA, DDMA_ENET: ti\demo\awr2x44P\	awr2x44P_mmw_demo	AWR2X44P	mmwave_dfp_02_04_ <ver>\ti \control\mmwavelink\lib</ver>	mmwave_dfp_02_04_ <ver>\firmware \radarss \xwr2x4xP_radarss_metarprc.bin</ver>
AWR2X44ECO	TDMA, DDMA, DDMA_ENET:	awr2x44ECO_mmw_demo	AWR2X44P	mmwave_dfp_02_04_ <ver>\ti \control\mmwavelink\lib</ver>	mmwave_dfp_02_04_ <ver>\firmware \radarss \xwr2x4xP_radarss_metarprc.bin</ver>
AWR2X44LC	DDMA: ti\demo\awr2x44P\	awr2x44LC_mmw_demo	AWR2X44P	mmwave_dfp_02_04_ <ver>\ti \control\mmwavelink\lib</ver>	mmwave_dfp_02_04_ <ver>\firmware \radarss \xwr2x4xP_radarss_metarprc.bin</ver>

mmWave Demo (AWR2X44ECO)

Set MMWAVE_SDK_DEVICE as awr2x44P in mmwave_mcuplus_sdk_<ver>/scripts/windows/setenv.bat for AWR2x44ECO or AWR2x44LC device.

mmWave Demo (AWR294x, AWR2x44P, AWR2544 HS-SE)

Pre-built demo binaries are available at mmwave_mcuplus_sdk_<ver>/ti/demo/<platform>/mmw (<platform>_mmw_demo<proc_chain>. appimage.hs) signed with TI-dummy keys available at mcu_plus_sdk_<platform>_<ver>/tools/boot/signing. User needs to have a valid HSM-RT to use this.

Following sections describe the general procedure for booting up the device with the demos and then executing it.





3.1. Hardware Setup (EVM Details)

The EVM figures below show some important cable connections, ports and switches. Take note of the location of the "BOOT MODE" switch, this is used to switch between different boot modes like QSPI, UART, NOBOOT mode.

Refer to the EVM User Guide to understand the bootup modes of the EVM ("Sense-on-Power (SOP) Jumpers" section in mmWave device's EVM user guide) .


3.1.1. AWR294x (EVM_UG)






Boot mode switch (SOP switches)

3.1.2. AWR2544 (EVM_UG)



3.1.3. AWR2X44P (AWR2E44P EVM_UG, AWR2944P EVM_UG)



3.2. Programming mmWave devices

Here is a little insight into the mmWave devices and the programmable cores they offer. For more detailed information, please refer to the technical reference manual for the respective mmWave device. These details are needed when loading the binaries using CCS and/or to understand the various terminologies that exist in the "Getting started" section.

AWR294X

This device has one cortex R5F (MSS) core, one DSP C66x (DSS) core and one cortex R4 (BSS) core. The demos have 2 executables - one for MSS and one for DSS which should be loaded concurrently for the demos to work. The BSS binary comes as a part of the AWR294X Device Firmware Package (DFP). See Running the Demos section for more details. The unit tests may have executables for either MSS or DSS or both. These executables are meant to be run in standalone operation. This means MSS unit test executable can be loaded and run on MSS R5F without downloading any code on DSS in the CCS Development Mode. Similarly, DSS unit test executable can be loaded and run on DSS C66x without downloading any code on DSS. The exceptions to this are the mmWave unit tests under full and datapath manager (DPM) unit tests.

AWR2544

This device has one cortex R5F (MSS) core and one cortex R4 (BSS) core. The demo has an executable file which should be loaded on the MSS core. The BSS binary is a part of the Device Firmware Package (DFP). Unit test case executables can be loaded and run on MSS R5F core. See Running the Demos section for more details. In mmwave_mcuplus_sdk_<ver>/ti/demo/<platform>/mmw, there are two executable files (awr2544_mmw_demo.appimage). The mmw_pm_demo has ethernet phy loopback feature enabled and MSS Loading task can be enabled by sending CLI command.

AWR2X44P

This device has one cortex R5F (MSS) core, one M4 (DSS_CM4) core, one DSP C66x (DSS) and one cortex R4 (BSS) core. The demos have 3 executables - one for MSS, one for DSS_CM4 (in case of DDM demo), and one for DSP which should be loaded concurrently for the demos to work. The BSS binary comes as a part of the Device Firmware Package (DFP). See Running the Demos section for more details. The unit tests may have executables for either MSS, DSS_CM4, DSS or combination of multiple cores. These executables are meant to be run in standalone operation. This means MSS, DSS_CM4, or DSS unit test executable can be loaded and run on MSS R5F, DSS_CM4 or DSS C66x respectively without downloading any code on other cores in the CCS Development Mode.



3.3. Loading images onto EVM

User can choose either one of Demonstration or CCS development modes for loading images onto the EVM.

Flash part

Please note that in the case of AWR294X, AWR2544 and AWR2X44P EVMs, the flashing procedure works with the EVM with the flash part "GD25B64CWAG". Ensure that you are using the same if you want to use the demonstration mode.

Refer How to use custom flash device section for any other flash part.

3.3.1. Demonstration Mode

This mode should be used when either upgrading the factory flashed binaries on the EVM to latest SDK version using the pre-built binaries provided in the SDK release or for field deployment of mmWave sensors.

- 1. Follow the procedure mentioned in the section (How to flash an image onto mmWave EVM). Use the mmwave_mcuplus_sdk_<ver>/ti/demo /<platform>/mmw/<demo_binary>.appimage as the metaimage.
- 2. Reboot the device to run the demo image every time on power up. No other image loading step is required on subsequent boot to run the demo.
- 3. Follow the steps mentioned in Running the Demos section.

3.3.2. CCS development mode

This mode should be used when debugging with CCS is involved and/or developing an mmWave application where the .appimage files keep changing constantly and frequent flashing of image onto the board is not desirable. This mode allows you to flash once and then use CCS to download a different image to the device's RAM on every boot.

This mode is the recommended way to run the unit tests for the drivers and components which can be found in the respective test directory for that component. See section mmWave SDK - TI components for location of each component's test code

- 1. EVM and CCS setup: Follow the steps in How to connect mmWave EVM to CCS using JTAG to setup the environment for CCS connectivity.
- 2. Load the following prebuilt executables provided in the SDK release package at mmwave_mcuplus_sdk_<ver>/ti/demo/<platform>/<demo>
 - /mmw :
 - a. AWR294x: <mmwave_sdk_device>_mmw_demo_dss<proc_chain>.xe66 and/or
 - <mmwave_sdk_device>_mmw_demo_mss<proc_chain>.xer5f on C66x and R5 cores respectively.
 - b. AWR2544: mwave_sdk_device>_mmw_demo.xer5f on R5 core.
 - c. AWR2x44P: <mmwave_sdk_device>_mmw_demo_dss<proc_chain>.xe66 and/or <mmwave_sdk_device>_mmw_demo_dss_cm4 <proc_chain>.xem4 and/or <mmwave_sdk_device>_mmw_demo_mss<proc_chain>.xer5f on DSS, DSS_CM4 and R5 cores respectively.
- 3. Click on "Run" button to run the file.




4. To reload, disconnect the connected cores, power cycle the EVM and connect to the cores on CCS again.

3.4. Running the Demos

Follow this subsection to experience the mmWave functionality using the out-of-box mmWave demo. Before you proceed further, make sure that:

- 1. You have loaded the right demo binary using the section above, set the EVM to functional mode (QSPI Boot Mode) and powered up the device. If you have followed the steps correctly,
 - a. In case of Demonstration Mode, mmwave_mcuplus_sdk_<ver>/ti/demo/<platform>/mmw/<demo_binary>.appimage should have been flashed onto the EVM.
 - b. In case of CCS development Mode, mmwave_mcuplus_sdk_<ver>/ti/utils/ccsdebug/<platform>_ccsdebug.appimage should have been flashed and correct pre-built executables should have been loaded onto the EVM.
- 2. You have connected the EVM to the PC using its XDS110 micro-USB port/cable.





3.4.1.1 Figure 1: mmWave Demo Visualizer- mmWave Device Connectivity

Note: The "EVM" in the above figure refers to the AWR294X System or the AWR2544 System or the AWR2X44P System.

🗥 AW	R2544 EVM	
	AWR2544 EVM, refer unning demo with Vis	<pre>mmwave_mcuplus_sdk_<ver>/mmwave_mcuplus_sdk_<ver>/docs/mmwave_radar_visualizer_user_guide.pdf ualizer GUI.</ver></ver></pre>
If the	e user is not using Vis	sualizer, below setup needs to be done to capture 1D compressed FFT output and export via Ethernet interface.
Use	any serial terminal ap	oplication like TeraTerm and connect to Application User COM port with baudrate set to 115200.
		net cable connected between EVM RJ45 port and PC ethernet port. And PC ethernet port needs to support needs for the PC ethernet port with Linux OS:
	Q Settings	Network 🖨 🛛 🖉
	💎 Wi-Fi	
	Bluetooth	PCI Ethernet +
	Background	Cancel Wired Apply
	Dock	Details Identity IPv6 Security +
	Notifications	IPv4 Method Automatic (DHCP) Link-Local Only O Manual Disable
	Q Search	Addresses +
	Region & Language	Address Netmask Gateway 192.168.0.136 255.255.255.0
	Universal Access	
	 Online Accounts Privacy 	
	Sharing	
	● Sound	Separate IP addresses with commas
	Ce Power	Routes Automatic ON Address Netmask Gateway Metric
	🗗 Network	
	To Devices	>
	Details	>
		sdk <ver>\ti\demo\awr2544\mmw\docs\doxygen\html\index.html, section: "Enet Configuration" for Network</ver>
hea	der details.	

3.4.1. Power ON EVM


Power on the EVM in functional/QSPI-boot mode with right binary loaded (see section above) and connect it to the PC as shown above with the USB cable.






AWR2544 EVM Functional Mode Configuration

SOP0: 1; SOP1: 0; SOP2: 0




AWR294x EVM Functional Mode Configuration SOP0: 1; SOP1: 0; SOP2: 0





AWR2X44P / AWR2X44ECO / AWR2X44LC EVM Functional Mode Configuration



3.4.2. mmWave Demo Visualizer - AWR294X and AWR2x44P


Browse to the TI gallery app "mmWave Demo Visualizer" at https://dev.ti.com/gallery/view/mmwave/mmWave_Demo_Visualizer. Use HelpREADME.md from inside this app for more information on how to run/configure this app.

A Baud rate

In the visualizer, the baud rate to be selected for the Auxiliary data port is 3125000 for all devices (AWR294X and AWR2x44P).

First Time Setup	First Time Setup						
also install the rig 2. Once the demo is detect the COM p device manager of below. In the Visu	alizer App, go to the Menu->Options->Se CFG_port: Use COM port number for "XI CLI (command line interface) runs for a Data_port: Use COM port "XDS110 Clas	t detection. a USB is connected from the board t sn't work, then you will need to conf orts as shown in the section "How to rial Port and perform the settings as DS110 Class Application/User UA III the demos. ss Auxiliary Data port ": Baud: 3125 mmWave demo will be received by . Note that the default Baud for this	to the PC, the app will try to automatically igure the serial ports in this App. Run the bidentify the COM ports for mmWave EVM" shown below and click on OK. RT ": Baud: 115200. This is the port where 5000. This is the port on which binary data the PC. This is the detected object list and port is 921600, and you will separately				
		umbers on your setup maybe differe t number from your setup for followir	ent from the one shown in this panel. ng steps.				
Serial Port	steps- Click on the Baud Rate by default. Scroll down the menu a	es drop down menu for the Data port and click on "custom".	for the Data port, perform the following t, where "921600 (recommended)" is shown all devices (AWR294X and AWR2x44P).				
mn	nWave:User/Application Port (CLI CFG_port)	mmWave:Auxillary Data port (D DATA_port)	emo output				
Ports: COM1	1 (Texas Instruments Incorporated) $ m imes$	COM12 (Texas Instruments Inco	rporated) 🗸				
Baud Rates: 11520	0 (recommended) V	custom ✓					
REFRESH		ОК	CANCEL				

a. At this point, this app will automatically try to connect to the target (mmWave Sensor). DATA_port will be marked connected only after device is configured and sending out detected point cloud. If CFG_port does not connect or if the connection fails, you should try to connect to the target by clicking in the bottom left corner of this App. If that fails as well, redo the serial port configuration as shown in "First time Setup" panel above.




b. After the App is connected to the target, you can select the configuration parameters (Frequency Band, Platform, etc) in the "Setup details" and "Scene Selection" area of the CONFIGURE tab. Note that upon successful connection, you can see the following status:
 COM11:115200, COM12:3125000 Hardware Connected. AM273X

Troubleshooting tip
 In case you're unable to perform this step correctly, reconfirm the following:

 The demo image has been loaded correctly. In case of CCS development mode, you should see "Debug: CLI is operational" printed on the CCS Console.
 The Serial Ports and corresponding baud rates been set correctly.
 The two COM Ports are not being used by any other application.

 Try reconnecting or refreshing the page.

- c. Besides selecting the configuration parameters, you should select which plots you want to see. This can be done using the "check boxes" in the "Plot Selection" area. Adjust the frame rate depending on number of plots you want to see. For selecting heatmap plots, set frame rate to less than or equal to 4 fps. When selecting frame rate to be 25-30fps, for better GUI performance, select only the scatter plot and statistics plot.
- d. Once the configuration is selected, you can send the configuration to the device (use "SEND CONFIG TO MMWAVE DEVICE" button).
- e. After the configuration is sent to the device, you can switch to the PLOTS view/tab and the plots that you selected will be shown.
- f. You can switch back from "Plots" tab to "Configure" tab, reconfigure your "Scene Selection", "Object Detection" and/or "Plot Selection" values and re-send the configuration to the device to try a different profile. After a new configuration has been selected, just press the "SEND CONFIG TO MMWAVE DEVICE" button again and the device will be reconfigured. This can be done without rebooting the device. If you change the parameters in the "Setup Details", then you will need to take further action before trying the new configurations
 - i. If SDK version is changed: make sure the mmW demo running on the connected TI EVM matches the selected SDK version in the GUI
 - ii. If Antenna Config is changed: make sure the TI EVM is rebooted before sending the new configuration.
- g. Alternatively, you can load one of the example configurations (.cfg) present in the mmwave_mcuplus_sdk_<ver>\ti\demo\<platform>\mmw\profiles folder and load it through the "LOAD CONFIG FROM PC AND SEND" button on the "Plots" tab.



If board is rebooted, follow the steps starting from 1 above.

COM port after reboot

Whenever TI EVM is power-cycled (rebooted), you will need to use the bottom left serial port connection icon inside TI gallery app "mmWave Demo Visualizer" for disconnecting and reconnecting the COM ports. Note that if you used the CLI COM port directly to send the commands (instead of TI gallery app) you will have to close the CLI teraterm window and open a new one on every reboot.

Inner workings of the GUI

In the background, GUI performs the following steps:


- Creates or reads the configuration file and sends to the mmWave device using the COM port called CFG_port. It saves the information locally to be able to make sense of the incoming data that it will display. Refer to the CFG Section for details on the configuration file contents.
- Receives the data generated by the demo on the visualization/Data COM port and processes it to create various displays based on the GUI configuration in the cfg file.
 - The format of the data streamed out of the demo is documented in mmw demo's doxygen mmwave_mcuplus_sdk_<ver>\ti\demo\ <platform>\mmw\docs\doxygen\html\index.html under section: "Output information sent to host".
- On every reconfiguration, it sends a 'sensorStop' command to the device first to stop the active run of the mmWave device. Next, it sends the command 'flushCfg' to flush the old configuration before sending the new configuration. It is mandatory to flush the old configuration before sending a new configuration. Additionally, it is mandatory to send all the commands for that demo/platform even if the user desires the functionality to be disabled i.e. no commands are optional.



ſ

Advanced GUI options
 User can configure the device from their own configuration file or the saved app-generated configuration file by using the "LOAD CONFIG FROM PC AND SEND" button on the PLOTS tab. Make sure the first two commands in this config file are "sensorStop" followed by "flushCfg". User can temporarily pause the mmWave sensor by using the "STOP" button on the plots tab. The sensor can be restarted by using the "START" button. In this case, sensor starts again with the already loaded configuration and no new configuration is sent from the App. User can simultaneously plot and record the processed/detected objects data coming out of the DATA_port using the "RECORD START" button in the plots tab. Set the max limits for file size or record time as per your requirements to prevent infinite capturing of data. The saving of data can be manually stopped using the "Record Stop" button (if the max limits are not reached). User can use the "PLAYBACK START" button to playback the data and config file recorded via "RECORD START" button in the plots tab. User should make sure the data file and the config file used in this playback are the matching set. This feature can only be used when sensor device is either not connected or stopped. Once the demo has started and plots are active, user can tune the demo using the "Real Time tuning tab" or "Advanced commands" tab and then save the tuned profile using "EXPORT TUNED PROFILE" button on the PLOTS tab.
Console Messages window in Visualizer
Console message window echoes the following debug information for the users
 Every command that is sent to the TI mmWave EVM and the response back from the EVM Any runtime assert conditions detected by the demo running on TI mmWave EVM after the sensor is started. This is helpful when mmW demo is flashed onto the EVM and CCS connectivity is not available. It spits out file name and line number to allow users to browse to the source code and understand the error. Error: Incorrect config reported by target. Hint: Change configuration and try again SEND CONFIG TO MMWAVE DEVICE SAVE CONFIG TO PC RESET SELECTION
 At times, a negative error code is spit out in the error message (either in Visualizer console or in the CCS console window). To understand or decode that error, please refer to the mmWave demo doxygen ((browse via mmwave_mcuplus_sdk_<ver>\ docs\mmwave_sdk_module_documentation.html).</ver> Init time calibration status after the first sensorStart is issued post reboot for debugging boot time or start failures. This status might be different for different platforms. ImmwDemo: />sensorStart
Debug: Init Calibration Status = 0x1ffe
Done

Here is an example of plots that mmWave Demo Visualizer produces based on the config that is passed to the demo application running on mmWave sensor.







Refer to the Visualizer Readme and the User Guide for a deep dive into the demo visualizer (present in the "Help" menu).

3.4.3. Data Collection and Visualization - AWR2544

Setup the EVM as described above (Section 3.4).

If you have followed the steps correctly, and run the demo, following prompt will be visible on the Application USER UART port:

м	сом5	2 - Tera	Term VT				
File	Edit	Setup	Control	Window	Help		
				******* 05.00.01		******	
****		*****			_	********	

Issue tcpdump command before issuing sensorStart CLI to capture initial frames.

Now send the configuration. Some default configurations are provided at the below path: mmwave_mcuplus_sdk_<ver>/ti/demo/awr2544/mmw /profiles.

Data Collection:

Note: This section describes the procedure to be followed to collect the Ethernet Compressed 1D FFT data on PC (linux OS).

sudo nice -n -20 tcpdump -i <port> udp and host <SRC IP> -w output.pcap -B 1048576 -s 2048 -C 1300 -p

For example:

sudo nice -n -20 tcpdump -i enx2887ba3e6104 udp and host 192.168.0.195 -w output.pcap -B 1048576 -s 2048 -C 1300 -p

Arguments:

nice -n -20: This allows users to change the priority of the processes in a Linux system

tcpdump: It is a Linux command-line utility used to capture and inspect network traffic going to and from the system.

-i: Interface

udp and host <IP>: Filter the udp packets from the network traffic with the provided host IP.

-w: Write the raw packets to file rather than parsing and printing them out.

-B: Set the operating system capture buffer size, in units of KiB (1024 bytes). Higher buffer size significantly reduces packet drop.

-s: Snarf snap length bytes of data from each packet rather than the default of 262144 bytes. This number should be larger than the packet size.

-C: Limits the size of each file. Before writing a raw packet to a savefile, check whether the file is currently larger than file_size and, if so, close the current savefile and open a new one. Default unit: millions of bytes

-p: Don't put the interface into promiscuous mode

These arguments -w, -B, -s, -C, -p are not mandatory, but helps in reducing the packet drop.

For more details, refer tcpdump MAN page: https://www.tcpdump.org/manpages/tcpdump.1.html

Wireshark is an another tool that can be used to capture the ethernet packet on Linux and Windows OS.

Data Parsing and Validation:



For data parsing and visualization, use the python script (data_parser_awr2544.py) available at mmwave_mcuplus_sdk_<ver>/ti/demo/parser_scripts. For usage details, read the file header.

3.5. mmWave SDK OOB Demo with LVDS Based Instrumentation

In this use case, high bandwidth data (raw ADC capture) is shipped from the device to a PC over the LVDS interface (captured by the DCA1000EVM) and saved onto the filesystem. For instructions on how to run the mmWave demo with this enabled, refer to the section How to run mmWave demo with LVDS-based instrumentation. For implementation details, refer to the mmwave demo documentation (mmwave_mcuplus_sdk_<ver>/docs /mmwave_sdk_module_documentation.html).

3.6. mmWave SDK OOB Demo with Ethernet Streaming Enabled


mmWave SDK out-of-box demo offers the capability of streaming the coordinates and velocity of the detected objects over Ethernet using TCP protocol and LwIP stack. It is based on the TCPECHO example which comes as a part of the default LwIP contrib apps. For instructions on how to run the mmWave demo with Ethernet streaming enabled, refer to the section How to Run MMWAVE SDK OOB Demo with Ethernet Streaming Enabled. For implementation details, refer to the mmwave demo documentation (mmwave_mcuplus_sdk_<ver>/docs/mmwave_sdk_module_documentation. html).



3.7. Configuration (.cfg) File Format

Each line in the .cfg file describes a command with parameters. The various commands and their arguments are described in the table below (arguments are in sequence). For mmW demo, users can create their own config files from the Visualizer GUI by using the "Save Config to PC" button or starting from the few sample profiles provided in the mmwave_mcuplus_sdk_<ver>\ti\demo<platform>\mmw\profiles directory.

Most of the parameters described below are the same as the mmwavelink API specifications (see doxygen mmwave_mcuplus_sdk_<ver>\ti\control\mmwavelink\docs\doxygen\html\index.html.) Additionally, users can refer to the chirp diagram below to understand the chirp and profile related parameters or the appnote http://www.ti.com/litv/pdf/swra553



3.7.1.1.1. Figure 2: Chirp Diagram

⚠

 The CLI commands and parameters for AWR294x device (TDM and DDM) are applicable for AWR2x44P unless exclusively specified in the below table.

Configuration command	Command details	Command Parameters	Usage in mmW demo	
feDataOutputMode	The values in this command should not change between sensorStop and sensorStart. Reboot the board to try config with different set of values in this command This is a mandatory command. Channel config message to RadarSS. See mmwavelink doxygen for details.	<modetype> 1 - frame based chirps 2 - continuous chirping 3 - advanced frame config 4 - advanced chirp with legacy frame config 5 - advanced chirp with advanced frame config</modetype>	TDM: only option 1, 3, 4 and 5 are supported DDM: only option 1, 3, 4 and 5 are supported Only option 1 is valid for AWR254	
	The values in this command should not change between sensorStop and sensorStart.	<rxchannelen> Receive antenna mask e.g for 4 antennas, it is 0x1111b = 15</rxchannelen>	4 antennas supported	
	Reboot the board to try config with different set of values in this command	<txchannelen> Transmit antenna mask</txchannelen>	Refer to the antenna layout on the EVM/board to determine the right Tx antenna mask needed to enable the desired virtual antenna configuration. For example, in AWR2943 the 2 azimuth antennas can be enabled using bitmask 0x5 (i.e. tx1 and tx3). The azimuth and elevation antennas can both be enabled using bitmask 0x7 (i.e. tx1, tx2 and tx3). AWR294X: Supports 4 transmit antennas using bitmask 0xF (i.e. tx1, tx2, tx3 and tx4).	
		<cascading> SoC cascading, not applicable, set to 0</cascading>	n/a	
		<ethoscclken> 0 - Disable 1 - Enable 25MHz ethernet oscillator clock supply from the chip</ethoscclken>	Enabling OSCLKOUT and OSCLKOUTETH at the same time is not supported. Applicable for AWR2544 and AWR2X44P only	



Texas Instruments

		<drivestrength> Configures drive strength of ethernet oscillator clock out Input values: Range 0 to 15 (integers) Drive strength = input * 0.5x Examples:</drivestrength>	Applicable for AWR2544 and AWR2X44P only
		0: High impedance state 1: 0.5x 2: 1x 15: 7.5x	
adcCfg	ADC config message to RadarSS. See mmwavelink doxygen for details. The values in this command should not change between sensorStop and sensorStart. Reboot the board to try config with different set of values in this command This is a mandatory command.	<numadcbits> Number of ADC bits (0 for 12-bits, 1 for 14-bits and 2 for 16-bits) <adcoutputfmt> Output format : 0 - real 1 - complex 1x (image band filtered output)</adcoutputfmt></numadcbits>	AWR294X: only real mode is supported AWR2544: only real mode is supported.
adcbufCfg	adcBuf hardware config. The values in this command can be changed between sensorStop and sensorStart. This is a mandatory command.	2 - complex 2x (image band visible)) -subFrameIdx> subframe Index <adcoutputfmt> ADCBUF out format O-Complex,</adcoutputfmt>	For legacy mode, that field should be set to -1. For advanced frame mode, it should be set to either the intended subframe number or -1 to apply same config to all subframes. AWR294X: only real mode is supported
		Solution of the second state of the second	TDM: only option 1 is supported DDM: only option 0 is supported Only option 1 is valid for AWR2544 for both TDM and DDM only value of 1 is supported since demos use HWA for 1D FFT
profileCfg	Profile config message to RadarSS and datapath. See mmwavelink doxygen for details.	and LVDS streaming is disabled only 1 for demos that use HWA for 1D FFT	Lagoou frame (dfcQutoutMode=1):
	This is a mandatory command. txCalibEnCfg Field This CLI command doesn't expose the txCalibEnCfg field in the mmwavelink structure. User should follow the mmwavelink documentation and update the CLI profileCfg handler function accordingly. The current handler sets the value to 0 for this field (backward compatible mode)	<profileid> profile Identifier</profileid>	Legacy frame (dfeOutputMode=1): could be any allowed value but only one valid profile per config is supported Advanced frame (dfeOutputMode=3): could be any allowed value but only one profile per subframe is supported. However, different subframes can have different profiles
	Combination of numAdcSamples in profileCfg (and numRangeBins), numDopplerChirps = total number of chirps/(num TX in MIMO mode) in frameCfg or subFrameCfg, number of TX and RX antennas in channeCfg and chirpCfg determine the size of Radarcube and other internal buffers/heap in the demo. It is possible that some combinations of these values result in out of memory conditions for these heaps and demo will reject such configuration. Refer to demo and DPC doxygen to understand the data buffer layout and use the system prints on	<startfreq> "Frequency Start" in GHz (float values allowed) Examples: 77 61.38 <idletime> "Idle Time" in u-sec (float values allowed)</idletime></startfreq>	any value as per mmwavelink doxygen/device datasheet but represented in GHz. Refer to the chirp diagram shown above to understand the relation between various profile parameters and inter-dependent constraints. any value as per mmwavelink doxygen/device datasheet but
	sensorStart in CCS console window to understand the exact heap usage for a given configuration.	Examples: 7 7.15	Refer to the chirp diagram shown above to understand the relation between various profile parameters and inter-dependent constraints.



	<adcstarttime> "ADC Valid Start Time" in u-sec (float values allowed)</adcstarttime>	any value as per mmwavelink doxygen/device datasheet but represented in usec.
	Examples:	
	7	Refer to the chirp diagram shown above to understand the
	7.34	relation between various profile parameters and inter-dependent constraints.
	<rampendtime> "Ramp End Time" in u-sec (float values allowed)</rampendtime>	any value as per mmwavelink doxygen/device datasheet but represented in usec
	Examples:	
	58	Refer to the chirp diagram shown
	216.15	above to understand the relation between various profile parameters and inter-dependent constraints.
	<txoutpower> Tx output power back-off code for tx antennas</txoutpower>	only value of '0' has been tested within context of mmW demo
	<txphaseshifter> tx phase shifter for tx antennas</txphaseshifter>	only value of '0' has been tested within context of mmW demo
	<freqslopeconst> "Frequency slope" for the chirp in MHz/usec (float values allowed)</freqslopeconst>	any value greater than 0 as per mmwavelink doxygen/device datasheet but represented in MHz/usec.
	Examples:	
	68	Refer to the chirp diagram shown
	16.83	above to understand the relation between various profile parameters and inter-dependent constraints.
	StartTime> "TX Start Time" in u-sec (float values allowed)	any value as per mmwavelink doxygen/device datasheet but represented in usec.
	Examples:	
	1	Refer to the chirp diagram shown above to understand the relation
	2.92	between various profile parameters and inter-dependent constraints.
	<numadcsamples> number of ADC samples collected during *ADC Sampling Time* as shown in the chirp diagram above</numadcsamples>	any value as per mmwavelink doxygen/device datasheet.
	Examples: 256	Refer to the chirp diagram shown above to understand the relation between various profile parameters
	224	and inter-dependent constraints.
	<digoutsamplerate> ADC sampling frequency in ksps.</digoutsamplerate>	any value as per mmwavelink doxygen/device datasheet.
	(<numadcsamples> / <digoutsamplerate> = "ADC Sampling Time")</digoutsamplerate></numadcsamples>	
	Examples: 5500	Refer to the chirp diagram shown above to understand the relation between various profile parameters and inter-dependent constraints.
	<pre><hptcornerfreq1> HPF1 (High Pass Filter 1) corner frequency 0: 175 KHz 1: 235 KHz 2: 350 KHz 3: 700 KHz</hptcornerfreq1></pre>	any value as per mmwavelink doxygen/device datasheet
	chronic Harden Strengther Stre	any value as per mmwavelink doxygen/device datasheet
	1: 700 KHz 2: 1.4 MHz 3: 2.8 MHz	Note: for AWR294X/AWR2544, <hpfcornerfreq2> and <hpfcornerfreq1> should have the same value. Different values cannot be used.</hpfcornerfreq1></hpfcornerfreq2>
	<rxgain> Bit 5:0 RX_GAIN</rxgain>	any value as per mmwavelink doxygen/device datasheet
	Bit 7:6 RF_GAIN_TARGET OR'ed value of RX gain in dB and RF gain target (See mmwavelink doxygen for	
	details)	
Chirp config message to RadarSS and datapath. See mmwavelink doxygen for details.		
The values in this command can be changed between sensorStop and sensorStart.	chirp start index	any value as per mmwavelink doxygen
This is a mandatory command when dfeOutputMode is set to 1 or 3.	chirp end index	any value as per mmwavelink doxygen
	profile identifier	should match the profileCfg- >profileId



chirpCfg

		start frequency variation in Hz (float values allowed)	only value of '0' ha within context of m	
		frequency slope variation in kHz/us (float values allowed)	only value of '0' ha within context of m	
		idle time variation in u-sec (float values allowed)	only value of '0' ha within context of m	
		ADC start time variation in u-sec (float values allowed)	only value of '0' ha	
		tx antenna enable mask (Tx2,Tx1) e.g (10)b = Tx2 enabled, Tx1 disabled.	See note under "c command above.	
		(10)u – TAZ eliableu, TAT usableu.	TDM: Individual ch either only one distinct T enabled (MIMO) o antennas should b chirps	x antenna r same TX
			DDM: All transmitt for the same chirp	
ChirpCfg	advance chirp config message to RadarSS and datapath. See mmwavelink doxygen and mmWave-Radar-Interface-Control document in the mmwave_dfp_ <vers details.="" docs="" for="" in<br="" the="" values="">this command can be changed between sensorStop and sensorStart.</vers>	<chirpparamidx> Chirp Parameter Index</chirpparamidx>	This value indicate for which the CLI	
	This is a mandatory command when dfeOutputMode is set to 4 or 5.	0: Profile ID	Valid value 0-10.	
	 All the field in this CLI command are specific to selected Chirp Parameter Index in this command. This command needs to be issued 11 times (AWR2943 /AWR2944) for each of the chirp parameters defined in <chirpparamldx> field in a sequential order.</chirpparamldx> 	1: Frequency Start Variation 2: Frequency Slope Variation 3: Idle Time Variation 4: ADC Start Time Variation 5: TX Antenna Enable Mask 6: BPM Enable Mask 7: TX0 Phase Shifter		
	ChirpParamox> leid in a sequential order. The final value of a chirp parameter is sum of profile data, accumulated delta dither (which increments every N chirps) and LUT dither.	8: TX1 Phase Shifter 9: TX2 Phase Shifter 10: TX3 Phase Shifter (for AWR294X only)		
	 The Delta Dither is optional and can be disabled by setting <deltaparamupdateperiod>= 0 and <sfnchirpparamdelta>= 0.</sfnchirpparamdelta></deltaparamupdateperiod> 	<resetmode> Global Reset Mode</resetmode>	This global reset v for all the chirp pa	rameters.
	 The LUT Dither is mandatory and at least one dither parameter value (it can be value zero) shall be programmed for all chirp parameters in LUT, same dither value can be 	0: Reset at End of Frame 1: Reset at End of Sub-Frame 2: Reset at End of Burst	It indicates when t (Delta Dither) or th resets back to its i	ne LUT dither patt
	 In the second sec	<deltaresetperiod> Delta Reset Period (M)</deltaresetperiod>	This value resets the delta increme (delta dither) sequence every M chi	
		0: Reset only as per <resetmode> option. 1: Delta increment is disabled. 2-32768: Reset every M chirps in addition to <resetmode> option.</resetmode></resetmode>	Reset period (M) should be an integ multiple of <deltaparamupdateperio< td=""></deltaparamupdateperio<>	
	 chirpStartIdx> and <chirpendidx> in frameCfg CLI command are not applicable.</chirpendidx> 	<pre><deltaparamupdateperiod></deltaparamupdateperiod></pre>	The chirp paramet	ter will be increme
	 cchirpStartIdx> and <numofchirps> in subFrameCfg CLI command are not applicable.</numofchirps> 	Delta Parameter Update Period (N)	by <sfnchirppara after every N chirp</sfnchirppara 	mDelta> (delta di
	 <numloops> field in frameCfg and subFrameCfg CLI command defines the total number of chirps in a frame or subframe respectively.</numloops> 	0: Delta increment is disabled 1-16384: The fixed delta value will be incremented once after every N chirps.		
		<sf0chirpparamdelta> Delta dither for Sub-frame 0</sf0chirpparamdelta>	This field indicates (Delta Dither) valu accumulated and	e that should be added to each ch
	Dithering of all parameters is supported as part of front-end configuration; however, OOB demo supports only the normal (legacy chirp) signal processing chain. Hence, significant dither in the chirp parameters can lead to undesired signal	Also applicable to frame in legacy frame dfeDataOutputMode (4).	based on update p	
		<sf1chirpparamdelta> Delta dither for Sub-frame 1 Not applicable in legacy frame dfeDataOutputMode (4).</sf1chirpparamdelta>	for certain chirp parameters. Any v as per mmwavelink doxygen/devic datasheet (float values allowed) ca programmed in the units mentione	
	processing results.	<sf2chirpparamdelta></sf2chirpparamdelta>	below.	e units mentioned
		Delta dither for Sub-frame 2	Parameter	Dither Unit
	This command is valid for AWR294X devices.	Not applicable in legacy frame dfeDataOutputMode (4). <sf3chirpparamdelta></sf3chirpparamdelta>	Start Frequency	Hz
		Delta dither for Sub-frame 3	Frequency Slope	KHz/us
		Not applicable in legacy frame dfeDataOutputMode (4).	Idle Time	u-sec
			ADC Start Time	u-sec
		hi Deset Desired	TX_N Phase Shift	-
		<lutresetperiod> LUT Reset Period (J)</lutresetperiod>	This value resets (LUT dither) every	J chirps.
		0: Reset only as per <resetmode> option. 1: Fixed 0th index LUT value programmed for all chirps. 2-32768: Reset every J chirps in addition to <resetmode> option.</resetmode></resetmode>	Reset period (J) s multiple of <lutpar< td=""><td></td></lutpar<>	
		<lutparamupdateperiod> LUT Parameter Update Period (K)</lutparamupdateperiod>	The chirp paramet with new LUT value	
		0: Fixed 0 th index LUT value programmed for all chirps. 1-16384: Index to LUT will be incremented once after every K chirps and corresponding LUT value is used.		

⚠



		LUT Pattern Address Offset LUT Pattern Address Offsets should be configured properly for each chirp parameter so that unique LUT values do not get overwritten with other parameter values. <numofpatterns> Number of unique LUT Patterns. <lutsfindexoffset> LUT Sub-frame Index Offset Valid in advanced frame configuration (dfeDataOutputMode 5) only. Valid Range: 0 to P 0: No offset (default) 1 to P: LUT index start offset for each sub-frame.</lutsfindexoffset></numofpatterns>					Address offset has to be multiple of 4 bytes (word boundary). This field provides the start address offset within the Chirp Parameter LUT. The first chirp of the sub-frame/frame picks the dither from Oth index to LUT with this address offset. This field provides the number of unique dither parameters present in LUT (LUT Dither). This value should always be greater than or equal to 1. The chirp LUT start index for first burst in each sub-frame is equal to the <lutpatternaddressoffset> <lutpatternaddressoffset> <lutpatternaddressoffset> thelps to loops et of different chirps in subsequent sub-frame in advance frame is always indexing to 0th parameter in LUT. NOTE2: The <lutresetperiod> cannot be more than number of chirps in a sub- frame if this feature is used.</lutresetperiod></lutpatternaddressoffset></lutpatternaddressoffset></lutpatternaddressoffset>		
		<lutchirpparam LUT Chirp Para Default Value: 0</lutchirpparam 	ameter Size	ameter size)					
		Parameter Start Frequency Idle Time	Value 0 4 bytes 2 bytes	Value 1 2 bytes 1 byte	Value 2 1 byte		parameters, i.e, St Time, and ADC Sta	art Frequency, Idle	
		ADC Start Time 2 bytes 1 byte - 					This field is used to reduce the size of the parameter in LUT if granularity of the resolution can be increased. Applicable only for certain chirp parameters, i.e, Start Frequency, Idle Time, and ADC Start Time.		
		<maxtxphshift Maximum TX P</maxtxphshift 		Internal Dithe	r		Only value of '0' has been tested within context of mmW demo.		
LUTDataCfg	LUT Data config message to RadarSS and datapath. See mmwavelink doxygen and mmWave-Radar-Interface-Control document in the mmwave_dfp_ <ver>/docs for details. The values in this command can be changed between sensorStop and sensorStart.</ver>	<lutdata_{0}><lutdata_{numofpatterns-1}> LUT Dither Patterns</lutdata_{numofpatterns-1}></lutdata_{0}>				This value indicates the chirp parameter for which the CLI command is issued.			
	This is a mandatory command when dfeOutputMode is set to 4 or 5. All the field in this CLI command are specific to selected Chirp Parameter Index in this command. 					Any value as per mmwavelink doxygen/device datasheet (float values allowed) in the units as defined below.			
	 This command needs to be issued 11 times (AWR2943 /AWR2944) for each of the chirp parameters defined in <chirpparamidx> field in a sequential order.</chirpparamidx> 						Parameter	LUT Data Unit	
							Profile ID	No unit	
	 This command stores the programmed patterns of a chirp parameter in the LUT at the <lutpatternaddressoffset></lutpatternaddressoffset> 						Start Frequency	Hz	
	configured in advChirpCfg CLI command.						Frequency Slope	KHz/us	
	 In CCS development mode, the programmed LUT data is stored in a text file AdvChirpLUTData.txt for verification. 						ADC Start Time	u-sec	
	This command is valid for AWR294X devices.						TX Enable Mask	No unit	
							BPM Enable Mask	No unit	
							TX_N Phase Shift	degree	
								·	
lowPower	Low Power mode config message to RadarSS. See mmwavelink								
	doxygen for details.	<don't_care></don't_care>					set to 0		
	The values in this command should not change between sensorStop and sensorStart. Reboot the board to try config with different set of values in this command. This is a mandatory command.	ADC Mode 0x00 : Regular ADC mode 0x01 : Low power ADC mode					use value of '0' or '1' (depending on profileCfg->digOutSampleRate)		
frameCfg	frame config message to RadarSS and datapath. See mmwavelink doxygen for details.	ahim -t1 1	(0.514)				anuscius :		
	dfeOutputMode should be set to 1 to use this command The values in this command can be changed between sensorStop	chirp start index Not applicable 5) configuration	in advanced	Chirp (dfeDat	aOutputMode	e 4 or	any value as per mmwavelink doxygen but corresponding chirpCfg should be defined		
	and sensorStart.								



1			
	This is a mandatory command when dfeOutputMode is set to 1 or 4.	chirp end index (chirp start index-511) Not applicable in advanced Chirp (dfeDataOutputMode 4 or 5) configuration.	any value as per mmwavelink doxygen but corresponding chirpCfg should be defined
		number of loops: In Legacy Chirp (dfeDataOutputMode: 1 or 3): No. of times to loop through the unique chirps (1 to 255).	any value as per mmwavelink doxygen/device datasheet but greater than or equal to 4.
		In Advanced Chirp (dfeDataOutputMode 4 or 5): Total number of chirps in a subframe.	Note: If value of 2 is desired for number of Doppler Chirps, one must update the demo/object detection DPC source code to use rectangular window for Doppler DPU instead of Hanning window.
		number of frames (valid range is 0 to 65535, 0 means infinite)	any value as per mmwavelink doxygen
		numAdcSamples	any value as per mmwavelink doxygen/device datasheet.
		number of ADC samples collected during "ADC Sampling Time" as shown in the	
		chirp diagram above Examples: 256	Refer to the chirp diagram shown above to understand the relation between various profile parameters and inter-dependent constraints.
		224	
		frame periodicity in ms (float values allowed)	any value as per mmwavelink doxygen and represented in msec. However frame should not have more than 50% duty cycle (i.e. active chirp time should be <= 50% of frame period). Also it should allow enough time for selected UART output to be shipped out (selections based on guiMonitor command) else demo will assert if the next frame start trigger is receive from the front end and current frame is still ongoing. User can use the output of stats TLV to tune this parameter.
		trigger select 1: Software trigger	only option for Software trigger is supported
		2: Hardware trigger. 3: CPTS based trigger	AWR2544: CPTS based trigger is also supported.
		Frame trigger delay in ms (float values allowed)	any value as per mmwavelink doxygen and represented in msec.
aduEramaCfa	Advanced config message to BoderSS and detects See		
advFrameCfg	Advanced config message to RadarSS and datapath. See mmwavelink doxygen for details. The dfeOutputMode should be set to 3 to use this command.	<numofsubframes> Number of sub frames enabled in this frame</numofsubframes>	any value as per mmwavelink doxygen
	The values in this command can be changed between sensorStop and sensorStart.	<forceprofile> Force profile</forceprofile>	only value of 0 is supported
	This is a mandatory command when dfeOutputMode is set to 3 or 5.	<pre><numframes> Number of frames to transmit (1 frame = all enabled sub frames)</numframes></pre>	any value as per mmwavelink doxygen
	This command is valid for AWR294X devices.	<pre></pre> <triggerselect> trigger select 1: Software trigger 2: Hardware trigger.</triggerselect>	only option for Software trigger is supported
		<frametrigdelay> Frame trigger delay in ms (float values allowed)</frametrigdelay>	any value as per mmwavelink doxygen and represented in msec.
		<numofsubframes> Number of sub frames for sequence configuration</numofsubframes>	should be kept the same as the first argument
aub From o Ofe	Cubinama applia magaza la DadarCC and datapath. Cas		
subFrameCfg	Subframe config message to RadarSS and datapath. See mmwavelink doxygen for details.	<subframenum> subframe Number for which this command is being given</subframenum>	value of 0 to RL_MAX_SUBFRAMES- 1
	The dfeOutputMode should be set to 3 to use this command. The values in this command can be changed between sensorStop	subtrame Number for which this command is being given <forceprofileidx> Force profile index</forceprofileidx>	ignored as <forceprofile> in advFrameCfg should be set to 0</forceprofile>
	and sensorStart.	<pre>cchirpStartIdx> Start Index of Chirp</pre>	advFrameCrg should be set to 0 any value as per mmwavelink doxygen but corresponding chirpCfg
	This is a mandatory command when dfeOutputMode is set to 3 or 5. This command is valid for AWR294X devices.	Not applicable in advanced Chirp (dfeDataOutputMode 4 or 5) configuration.	should be defined
		 <numofchirps></numofchirps> Num of unique Chirps per burst including start index. 	any value as per mmwavelink doxygen but corresponding number of chirpCfg
		Not applicable in advanced Chirp (dfeDataOutputMode 4 or 5) configuration.	should be defined
		5) configuration. <numloops></numloops>	any value as per mmwavelink doxygen but greater than or equal to
		In Legacy Chirp (dfeDataOutputMode: 1 or 3): No. of times to loop through the unique chirps.	4 <u>Note</u> : If value of 2 is desired for number of Doppler Chirps, one
		In Advanced Chirp (dfeDataOutputMode 4 or 5): Total number of chirps in a subframe.	must update the demo/object detection DPC source code to use rectangular window for Doppler DPU instead of Hanning window.



🤴 Texas Instruments

		-burstBoriodicity	
		<burstperiodicity> Burst periodicity in msec (float values allowed) and meets the criteria burstPeriodicity >= ((numLoops)* (Sum total of time duration of all unique chirps in that burst)) + InterBurstBlankTime</burstperiodicity>	any value as per mmwavelink doxygen and represented in msec but subframe should not have more than 50% duty cycle and allow enough time for selected UART output to be shipped out (selections based on guiMonitor command)
		<chirpstartldxoffset> Chirp Start address increment for next burst</chirpstartldxoffset>	set it to 0 since demo supports only one burst per subframe
		<numofburst> Num of bursts in the subframe</numofburst>	set it to 1 since demo supports only one burst per subframe
		<numofburstloops> Number of times to loop over the set of above defined bursts, in the sub frame</numofburstloops>	set it to 1 since demo supports only one burst per subframe
		<subframeperiodicity> subFrame periodicity in msec (float values allowed) and meets the criteria subFramePeriodicity >= Sum total time of all bursts + InterSubFrameBlankTime</subframeperiodicity>	set to same as <burstperiodicity> since demo supports only one burst per subframe</burstperiodicity>
guiMonitor	Plot config message to datapath. The values in this command can be changed between sensorStop and sensorStart.	All parameters below are flags (1 to enable and 0 to disable)	
	This is a mandatory command. This command is valid for AWR294X devices.	<subframeidx> subframe Index</subframeidx>	For legacy mode, that field should be set to -1 whereas for advanced frame mode, it should be set to either the intended subframe number or -1 to apply same config to all subframes.
		<detected objects=""> 1 - enable export of point cloud (x,y,z,doppler) and point cloud sideinfo (SNR, noiseval)</detected>	all values supported
		2 - enable export of point cloud (x,y,z,doppler)	
		0 - disable <log magnitude="" range=""> 1 - enable export of log magnitude range profile at zero Doppler 0 - disable 0 - disable</log>	all values supported
		<noise profile=""> 1 - enable export of log magnitude noise profile 0 - disable</noise>	TDM: all values supported DDM: must be 0
		<rangeazimuthheatmap> or <rangeazimuthelevationheatmap> range-azimuth or range-azimuth- elevation heat map related information</rangeazimuthelevationheatmap></rangeazimuthheatmap>	TDM: all values supported DDM: must be 0
		<rangeazimuthheatmap></rangeazimuthheatmap>	
		This output is provided only in demos that use AoA (legacy) DPU for AoA processing 1 - enable export of zero Doppler radar cube matrix, all range bins, all azimuth	
		virtual antennas to calculate and display azimuth heat map.	
		(The GUI computes the FFT of this to show heat map)	
		0 - disable	
		< rangeAzimuthElevationHeatMap >	
		This output is provided in demos that use AoA 2D DPU for AoA processing 1 - enable export of zero Doppler radar	
		artennas export of zero Doppler ladar cube matrix, all range bins, all virtual antennas to calculate and display azimuth heat map.	
		(The GUI remaps the antenna symbols and computes the FFT of this stream to show azimuth heat map only).	
		0 - disable	
		<rangedopplerheatmap> range-doppler heat map 1 - enable export of the whole detection matrix. Note that the frame period should be adjusted according to UART transfer time. 0 - disable</rangedopplerheatmap>	all values supported
		<statsinfo> statistics (CPU load, margins, device temperature readings, etc) 1 - enable export of stats data. 0 - disable</statsinfo>	all values supported



🦊 Texas Instruments

aoaFovCfg	Command for datapath to filter out detected points outside the specified range in azimuth or elevation plane		Specific to TDM.
	This is a mandatory command. This command is valid for AWR294X devices.	<subframeidx></subframeidx>	For legacy mode, that field should be set to -1 whereas for advanced frame mode, it should be set to either the intended subframe number or -1 to apply same config to all subframes.
		<minazimuthdeg></minazimuthdeg>	minimum azimuth angle (in degrees) that specifies the start of field of view
		<maxazimuthdeg></maxazimuthdeg>	maximum azimuth angle (in degrees) that specifies the end of field of view
		<minelevationdeg></minelevationdeg>	minimum elevation angle (in degrees) that specifies the start of field of view
		<maxelevationdeg></maxelevationdeg>	maximum elevation angle (in degrees) that specifies the end of field of view
forCfa	CEAD config manages to datapath		Specific to TDM For DDM shock
farCfg	CFAR config message to datapath.		Specific to TDM. For DDM, check cfarCfg (DDM)
TDM)	This is a mandatory command. This command is valid for AWR294X devices.	<subframeldx> subframe Index</subframeldx>	For legacy mode, that field should be set to -1 whereas for advanced frame mode, it should be set to either the intended subframe number or -1 to apply same config to all subframes.
		<pre><procdirection> Processing direction: 0 - CFAR detection in range direction 1 - CFAR detection in Doppler direction</procdirection></pre>	all values supported; 2 separate commands need to be sent; one for Range and other for doppler.
		<mode> CFAR averaging mode: 0 - CFAR_CA (Cell Averaging) 1 - CFAR_CAGO (Cell Averaging Greatest Of) 2 - CFAR_CASO (Cell Averaging Smallest Of)</mode>	all values supported
		<noisewin> noise averaging window length: Length of the one-sided noise averaged cells in samples Make sure 2*(noiseWIn+guardLen)</noisewin>	supported
		<pre><numrangebins and<br="" direction="" for="" range="">2*(noiseWIn+guardLen) <numdopplerbins direction.<="" doppler="" for="" pre=""></numdopplerbins></numrangebins></pre>	
		<guardlen> one-sided guard length in samples Make sure 2°(noiseWIn+guardLen) <numrangebins and<br="" direction="" for="" range="">2°(noiseWIn+guardLen)</numrangebins></guardlen>	supported
		<numdopplerbins direction.<br="" doppler="" for=""><divshift> Cumulative noise sum divisor expressed as a shift.</divshift></numdopplerbins>	CFAR_CA: <divshift> = ceil(log₂(2 x <noisewin>))</noisewin></divshift>
		Sum of noise samples is divided by 2^ <divshift>. Based on <mode> and <noisewin>, this value should be set as shown inn ext columns.</noisewin></mode></divshift>	CFAR_CAGO/_CASO: <divshift> = ceil(log₂(<noisewin>)) In profile_2d.cfg, value of 3 means that the noise sum is</noisewin></divshift>
		The value to be used here should match the "CFAR averaging mode" and the "noise averaging window length" that is selected above.	divided by 2/3-8 to get the average of noise samples with window length of 8 samples in CFAR -CASO mode.
		The actual value that is used for division $(2^{\circ}x)$ is a power of 2, even though the "noise averaging window length" samples may not have that restriction.	
		cyclic mode or Wrapped around mode. 0- Disabled 1- Enabled	supported
		Threshold scale in dB using float representation. This is used in conjunction with the noise sum divisor (say x). the CUT comparison for log input is:	Detection threshold is specified in dB scale. Maximum value allowed is 100dB
		CUT > (Threshold scale converted from dB to Q8) + (noise sum / $2^{n}x$)	
		For example:	
		10.75	
		peak grouping	supported
		0 - disabled	



🐌 Texas Instruments

nultiObjBeamForming (TDM)	Multi Object Beamforming config message to datapath.		Specific to TDM.
		<subframeldx></subframeldx>	For legacy mode, that field should
	This feature allows radar to separate reflections from multiple objects originating from the same range/Doppler detection. The procedure searches for the second peak after locating the highest peak in Azimuth FFT. If the second peak is greater than the specified threshold, the second object with the same range/Doppler	subframe Index	be set to -1 whereas for advanced frame mode, it should be set to either the intended subframe number or -1 to apply same config to all subframes.
	is appended to the list of detected objects. The threshold is proportional to the height of the highest peak.	<pre><feature enabled=""> 0 - disabled 1 - enabled</feature></pre>	supported
	This is a mandatory command. This command is valid for AWR294X devices.	cthreshold> 0 to 1 – threshold scale for the second peak detection in azimuth FFT output. Detection threshold is equal to <thresholdscale> multiplied by the first peak height. Note that FFT output is magnitude squared.</thresholdscale>	supported
alibDcRangeSig	DC range calibration config message to datapath.		Specific to TDM.
TDM)	Antenna coupling signature dominates the range bins close to the radar. These are the bins in the range FFT output located around DC. When this feature is enabled, the signature is estimated during the first N chirps, and then it is subtracted during the subsequent chirps.	<subframeldx> subframe index</subframeldx>	For legacy mode, that field should be set to -1 whereas for advanced frame mode, it should be set to either the intended subframe number or -1 to apply same config to all subframes.
	During the estimation period the specified bins (defined as [negativeBinldx, positiveBinldx]) around DC are accumulated and averaged. It is assumed that no objects are present in the vicinity of the radar at that time.	<enabled> Enable DC removal using first few chirps 0 - disabled 1 - enabled</enabled>	supported
	This procedure is initiated by the following CLI command, and it can be initiated any time while radar is running. Note that the maximum number of compensated bins is 32.	<negativebinidx> negative Bin Index (to remove DC from farthest range bins)</negativebinidx>	supported
	This is a mandatory command. This command is valid for AWR294X devices.	Maximum negative range FFT index to be included for compensation. Negative indices are indices wrapped around from far end of 1D FFT.	
		Ex: Value of -5 means last 5 bins starting from the farthest bin	
		<pre><pre>cpositiveBinIdx> positive Bin Index (to remove DC from closest range bins) Maximum positive range FFT index to be included for compensation</pre></pre>	supported
		Value of 8 means first 9 bins (including bin#0)	
		cnumAvg> number of chirps to average to collect DC signature (which will then be applied to all chirps beyond this).	The value must be power of 2, and must be greater than the number of Doppler bins.
		Value of 256 means first 256 chirps (after command is issued and feature is enabled) will be used for collecting (averaging) DC signature in the bins specified above. From 257th chirp, the collected DC signature will be removed from every chirp.	
lutterRemoval	Static clutter removal config message to datapath.		Specific to TDM.
TDM)	Static clutter removal algorithm implemented by subtracting from the samples the mean value of the input samples to the 2D-FFT This is a mandatory command.	<subframeidx> subframe Index</subframeidx>	For legacy mode, that field should be set to -1 whereas for advanced frame mode, it should be set to either the intended subframe number or -1 to apply sameconfig to all subframes.
	This command is valid for AWR294X devices.	<enabled> Enable static clutter removal technique 0 - disabled 1 - enabled</enabled>	supported
farFovCfg	Command for datapath to filter out detected points outside the		Specific to TDM.
-	specified limits in the range direction or doppler direction	<subframeldx></subframeldx>	For legacy mode, that field should
TDM)	This is a mandatory command. This command is valid for AWR294X devices.	subframe Index	for regardy mode, that here should be set to -1 whereas for advanced frame mode, it should be set to either the intended subframe number or -1 to apply same config to all subframes.
		<pre><pre>cprocDirection> Processing direction: 0 – point filtering in range direction 1 – point filtering in Doppler direction</pre></pre>	both values supported but this command should be given twice - one for range direction and other for doppler direction
		<min (meters="" m="" or="" s)=""> the units depend on the value for <procdirection> field above.</procdirection></min>	minimum limits for the range or doppler below which the detected points are filtered out
		meters for Range direction and meters/sec for Doppler direction	



		<max (meters="" m="" or="" s)=""></max>	maximum limits for the range or doppler above which the detected
		the units depend on the value for <pre>cprocDirection> field above.</pre>	points are filtered out
		meters for Range direction and meters/sec for Doppler direction	
compRangeBias	Command for datapath to compensate for bias in the		Specific to TDM.
AndRxChanPhase (TDM)	range estimation and receive channel gain and phase imperfections.	<rangebias> Compensation for range estimation bias in meters</rangebias>	supported
	Refer to the procedure mentioned here The values in this command can be changed between	<re(0,0)> <im(0,0)> <re(0,1)> <im(0,1)> <re(0,r-1)> <im(0,r-1)></im(0,r-1)></re(0,r-1)></im(0,1)></re(0,1)></im(0,0)></re(0,0)>	For AWR2944 demo: 16 pairs of values
	sensorStop and sensorStart and even when the sensor is running.	<re(1,0)> <im(1,0)> <re(t-1,r-1)> <im(t-1,r-1)></im(t-1,r-1)></re(t-1,r-1)></im(1,0)></re(1,0)>	should be provided here since the device has 4 Rx and 4 Tx (total of 16 virtual antennas).
	This is a mandatory command. This command is valid for AWR294X devices.	Set of Complex value representing compensation for virtual Rx channel phase bias in Q15 format. Pairs of I and Q should be provided for all Tx and Rx antennas in the device	
measureRangeBias	Command for datapath to enable the measurement		
AndRxChanPhase	of the range bias and receive channel gain and phase imperfections. Refer to the procedure mentioned here Range bias measurement is only for TDM.	<enabled> 1 - enable measurement. This parameter should be enabled only using profile calibration. 0 - disable measurement. This should be</enabled>	supported
	This is a mandatory command for both TDM and DDM.	the value to use for all other profiles. <targetdistance></targetdistance>	supported
	This command is valid for AWR294X devices.	distance in meters where strong reflector is located to be used as test object for measurement. This field is only used when measurement mode is enabled.	Supporteu
		<searchwin> distance in meters of the search window around <targetdistance> where the peak will be searched</targetdistance></searchwin>	supported
extendedMax	Velocity disambiguation config message to datapath.		Specific to TDM.
Velocity (TDM)	A simple technique for velocity disambiguation is implemented. It corrects target velocities up to (2*vmax). The output of this feature may not be reliable when two or more objects are present in the same range bin and are too close in azimuth plane. This is a mandatory command.	<subframeldx> subframe index</subframeldx>	For legacy mode, that field should be set to -1 whereas for advanced frame mode, it should be set to either the intended subframe number or -1 to apply same config to all subframes.
	This command is valid for AWR294X devices.	<enabled> Enable velocity disambiguation technique 0 - disabled 1 - enabled</enabled>	supported.
CQRxSatMonitor	Rx Saturation Monitoring config message for Chirp quality to RadarSS and datapath. See mmwavelink doxygen for details on rlRxSatMonConf_t.	<profile> Valid profile Id for this monitoring configuration. This profile ID should have a matching profileCfg.</profile>	not presently supported
	The enable/disable for this command is controlled via the	<satmonsel> RX Saturation monitoring mode</satmonsel>	
	"analogMonitor" CLI command. The values in this command can be changed between sensorStop	<prisliceduration> Duration of each slice, 1LSB=0.16us, range: 4 -number of ADC samples</prisliceduration>	
	and sensorStart.	<numslices> primary + secondary slices, range 1-127. Maximum primary slice is 64.</numslices>	
		crxChanMask> RX channel mask, 1 - Mask, 0 - unmask	-
CQSigImgMonitor	Signal and image band energy Monitoring config message for Chirp quality to RadarSS and datapath. See mmwavelink doxygen for details on rlSigImgMonConf_t.	<profile> Valid profile Id for this monitoring configuration. This profile ID should have a matching profileCfg</profile>	not presently supported
	The enable/disable for this command is controlled via the "analogMonitor" CLI command. The values in this command can be changed between sensorStop	<numslices> primary + secondary slices, range 1-127. Maximum primary slice is 64.</numslices>	
	and sensorStart.	<numsampleperslice> Possible range is 4 to 'number of ADC samples' in the corresponding profileCfg. It must be an even number.</numsampleperslice>	
analogMonitor	Controls the enable/disable of the various monitoring features	<rxsaturation></rxsaturation>	not presently supported
	supported in the demos. The values in this command can be changed between sensorStop	CQRxSatMonitor enable/disable	
	and sensorStart.	0: disable <siglmgband> CQSiglmgMonitor enable/disable 1:enable</siglmgband>	_



🐌 Texas Instruments

		<aplildoscmonen> APLL LDO Short Circuit Monitor enable/disable 1: Enable 0: Disable</aplildoscmonen>	Supported for AWR2544 Testing procedure: Connect one end o a wire at 1V4 APLL point (C103 on EVM). When the other end is in contac with ground, ESM error occurs and the nError LED glows.
vdsStreamCfg	Enables the streaming of various data streams over LVDS lanes. When this feature is enabled, make sure chirp Threshold in adcbufCfg is set to 1. The values in this command can be changed between sensorStop and sensorStart.	<subframeidx> subframe Index</subframeidx>	For legacy mode, that field should be set to -1 whereas for advanced frame mode, it should be set to either the intended subframe number or -1 to apply same config to all subframes.
		<pre><enableheader> 0 - Disable HSI header for all active</enableheader></pre>	Only 0 is supported.
	This command is valid for AWR294X and AWR2544 devices.	streams 1 - Enable HSI header for all active	
		streams cdataFmt> Controls HW streaming. Specifies the HW streaming data format. 0-HW STREAMING DISABLED 1-ADC 4-CP_ADC_CQ	When choosing CP_ADC_CQ, please ensure that CQRxSatMonitor and CQSigImgMonitor commands are provided with appropriate values and these monitors are enabled using analogMonitor command.
		<enablesw> 0 - Disable user data (SW session) 1 - Enable user data (SW session)</enablesw>	Only ADC format is currently supported.
		<enableheader> should be set to 1 when this field is enabled.</enableheader>	
alibdata	Boot time RF calibration save/restore command. Provides user to either save the boot time RF calibration performed by the RadarSS onto the FLASH or to restore the previously saved RF calibration data from the FLASH and instruct RadarSS to not re-perform the boot-time calibration. User can either save or restore or perform neither operations. User is not allowed to simultaneous save and restore in a given boot sequence. Boot time phase shift calibration data is also saved along with all other calibration data. The values in this command should not change between sensorStop and sensorStart.	<save enable=""> 1 - Save enabled. Application will boot -up normally and configure the RadarSS to perform all applicable boot calibrations during mmWave_open. Once the calibrations are performed, application will retrieve the calibration data from RadarSS and save it to FLASH. User need to specify valid <flash offsets<br="">value. <restore enable=""> option should be set to 0.</restore></flash></save>	supported
	Reboot the board to try config with different set of values in this	0 - Save disabled.	
		1 - Restore enabled. Application will check the FLASH for a valid calibration data section. If present, it will restore the data from FLASH and provide it to RadarSS while configuring it to skip any real-time boot calibrations and use provided calibration data. User need to specify valid -flash offset> value which was used during saving of calibration data. <save enable=""> option should be set to 0.</save>	
		0 - Restore disabled. <flash offset=""></flash>	supported
		Address offset in the flash to be used while saving or restoring calibration data. Make sure the address doesn't overlap the location in FLASH where application images are stored and has enough space for saving rlCalibrationData_t and rlPhShiftCalibrationData_t	To be specified as a hexadecimal number with the prefix "0x" (Ex. 0x1f0000)
		This field is don't care if both save and restore are disabled	
enetStreamCfg	Ethernet streaming configuration command		Specific to TDM.
TDM)		<isenable></isenable>	supported
	This is a mandatory command if mmwDemoEnet is used.	0 - Ethernet streaming of detected object data is enabled	
	This command is valid for AWR294X devices.	1 - Ethernet streaming of detected object data is disabled	oupported
		<remotelpd> <remotelpc> <remotelpb> <remotelpa> If the IP Address obtained by the PC is D.B.C.A, the arguments to send would be D B C A.</remotelpa></remotelpb></remotelpc></remotelpd>	supported
sensorStart	sensor Start command to RadarSS and datapath.		
is nou o la l	sensor Start command to RadarSS and datapath. Starts the sensor. This function triggers the transmission of the frames as per the frame and chirp configuration. By default, this function also sends the configuration to the mmWave Front End and the processing chain. This is a mandatory command.		



Page 30 of 90

sensorStop	sensor Stop command to RadarSS and datapath. Stops the sensor. If the sensor is running, it will stop the mmWave Front End and the processing chain. After the command is acknowledged, a new config can be provided and sensor can be restarted or sensor can be restarted without a new config (i.e. using old config). See 'sensorStart' command. This is mandatory before any reconfiguration is performed post sensorStart.	Optionally, user can provide an argument 'doReconfig' 0 - Skip reconfiguration and just start the sensor using already provided configuration. <any other="" value=""> - not supported</any>	supported For AWR2x44P sensor reconfiguration is not possible. Issue only sensorStart 0 after sensorStop to re-start the sensor. Sending the entire config file is not supported supported
flushCfg	This command should be issued after 'sensorStop' command to flush the old configuration and provide a new one. This is mandatory before any reconfiguration is performed post sensorStart.		
configDataPort	This is an optional command to change the baud rate of the DATA_port. This command will be accepted only when sensor is in init state or stopped state i.e. between sensorStop and sensorStart. It is recommended to use this command outside of the CFG file so that PC tools can also be configured to accept data at the desired baud rate. This command is valid for AWR294X devices.	 <baudrate> The new baud rate for the DATA_port. Recommended value: 3125000. <ackping> 0 - Do not send any bytes on data port 1- Send 16 bytes of value '0xFF' to ack/sync over the DATA_port (binary) after change to baud rate is applied.</ackping></baudrate>	supported supported
queryDemoStatus	This is an optional command that can be issued anytime to get the sensor state (0-init,1-opened,2-started,3-stopped) of the device and the current baud rate of the DATA_port. The response of this command is provided on the CLI port. This command is valid for AWR294X devices.		
queryLocallp (TDM)	This is an optional command that can be issued anytime via the "Status" window of the visualizer to print out the IP Address obtained by the EVM. This command is valid for AWR294X devices.		Specific to TDM.
compressionCfg	Compression / Decompression configuration		Specific to DDM.
	This is a mandatory command.	<subframenum>: subframe Number</subframenum>	value of 0 to RL_MAX_SUBFRAMES- 1
AWR294X (DDM) AWR2544 (TDM/DDM)		<enabled>: 1 if enabled</enabled>	must be enabled, since disabling compression is not currently supported
		<compressionmethod></compressionmethod>	0: EGE compression 1: BFP compression
		<compressionratio>: compression ratio</compressionratio>	floating point number between 0 and 1
		<rangebinsperblock>: number of range bins to compress per block</rangebinsperblock>	must be a power of 2.
intfMitigCfg	Interference mitigation configuration. Enabled by default in the current release.		Specific to DDM.
		<subframenum>: subframe number</subframenum>	value of 0 to RL_MAX_SUBFRAMES- 1
AWR294X (DDM) AWR2544 (TDM/DDM)	Mandatory command.	<magsnrdb>: mag SNR for interference mitigation</magsnrdb>	integer val in dB
		<magdiffsnrdb>: magDiff SNR for interference mitigation</magdiffsnrdb>	integer val in dB
localMaxCfg (DDM)	Local max configuration. Enabled by default in the current release.		Specific to DDM.
	Mandatory command.	<subframenum>: subframe number</subframenum>	value of 0 to RL_MAX_SUBFRAMES- 1
	This command is valid for AWR294X devices.	<azimthreshdb>: azimuth threshold for local max paramset</azimthreshdb>	integer val in dB
		<dopplerthreshdb>: doppler threshold for local max paramset</dopplerthreshdb>	integer val in dB
rangeProcCfg (DDM)	Range processing chain configuration.		Specific to DDM.
	Not a mandatory command.		
I	I	I	



		 <rangeprocchain>: Range Processing Chain select (below number of paramsets exclude dummy and compression paramsets)</rangeprocchain> 0 (Default Mode) – Three HWA Paramsets (except Dummy and Compression) are used. DC Estimates and Interference Statistics are computed for current chirp and used in the same chirp. 1 (Previous Frame DC Estimate Mode) – Two HWA Paramsets (except Dummy and Compression) are used. DC Estimates is computed for current chirp and used in the same chirp. Thus, every chirp's DC compensation happens with the DC estimate of previous frame. 2 (Previous Chirp Estimates Mode) – One HWA Paramset (except Dummy and Compression) is used. DC Estimates and Interference Statistics is computed and stored for next inth chirp. Thus, every chirp's DC compensation happens with the DC estimates and Interference Mitigation happens with the estimates from land the freence Mitigation happens with the estimates from previous not chirp and used in the same chirp is b Compensation and Interference is total number of subbands. 	Selects out of the three range processing chain differentiated primarily by number of HWA paramsets used for DC compensation, interference mitigation and range fft.
		<enablereal2x>: 1 if enabled</enablereal2x>	Real 2x mode makes the paramsets doing DC estimation, compensation and /or interference statistics but not FFT, to run on two real samples at once by considering them complex. Not applicable for rangeProcChain mode 2 (previous chirp estimates mode).
		<magthresminlim>: Interference stats magnitude threshold minimum limit</magthresminlim>	integer val > 0 Applicable only for rangeProcChain 2 (previous chirp estimates mode).
		<magdiffthresminlim>: Interference stats magnitude difference threshold minimum limit</magdiffthresminlim>	integer val > 0 Applicable only for rangeProcChain 2 (previous chirp estimates mode).
ddmPhaseShiftAntOrder (DDM)	Antenna order to configure DDM phase shifters. If the user does not intend to use all the TX antennas, the order should be programmed assuming that all the TX were enabled. The phase shift values for the ones that are not enabled will be configured to 0 by the code. Note that in the DDMA case, the elevation antenna(s) should always come at the end of this array. Basically, phaseShift(azimuth) < phaseShift(elevation) must be ensured. Mandatory command for DDM demo in dfeDataOutputMode 1 and 3.	<tx0> <tx1> <txn>: Antennas in increasing order of phase shift value. tvOChirpPhase < tx1ChirpPhase < < txNChirpPhase N = Number of Tx Antenna - 1</txn></tx1></tx0>	Specific to DDM. For AWR2944 ETS antenna array, TX0, TX2, TX3 are azimuth and TX1 is elevation. Then phase shift order = {0, 2, 3, 1}.
antGeometryCfg	Antenna Geometry Parameters required to derive the virtual antenna		
andeonetyoig	array rearrangement order and zero insertion mask. For more details refer to: mmwave mcuplus sdk <ver>\ti\demo\</ver>	<tx0row> <tx0col> <txnrow> <txncol> : Antenna Position for the N - 1 virtual antennas in <row> <column> format</column></row></txncol></txnrow></tx0col></tx0row>	
	<device>\mmw\docs\doxygen\html \index.html</device>	<xspacebylambda>: Azimuth spacing in units of lambda</xspacebylambda>	Float val = 0.5 for AWR2944 ETS antenna array
	Mandatory command. This command is valid for AWR294X device.	<zspacebylambda>: Elevation spacing in units of lambda</zspacebylambda>	Float val = 0.8 for AWR2944 ETS antenna array
antennaCalibParams (DDM)	Antenna calibration parameters. Refer to the procedure mentioned here Mandatory command. This command is valid for AWR294X devices.	<q0> <l0> <q15> <l15>: antenna calibration parameters for the 16 virtual antennas of AWR294X in Im(Q) -Re(I) format For AWR2943, the last 8 values will be ignored.</l15></q15></l0></q0>	Specific to DDM. Im(Q)-Re(I) format
cfarCfg (different from cfarCfg used	cfar configuration		Specific to DDM.
in TDM chain) (DDM)		< procDirection>	Both values supported
	Mandatory command. This command is valid for AWR294X devices.	Processing direction: 0 – CFAR detection in range direction	
	This command is valid for AWK234X devices.	1 – CFAR detection in Doppler direction	
		<averagemode> CFAR OS and CFAR CA (smaller of) is supported</averagemode>	must be 2 (CFAR-CASO) or 3 (CFAR- OS)
		<pre><winlen> noise averaging window length: Length of the one-sided noise averaged cells in samples Make sure 2*(winLen+guardLen) <numrangebins 2*(winlen+guardlen)="" <numdopplerbins="" and="" direction="" direction.<="" doppler="" for="" pre="" range=""></numrangebins></winlen></pre>	supported



		<guardlen></guardlen>	must be 0 for CFAR-OS
		one-sided guard length in samples	
		Make sure 2*(noiseWIn+guardLen) <numrangebins and<br="" direction="" for="" range="">2*(noiseWIn+guardLen)</numrangebins>	
		<pre><numdopplerbins <="" direction.="" doppler="" for="" pre=""></numdopplerbins></pre>	noise div shift
		Cumulative noise sum divisor expressed as a shift. Sum of noise samples is divided by 2^ <noisedivshift>. This parameter is not applicable in</noisedivshift>	<noisedivshift> = ceil(log₂(<winlen> A value of 3 means that the noise sum is divided by 2^A3=8 to get the</winlen></noisedivshift>
		CFAR-OS mode.	average of noise samples with window length of 8 samples in CFAR-CASO mode.
		The actual value that is used for division (2^x) is a power of 2, even though the "noise averaging window length" samples may not have that restriction.	
		<cyclicmode></cyclicmode>	only cyclic mode enabled (1) is supported
		cyclic mode	
		0- Disabled 1- Enabled	
		<threshold></threshold>	Detection threshold is specified in
		CFAR detection threshold in dB	dB scale.
		<peakgroupingen></peakgroupingen>	supported
		Peak grouping	
		0: Disabled	
		1: Enabled	
		<oskvalue></oskvalue>	See model profile configuration file in demo/awr294x/mmw/profiles for example configuration
		CFAR-OS K Value <osedgekscaleen></osedgekscaleen>	example configuration. See model profile configuration file in
		CFAR-OS Edge K Scaling Enable	demo/awr294x/mmw/profiles for example configuration.
		< isEnabled>	For CFAR in Range direction: Both values supported
		CFAR Enable: 0 – Disabled 1 – Enabled	For CFAR in Doppler direction: Must enabled
eadSpectrumConfig	Spread spectrum clocking (SSC) configuration		
eadopectrumcomig	The module supports spread spectrum clocking (SSC) on its output	<coreadpllenable></coreadpllenable>	Supported
	clocks. SSC is used to spread the spectral peaking of the clock to reduce any electromagnetic interference (EMI) that may be caused due to the clock's fundamental or any of its harmonics. When SSC is	Enable SSC for Core ADPLL	
	enabled the clock's spectrum is spread by the amount of frequency spread, and the attenuation is given by the ratio of the frequency	0- Disabled	
	spread (f) and the modulation frequency (fm), i.e., 10*log10(f/fm) dB.	1- Enabled	
		<coremodrate></coremodrate>	Integer values in range 1 to 100
	BSS Clock source (PER PLL in default SBL) cannot	Core ADPLL modulation rate in KHz <coremoddepth></coremoddepth>	Float values in range 0 to 2
	have SSC enabled.	Core ADPLL modulation depth in percentage	
	Additionally, when BSS Dynamic clocking is enabled, FRC clock source cannot have SSC enabled.	<coredownspread></coredownspread>	1 is recommended as frequency sho not exceed the maximum operating
		0- Center spread	frequency of device
	Refer section 3.8 SBL Clock configuration for more details on clock	1- Down spread	Currented
	sources.	<dspadpllenable> Enable SSC for DSP ADPLL</dspadpllenable>	Supported
		0- Disabled	
		1- Enabled	
		<pre></pre>	Integer values in range 1 to 100
		DSP ADPLL modulation rate in KHz	
		<dspmoddepth></dspmoddepth>	Float values in range 0 to 2
		Core ADPLL modulation depth in percentage	
		<dspdownspread></dspdownspread>	1 is recommended as frequency sho not exceed maximum operating
		0- Center spread	frequency of device
		1- Down spread	



			-
		<peradpllenable></peradpllenable>	Supported
		Enable SSC for PER ADPLL	Default SBL derives BSS clock from PER PLL, hence recommended to
		0- Disabled	disable SSC
		1- Enabled	
		<permodrate></permodrate>	Integer values in range 1 to 100
		PER ADPLL modulation rate in KHz	
		<permoddepth></permoddepth>	Float values in range 0 to 2
		PER ADPLL modulation depth in percentage	
		<perdownspread></perdownspread>	1 is recommended as frequency should
		0- Center spread	not exceed the maximum operating frequency of device
		1- Down spread	
		1- Down spiead	
procChainCfg	Configures processing chain for TDM/DDM, 1X/2X mode.		
		<procchain></procchain>	Supported
		0 - TDM : Do not configure phase	
	This command is valid for only AWR2544 device.	1 - DDM : Configures the phase of TX antennae per chirp.	
		<2xMode>	Supported
		0 - Disable 2x Mode : Use HWA FFT engine in single path. 1 - Enable 2x Mode : Use HWA FFT engine in 2X mode (two parallel paths).	
		<ethpktrdycnt></ethpktrdycnt>	Supported
		Number of Chirps after which CPSW is to be triggered.	
		Refer demo documentation for more details.	
		<pre><code and="" content="" dotated.<="" more="" pre="" the=""></code></pre>	Integer Values
		Amount of delay to be added before each packet is transmitted in us.	
		This delay spreads the packet transfers and may be helpful in the use-cases where lower (< 1Gbps) CPSW transfer rate is required depending on the capability of Rx side. It helps	
		in resolving the packet drop.	
		Refer demo documentation for more details.	
		<nwpktcrcsel></nwpktcrcsel>	Supported
		Computes CRC for payload, header and footer	Refer TRM for more details.
		0 - 16 bit CRC	
		1 - 32 bit CRC	
adcDataDitherCfg	Configures the dither of chirp available interrupt to delay CPSW event		
adebatabiliterolg		<isdelayen></isdelayen>	Supported
	This command is valid for only AWR2544 device.	Minimum delay of 1.1us is added if enabled	
		0 - Disable 1 - Enable	
		<isditheren></isditheren>	Supported
		Random dither is added if enabled in the range of (0, <ditherval>).</ditherval>	
		0 - Disable 1 - Enable	
		<ditherval></ditherval>	Value > 0
		Maximum amount of dither to be added in us	
showCpswStats	Prints the CPSW Network Statistics for Port0 and Port1 This command is valid for only AWR2544 device.		Note: This CLI should not be issued during chirping.
anaTempRead	Prints temperature values from BSS		Supported
	This command is valid for only AWR2544 and AWR2X44P		
	device.		
diaTompBood	Printo MCLL HWA and HSM tomperature values for AWDS544		Supported
digTempRead	Prints MCU, HWA and HSM temperature values for AWR2544.		Supported
	Prints DSP, HWA and HSM temperature values for AWR2X44P.		
	This command is valid for only AWR2544 and AWR2X44P device.		
readVoltageSig	Measures and prints external connected voltage values		Supported
. add y onlage Oly	This command is valid for only AWR2544 device.		



	on paramset (<enable> 0 - Disabled 1 - Enabled</enable>	Supported
hwaGateAfterFrameProc	Clock gates or p completed	ower gates	HWA afte	r the frame p	processing is		
	Clock is ungated	d in frame s	tart ISR			<option> 0 - No optimization 1 - Enable HWA Power gating</option>	Supported
	This command	is valid fo	r only AW	R2544 devid	ce.	2 - Enable HWA Clock gating	
unusedPerClkGate	The unused per gated.	ipherals in t	he provide	d demo app	lication are clock		
		is valid fo	r only AW	R2544 devid	ce.	<enableclkgating></enableclkgating>	Supported
	This command is valid for only AWR2544 device.					0 - Disabled 1 - Enabled	Clock gates the below peripherals when enabled: SPIB, I2C, SCIB, Watchdog, OBSCLKOUT, PMICCLKOUT, TRCCLKOUT, MCUCLKOUT
enableProgFiltCfg	To program the When enabled, filter and allows	overrides th	e device's	hard-coded	digital decimation	<enable></enable>	Supported
	From (MHz)	To (MHz)	Gain (dB)	Ripple (dB)	Actual Ripple (dB)	1 - Enabled	
	0	4	1	5	3.55		
	6	10	0	-60	-61.37		
	Sampling Frequ Desired Taps: 1		łz				
	This command		r AWR2X4	4P device o	oniv.		
					, .		
coexMSSVMONSelfTest	OV VMON Self-				DN Self-test, 1.2 I 3.3 UV VMON	<uv_vmon></uv_vmon>	Supported
	Self-test					0 - Disable 1 - Enable	
	not be used sim	ultaneously	. Please do	o not	NSelfTest should	<thresh></thresh>	Range: 0.56 to 0.68
	issue coexMSS been issued. Yo					Scaled Reference voltage value in V for 1.2 UV test (float) Scaling factor: 2	
	This command	is valid fo	r only AW	R2544 devid	ce.	<pre></pre> <pre></pre> <pre></pre>	Supported
						0 - Disable	
						1 - Enable <thresh></thresh>	Range: 0.48 to 0.58
						Scaled Reference Voltage Value in V for 1.2 OV test (float)	
						Scaling factor: 2 <osc_uv_vmon></osc_uv_vmon>	Supported
						0 - Disable	Cupportou
						1 - Enable	
						<thresh< td=""><td>Valid options: 0.6, 0.62, 0.64, 0.66</td></thresh<>	Valid options: 0.6, 0.62, 0.64, 0.66
						Scaled Reference Voltage Value in V for 1.8 OSC UV test (float) Scaling factor: 3	
						<td>Supported</td>	Supported
						0 - Disable	
						1 - Enable <thresh></thresh>	Valid options: 0.6, 0.62, 0.64, 0.66
						Scaled Reference Voltage Value in V for 3.3 UV test (float) Scaling factor: 5.5	
coexMSSVMONEnable	Enable and set	reference v	oltages for	1.2 UV VM	ON, 1.2 OV VMON	<uv_vmon></uv_vmon>	Supported
	, OSC UV VMO	N and 3.3 L	IV VMON		NSelfTest should	0 - Disable 1 - Enable	
	not be used sim					<pre><hr/><hr/><hr/><hr/><hr/><hr/><hr/><hr <="" td=""/><td>Range: 0.48 to 0.58</td></pre>	Range: 0.48 to 0.58
	This command	is valid fo	r only AW	R2544 devid	ce.	Scaled Reference voltage value in V for 1.2 UV VMON enable (float) Scaling factor: 2	
						<ov_vmon></ov_vmon>	Supported
						0 - Disable 1 - Enable	
						<pre><pre><pre><pre><pre><pre><pre><pre></pre></pre></pre></pre></pre></pre></pre></pre>	Range: 0.56 to 0.68
						Scaled Reference Voltage Value in V for 1.2 OV VMON enable (float) Scaling factor: 2	



		<osc_uv_vmon></osc_uv_vmon>	Supported
		0 - Disable 1 - Enable	
		<thresh< td=""><td>Valid options: 0.5, 0.52, 0.54, 0.56</td></thresh<>	Valid options: 0.5, 0.52, 0.54, 0.56
		Scaled Reference Voltage Value in V for 1.8 OSC UV VMON Enable (float) Scaling factor: 3	
		<vmon_3p3v></vmon_3p3v>	Supported
		0 - Disable 1 - Enable	
		<thresh></thresh>	Valid options: 0.5, 0.52, 0.54, 0.56
		Scaled Reference Voltage Value in V for 3.3 UV VMON Enable(float) Scaling factor: 5.5	
coexBSSVMONEnable	Enable and set reference voltages for VddaBb1P8V, VddaVco1P8V,	<vddabb1p8ven></vddabb1p8ven>	Supported
COEXDOG WICHLINDIE	VddRf11P0V, VddRf21P0V.		Supported
	This command is valid for only AWR2544 device.	0 - Disable 1 - Enable 3 - Self-test and enable	
		<vddabb1p8vref></vddabb1p8vref>	Valid values: 0.5, 0.52, 0.54, 0.56
		Scaled Reference Voltage Value in V (float) Scaling factor: 3	
		<vddavco1p8ven></vddavco1p8ven>	Supported
		0 - Disable 1 - Enable 3 - Self-test and enable	
		<vddavco1p8vref></vddavco1p8vref>	Valid values: 0.5, 0.52, 0.54, 0.56
		Scaled Reference Voltage Value in V (float) Scaling factor: 3	
		<vddrf11p0ven></vddrf11p0ven>	Supported
		0 - Disable 1 - Enable 3 - Self-test and enable	
		<pre></pre> <pre></pre> <pre></pre>	Valid values: 0.48, 0.49, 0.51, 0.52
		Scaled Reference Voltage Value in V (float) Scaling factor: 1.8	
		<vddrf21p0ven></vddrf21p0ven>	Supported
		0 - Disable 1 - Enable 3 - Self-test and enable	
		<vddrf21p0vref></vddrf21p0vref>	Valid values: 0.48, 0.49, 0.51, 0.52
		Scaled Reference Voltage Value in V (float) Scaling factor: 1.8	
coexMSSVMONDisable	Disable MSS VMONs	<uv_vmon></uv_vmon>	Supported
	This command is valid for only AWR2544 device.	1- Disable 1.2V UV VMON	Currented
		<ov_vmon></ov_vmon>	Supported
		1 - Disable 1.2V OV VMON <osc_uv_vmon></osc_uv_vmon>	Supported
			Supported
		1 - Disable 1.8V OSC UV VMON <vmon_3p3v></vmon_3p3v>	Supported
			Cupponeu
		1 - Disable 3.3V UV VMON	
powerMeasMssLoading	loads MSS (Perform matrix multiplication) for a given percentage of frame period.	<enable></enable>	Supported
	Loading time = frame period * (<percent>/100)</percent>	0 - Disable 1 - Enable	
	The matrix multiplication is a low priority task which R5 core executes when it is idle within the Loading time for each frame.	<pre><percent> Percentage duration of frame period when the R5 core is</percent></pre>	Supported
	This command is valid for only AWR2544 device. Note: Only the power measurement executable supports this command (awr2544_mmw_pm_demo.xer5f)	loaded	
%		Any line starting with '%' character is considered as	1

3.7.1.1.2. Table 1: mmWave SDK Demos - CLI commands and parameters

3.8. Running the prebuilt unit test binaries (.xer5f, .xem4 and .xe66)



Unit tests for the drivers and components can be found in the respective test directory for that component. See section "mmWave SDK - TI components" for location of each component's test code. For example, the Range Processing DPU test codes (that can run on RF5 and C66x separately) can be found in <mmwave_mcuplus_sdk_mcuplus_vers/ti/datapath/dpu/rangeproc/test. In this test directory, user can build .xer5f and . xe66 files (build instructions mentioned in "Building datapath/control components"). Follow the instructions in section "CCS development mode" to download and execute these unit tests via CCS.

3.9. SDK Clock Configurations

3.9.1. AWR294x

A SBL - R5F Operating Mode

MCU PLUS SDK has environment to support both lock-step and dual core boot modes. Current "sbl_qspi.release.tiimage" available at " <mmwave_mcuplus_sdk_mcuplus_ver>/tools/<device>" SBL application supports only Lock-step boot mode.

3.9.1.1. Default SBL clock configurations

The secondary bootloa	ader configures all the clo	cks. The default configuration is:

ADPLL Name (Operating Freq.)	HSDIV	Configured frequency
CORE PLL (600 MHz)	HSDIV_CLKOUT0	Powered down
	HSDIV_CLKOUT1	200 MHz (Ethernet)
	HSDIV_CLKOUT2	300 MHz (MSS Clock Source) 150MHz (SYS Clock)
	HSDIV_CLKOUT3	200 MHz (FRC Clock Source)
DSP PLL (720 MHz)	HSDIV_CLKOUT0	Powered Down
	HSDIV_CLKOUT1	360 MHz (DSP Clock Source)
	HSDIV_CLKOUT2	240 MHz (QSPI, MCAN)
	HSDIV_CLKOUT3	Powered Down
PER PLL (1800 MHz)	HSDIV_CLKOUT0	Powered Down
	HSDIV_CLKOUT1	200 MHz (BSS Clock Source)
	HSDIV_CLKOUT2	Powered Down
	HSDIV_CLKOUT3	Powered Down

3.9.1.1.1. Table 1: mmWave SDK Demos - Clock configurations

3.9.1.2. SBL clock configurations for BSS dynamic clocking feature

Feature	BSS Clock Source	FRC Clock Source
BSS Dynamic clocking disabled	PER PLL CLKOUT1	PER PLL CLKOUT1
BSS Dynamic clocking enabled	Switches between XTAL (40 MHz) and PER PLL CLKOUT1	CORE PLL CLKOUT3

3.9.1.2.1. Table 2: mmWave SDK Demos - Clock configurations for BSS dynamic clocking

A The BSS, FRC clock source and dynamic clocking feature should be enabled before un-halting BSS core.

If BSS Dynamic clocking feature is enabled, the BSS and FRC clock sources need to be different. Application has to configure FRC to 200 MHz.

MSS RTIC is used by BSS when Dynamic clocking is enabled and hence cannot be used by application.

By default, BSS Dynamic clocking has been enabled in the SBL provided in the SDK

For more details on BSS Dynamic clocking feature refer "RSS dynamic frequency switch" section in ICD at: mmwave_mcuplus_sdk_<ver>\mmwave_dfp_02_04_<ver>\docs.

Clock Source

To enable/disable this feature, refer BSS Dynamic Clocking.

3.9.1.3. Peripheral Clock Configurations

Peripheral

AWR294x Frequency (MHz)



CPSW (Ethernet)	150	SYS Clock
CPTS	200	DPLL_CORE_HSDIV0_CLKOUT1
CPSW (MII100)	50	DPLL_CORE_HSDIV0_CLKOUT1
CPSW (MII10)	5	DPLL_CORE_HSDIV0_CLKOUT1
CPSW (RGMII)	50	DPLL_CORE_HSDIV0_CLKOUT1
EPWM	150	SYS Clock
HSI (LVDS)	1800	PER_PLL
HWA	300	DPLL_CORE_HSDIV0_CLKOUT2
I2C	150	SYS Clock
MCANA MCANB	80	DPLL_DSP_HSDIV0_CLKOUT2
MIBSPIA MIBSPIB	150	SYS Clock
MSS_RTIA MSS_RTIB MSS_RTIC DSS_RTIA DSS_RTIB	150	SYS Clock
QSPI	80	DPLL_DSP_HSDIV0_CLKOUT2
UARTA UARTB	150	SYS Clock
WDT (Watchdog)	150	SYS Clock

3.9.2. AWR2544

3.9.2.1. Default SBL clock configurations


ADPLL Name (Operating Freq.)	HSDIV	Configured frequency
CORE PLL (1500 MHz)	HSDIV_CLKOUT0	Powered down
	HSDIV_CLKOUT1	250 MHz (Ethernet Clock Source)
	HSDIV_CLKOUT2	300 MHz (MSS Clock Source)
		150MHz (SYS Clock)
	HSDIV_CLKOUT3	Powered Down
PER PLL (1200 MHz)	HSDIV_CLKOUT0	Powered Down
	HSDIV_CLKOUT1	200 MHz (BSS and FRC Clock Source)
	HSDIV_CLKOUT2	Powered Down
	HSDIV_CLKOUT3	Powered Down

3.9.2.1.1. Table 1: mmWave SDK Demos - Clock configurations

3.9.2.2. SBL clock configurations for BSS dynamic clocking feature

Feature	BSS Clock Source	FRC Clock Source
BSS Dynamic clocking disabled PER PLL CLKOUT1		PER PLL CLKOUT1
BSS Dynamic clocking enabled	Switches between XTAL (50 MHz) and PER PLL CLKOUT1	PER PLL CLKOUT1

3.9.2.2.1. Table 2: mmWave SDK Demos - Clock configurations for BSS dynamic clocking





BSS Dynamic Clock Switching (AWR2544)
 Sequence to enable BSS Dynamic clock switching feature can be referred from "SOC_rcmPopulateBSSControl" API in mcu_plus_sdk_awr2544_<ver>\source\drivers\soc\awr2544\soc_rcm.c.
 Below are the sequence of steps to enable feature (Current SBL Configuration) before un-halting BSS core:

 Set BIT#3 of RSS_PROC_CTRL:RSS_CR4_BOOT_INFO_REG5 register.
 Configure FRC clock source as DPLL_PER_HSDIV0_CLKOUT1 by writing "1" to BIT#18:16 of RSS_PROC_CTRL: RSS_CR4_BOOT_INFO_REG5 register.
 Configure BSS Clock source by writing 0x333 (Clock Source Selected: DPLL_PER_HSDIV0_CLKOUT1_MUXED) to BIT#15:4 of RSS_PROC_CTRL:RSS_CR4_BOOT_INFO_REG5 register
 Enable FRC clock by writing 0x7 to BIT#8:10 of MSS_TOPRCM:HW_SPARE_RW0 register.

 By default, SBL application provided in the SDK enables BSS Dynamic clocking feature.

3.9.3. AWR2X44P

3.9.3.1. Default SBL clock configurations

ADPLL Name (Operating Freq.)	HSDIV	Configured frequency
CORE PLL (800 MHz)	HSDIV_CLKOUT0	Powered down
	HSDIV_CLKOUT1	200 MHz (Ethernet)
	HSDIV_CLKOUT2	400 MHz (MSS Clock Source) 200 MHz (SYS Clock DSS CM4 Clock Source)
	HSDIV_CLKOUT3	Powered down
DSP PLL (900 MHz)	HSDIV_CLKOUT0	Powered Down
	HSDIV_CLKOUT1	450 MHz (DSP Clock Source)
	HSDIV_CLKOUT2	Powered Down
	HSDIV_CLKOUT3	Powered Down
PER PLL (1600 MHz)	HSDIV_CLKOUT0	Powered Down
	HSDIV_CLKOUT1	200 MHz (BSS and FRC Clock Source)
	HSDIV_CLKOUT2	Powered Down
	HSDIV_CLKOUT3	Powered Down

3.9.3.1.1. Table 1: mmWave SDK Demos - Clock configurations

3.9.3.2. SBL clock configurations for BSS dynamic clocking feature

Feature	BSS Clock Source	FRC Clock Source
BSS Dynamic clocking disabled	PER PLL CLKOUT1	PER PLL CLKOUT1
BSS Dynamic clocking enabled	Switches between XTAL (40/50 MHz) and PER PLL CLKOUT1	PER PLL CLKOUT1

3.9.3.2.1. Table 2: mmWave SDK Demos - Clock configurations for BSS dynamic clocking

A BSS Dynamic Clock Switching (AWR2X44P)

Sequence to enable BSS Dynamic clock switching feature can be referred from "SOC_rcmPopulateBSSControl" API in mcu_plus_sdk_awr2x44p_<ver>\source\drivers\soc\awr2x44p\soc_rcm.c .

Below are the sequence of steps to enable feature (Current SBL Configuration) before un-halting BSS core:

- Set BIT#3 of RSS_PROC_CTRL:RSS_CR4_BOOT_INFO_REG5 register.
- Configure FRC clock source as DPLL_CORE_HSDIV0_CLKOUT3 by writing "0" to BIT#18:16 of RSS_PROC_CTRL: RSS_CR4_BOOT_INFO_REG5 register.
- Configure BSS Clock source by writing 0x333 (Clock Source Selected: DPLL_PER_HSDIV0_CLKOUT1_MUXED) to BIT#15:4 of RSS_PROC_CTRL:RSS_CR4_BOOT_INFO_REG5 register.

By default, SBL application provided in the SDK enables BSS Dynamic clocking feature.



3.9.3.3. Peripheral Clock Configurations

Peripheral	Frequency (MHz)	Clock Source
CPSW (Ethernet)	200	SYS Clock
CPTS	200	DPLL_CORE_HSDIV0_CLKOUT1
CPSW (MII100)	50	DPLL_CORE_HSDIV0_CLKOUT1
CPSW (MII10)	5	DPLL_CORE_HSDIV0_CLKOUT1
CPSW (RGMII)	50	DPLL_CORE_HSDIV0_CLKOUT1
EPWM	200	SYS Clock
HSI (LVDS)	1600	PER_PLL
HWA	400	DPLL_CORE_HSDIV0_CLKOUT2
I2C	200	SYS Clock
MCANA MCANB	80	DPLL_CORE_HSDIV0_CLKOUT2
MIBSPIA MIBSPIB	200	SYS Clock
MSS_RTIA MSS_RTIB MSS_RTIC DSS_RTIA DSS_RTIB	200	SYS Clock
QSPI	80	DPLL_CORE_HSDIV0_CLKOUT2
UARTA UARTB	200	SYS Clock
WDT (Watchdog)	200	SYS Clock

3.9.3.4. Ethernet configuration changes (Gigabit speed)

A Default EVM configuration is having Industrial PHY (DP83867E) connected to SOC.

To enable Auto PHY (DP83TC812R) populated on EVM which is capable of 100Mbps link requires hardware modification. Refer EVM User Guide for more details.

User can select DP83TG720S Auto PHY for testing 1Gbps operation.

Default configuration in SDK is for 100Mbps link. To operate ethernet at 1Gbps speed, the following changes have to be done:

1. Clock changes:

a. Configure Core PLL frequency to 2000MHz (250MHz for RGMII and 400MHz for R5F[MSS]) and CORE_PLL_CLKOUT_1 to 250MHz in Bootloader_socConfigurePII API as shown below in mcu_plus_sdk_awr2x44p_<ver>

b. Set "PLL_CORE_CLKCTRL_SELFREQDCO" field of MSS_TOPRCM:PLL_CORE_CLKCTRL register to 0x4 in SOC_rcmConfigurePIICore API as shown below in mcu_plus_sdk_awr2x44p_<ver>

*ptrClkCtrl = SOC_rcmInsert8 (*ptrClkCtrl, 12U, 10U, 0x4U);

c. Configure RGMII clock to 250MHz in SOC_rcmConfigEthMacIf API as shown below in <u>mcu_plus_sdk_awr2x44p_<ver>\source\drivers\soc\awr2x44p\soc_rcm.c</u>

```
void SOC_rcmConfigEthMacIf(void)
{
    CSL_mss_rcmRegs *ptrMSSRCMRegs;
   uint32_t clkFreq = 0U;
   uint32_t clkDivisor;
   uint32_t mii10ClkDivVal;
   uint32_t clkSrcVal;
   ptrMSSRCMRegs = CSL_RCM_getBaseAddress();
    clkSrcVal = gSocRcmCpswMiiClkSrcValMap[SOC_RcmCpswMiiClockSource_DPLL_CORE_HSDIV0_CLKOUT1];
    CSL_FINS(ptrMSSRCMRegs->MSS_CPSW_MII_CLK_SRC_SEL,
MSS_RCM_MSS_CPSW_MII_CLK_SRC_SEL_MSS_CPSW_MII_CLK_SRC_SEL_CLKSRCSEL, clkSrcVal);
   clkFreq = SOC_rcmGetFreq(gSocRcmCpswMiiClkSrcInfoMap
[SOC_RcmCpswMiiClockSource_DPLL_CORE_HSDIV0_CLKOUT1]);
   clkDivisor = SOC_rcmGetModuleClkDivVal(clkFreq, SOC_RCM_FREQ_MHZ2HZ(50U));
   ptrMSSRCMRegs->MSS_MII100_CLK_DIV_VAL = SOC_rcmInsert16 (ptrMSSRCMRegs-
>MSS_MII100_CLK_DIV_VAL, 11U, 0U, SOC_rcmGetModuleClkDivRegVal(clkDivisor));
   clkDivisor = SOC_rcmGetModuleClkDivVal(clkFreq, SOC_RCM_FREQ_MHZ2HZ(5U));
   miilOClkDivVal = (clkDivisor & 0xFF) | ((clkDivisor & 0xFF) << 8) | ((clkDivisor & 0xFF)</pre>
<< 16);
   ptrMSSRCMRegs->MSS_MII10_CLK_DIV_VAL = SOC_rcmInsert32 (ptrMSSRCMRegs-
>MSS_MII10_CLK_DIV_VAL, 23U, 0U, mii10ClkDivVal);
   clkDivisor = SOC_rcmGetModuleClkDivVal(clkFreq, SOC_RCM_FREQ_MHZ2HZ(250U));
   ptrMSSRCMRegs->MSS_RGMII_CLK_DIV_VAL = SOC_rcmInsert16 (ptrMSSRCMRegs-
>MSS_RGMII_CLK_DIV_VAL, 11U, 0U, SOC_rcmGetModuleClkDivRegVal(clkDivisor));
}
```

2. Enable 1Gbps by setting CPSW_SOC_ENABLE_1GBPS macro to 1 as shown below in <u>mcu_plus_sdk_awr2x44p_<ver>\source\networking\.</u> meta\enet_cpsw\templates\awr2x44p\enet_soc_cfg.c.xdt

(1)

#define CPSW_SOC_ENABLE_1GBPS

3. Update CPTS Clock to 250MHz:

a. Set cpts_input_clk_freq_2x44p = 250000000 in <u>mcu_plus_sdk_awr2x44p_<ver>\source\networking\.</u> meta\enet_cpsw\awr2x44p.enet_cpsw_awr2544_awr2x44p.syscfg.js

let cpts_input_clk_freq_2x44p = 250000000;

b. Set the default value for "cptsRftClkFreq" field in CPTS configuration as "CPSW_CPTS_RFTCLK_FREQ_250MHZ" in mcu_plus_sdk_awr2x44p_<ver>\source\networking\.meta\enet_cpsw\awr2544_awr2x44p\enet_cpsw_cpts_config.syscfg.is

```
name: "cptsRftClkFreq",
description: "CPTS RFT clock frequency required to set TS_ADD VAL",
displayName: "CPTS Clock Frequency Add Value",
default: "CPSW_CPTS_RFTCLK_FREQ_250MHZ",
```

🐌 Texas Instruments

4. How-To Articles


4.1. How to identify the COM ports for mmWave EVM

When the EVM is powered on and connected to Windows PC via the supplied USB cable, there should be two additional COM Ports in Device Manager. See your mmWave devices' TI EVM User Guide for details on the COM port.

Troubleshooting Tip If the COM ports don't show up in the Device Manager or are not working (i.e. no demo output seen on the data port), then one of these steps would apply depending on your setup:

- 1. If you want to run the Out-of-box demo, simple browse to the Visualizer (https://dev.ti.com/gallery/view/mmwave /mmWave_Demo_Visualizer) and follow the one-time setup instructions.
- 2. If you are trying to flash the board, using Uniflash command line tool and desktop version installation instructions would also install the right drivers for the COM ports.
- 3. If above methods didn't work and if TI code composer studio is not installed on that PC, then download and install the standalone XDS110 drivers.
- 4. If TI code composer studio is installed, then version of CCS and emulation package need to be checked and updated as per the mmWave SDK release notes. See section Emulation Pack Update for more details.

After following the above steps, disconnect and re-connect the EVM and you should see the COM ports now. See the highlighted COM ports in the Figure below



4.1.1.1.1 Figure 3: mmWave EVM PC Connectivity - Device Manager - COM Ports

A COM Port

Please note that the COM port numbers on your setup maybe different from the one shown above. Please use the correct COM port number from your setup for following steps.

🐌 Texas Instruments

4.2. How to flash an image onto mmWave EVM

4.2.1. Tool requirements on host PC:


- The tool is implemented using python and needs python version 3.x
 - The tool uses additional python packages as listed below:
 - pyserial for UART access on PC
 - xmodem for the file transfer protocol
 - ° tqdm for progress bar when the tool is executing
- Refer to Python3, to install python and the required python packages on your PC.

4.2.2. Python3 Setup

Attention

It is important to install Python 3.x. If you have Python 2.x installed, then additionally install Python 3.x and make sure the command python or python3 indeed points to Python 3.xAll commands mentioned below should be typed in cmd.exe command console in Windows and bash terminal in Linux.

- Python scripts are used for below functionality in the SDK,
 - Flashing files to the flash on the EVM via UART.
 - Booting application on the EVM via UART
- Flashing files is the most popular reason why you would need python, so its strongly recommended to install it.
- In Windows,
 - Install python from, https://www.python.org/downloads/windows/
 - Confirm python is installed by typing below in a command prompt, make sure you see 3.x as the version
 C:\> python --version
 - Python 3.9.1
 - If above command fails, then add path to Python to your environment "Path" variable, by default python is installed at below path C:\Users\{your username}\AppData\Local\Programs\Python\Python39
 - To add a new path to your environment variables, go to "Windows Task Bar Search" and search for "environment variables for your account"



Environment Variables For Your Account

- Click on "Path" variables, click on "Edit", click on "New"
- Add the path to the folder where python in installed.
- It is strongly recommended to move the path "up" in your path list by clicking the "Move Up" button until the path is at the top of the list.
- Click "OK" to save the settings
- Close your Windows command prompt and reopen it and then check if python is visible by doing below C:\> python --version Python 3.9.1

```
    Check if the python package manager "pip" is installed, by default pip should be installed along with python.
    C:\> python -m pip --version
    pip 21 0 1 from C:\Userpa(version)
```

pip 21.0.1 from C:\Users\{your username}\AppData\Local\Programs\Python\Python39\lib\sitepackages\pip (python 3.9)



Install below additional packages via "pip" that are needed for the flashing tools. If you are behind a corporate firewall make sure to
pass the server name and port for the proxy as shown below. If proxy is not needed keep --proxy= as blank.

C:\> python -m pip install pyserial xmodem tqdm --proxy={your proxy server weblink and port}

- In Linux,
 - Do below in Linux bash shell to install python3
 \$ sudo apt install python3 python3-pip
 - Check the python version by doing below
 - \$ python3 --version
 - Check if the python package manager "pip" is installed, by default pip should be installed along with python.
 \$ pip3 --version
 - Install below additional packages via "pip" that are needed for the flashing tools. If you are behind a corporate firewall make sure to
 pass the server name and port for the proxy as shown below. If proxy is not needed keep --proxy= as blank.

\$ pip3 install pyserial xmodem tqdm --proxy={your proxy server weblink and port}

Go back to: How to connect mmWave EVM to CCS using JTAG, Loading images onto mmWave EVM -->Demonstration Mode

4.2.3. Flash Procedure using UniFlash GUI (Applicable for AWR294x (not applicable for AWR2X44P))

- 1. Download UniFlash GUI tool (https://www.ti.com/tool/UNIFLASH) or use browser based UniFlash tool (https://dev.ti.com/uniflash/#!/) version 8.3.0 or later.
- 2. Prepare your EVM or module in flashing mode by setting it to SOP5 mode (SOP0:1; SOP1:0; SOP2:1) Refer SOP Configuration details.
- 3. Select AWR2944EVM (if using EVM else AWR2944) from the device option in UniFlash GUI and click Start button.

UniFlash						- 0
JniFlash	Session +	About				Help Set
Detected	Devices					
			Detect I	My Device		
			Connected devices will automa	-	vre info]	
			Start	New		
			Start	Now		
New Conf	figuration					
			Choose \	our Device		
			Category: All C2000 mmWave MSP PGA	Safety Tiva UCD	Wireless Bootloader	
			Q AWR294		22 ×	
			AWR2944EVM	EVM	Sorial	
			AWR2943		Seriel	
			AWR2944		Seriel	
				r Connection		

4. Select SBL (mmwave_mcuplus_sdk_<ver>\mmwave_mcuplus_sdk_<ver>\tools\awr294x\sbl_qspi.release.tiimage) and Application image (mmwave_mcuplus_sdk_<ver>\ti\demo\awr294x\mmw\awr2944_mmw_demoDDM.appimage).

- onniasi			
UniFlash Session -	About	🕐 Help 🛛 🔹 Settings	
Configured Device : Serial Connection	> AWR2944 [download coxml]	Cortex_R5_0	
Program	Select and Load Images		
Settings & Utilities	Flash Image(s)		
Standalone Command Line	SBL Image sbl_qspi.release.tiimage	Size: 59.59 KB 🚨 Browse 🗶	
	App Image awr2944_mmw_demoDDM.appimage	Size: 414.12 KB 📕 Browse 🗶	
	Available Action(s) - 2 images Selected Load Images Note: Please power cycle your device before loading images Quick Settings Remove All Note: Example - COM1 (Windows), /dev/ttyACM0 (Linux) Note: Example - COM1 (Windows), /dev/ttyACM0 (Linux) Note: Example - COM1 (Windows), /dev/ttyACM0 (Linux) 		
	COM Port: COM20		

- 5. Set the COM port as marked in above snapshot, select this COM port no. which is populated in Device Manager as 'Application/UART' with AWR2944BOOST EVM connected.
- 6. Click on 'Load Images' button to start the flashing process.

In case of any failure or uniflash stuck for long: check USB connection and COM port no., AWR294x EVM SOP setting and reset it, restart UniFlash GUI.

Go back to: How to flash an image onto mmWave EVM

/!

4.2.4. Flash Procedure using Python tools

You will need the mmWave Device TI EVM, USB cable and a Windows/Linux PC to perform these steps.

1. Setup the EVM for Flashing

Refer to the EVM User Guide to understand the bootup modes of the EVM and the SOP jumper/switch locations (See "Sense-on-Power (SOP) Jumpers" section in mmWave device's EVM user guide). The table detailing the boot modes and the figure with the SOP jumper /switch locations are provided below for quick reference.

SOP0	SOP1	SOP2	Bootloader mode & operation
jumper /switch	jumper /switch	jumper /switch	
1	1	0	No-Boot Mode
			ROM does not execute in this boot mode.
1	0	1	UART Boot Mode
			ROM receives the secondary boot loader via UART interface MSS SCI A and loads it in SoC memory and switches to SBL execution.
			SBL receives multicore application image via UART interface MSS SCI A and loads it in SoC memory and switches to application image execution.
1	0	0	QSPI Boot Mode
			ROM loads the SBL from serial flash at flash offset of 0x0, and SBL loads the multicore appimage from serial flash at flash offset of 0xA0000.

A XTAL 40/50 MHz Detection

SOP3 and SOP4 pins are connected to SOC which is read by software to determine the XTAL populated on EVM.

XTAL	SOP4	SOP5
40 MHz	0	0
50 MHz	1	1

Refer EVM schematics for more details.

2. Procure the Images

For flashing AWR294X / AWR2544 / AWR2X44P devices, flashing tool at mcu_plus_sdk_<platform>_<version>\tools\boot\uart_uniflash.py should be used. For details related to tools required for flashing procedure, please refer "Flashing Tools" section of mcu_plus_sdk api_guide available at mcu_plus_sdk_<platform>_<version>\docs\api_guide_<platform>. The flashing procedure requires the flashing of three binaries, the first two (flash programmer and SBL) of which are present in the mmwave_mcuplus_sdk_<version>\tools\<platform> folder. The third step is to flash the application image (with an extension .appimage) of your choice (for example, CCS Debug binary or demo binary). For the SDK packaged demos, there is a .appimage file provided in their respective folder:

mmwave_mcuplus_sdk_<version>\ti\demo\<platform>\mmw\<platform>_<demo>.appimage which is the metalmage to be used for flashing. The metalmage already has the MSS, DSS, DSS_CM4 and BSS (as applicable) application combined into one file. Users can use the flashing procedure given below to flash the metalmage of their custom demo as well.

3. Setup the Build Environment

a. Run the setenv script to set up the build environment, as shown in the following code block. Note that for UNIX, the shell script which performs this step is located in mmwave_mcuplus_sdk_<version>\scripts\unix (use source ./setenv.sh as mentioned in this section).

Setting up Build Environment variables

```
@REM Change the path/version
cd C:\ti\mmwave_mcuplus_sdk_<version>\scripts\windows
@REM Remember to change the variable "MMWAVE_SDK_DEVICE" in this file!
setenv.bat
```

4. Flashing procedure

- a. Power up the EVM and check the Device Manager in your windows PC. Note the number for the serial port marked as " XDS110 Class Application/User UART " for the EVM. Refer to How to identify the COM ports for mmWave EVM section to identify the COM port. Lets say for this example, it showed up as COM25. The steps for flashing the binaries to the EVM are as follows:
- b. Switch to UART Boot Mode (SOP0: 1, SOP1: 0, SOP2: 1) and power cycle the EVM.
- c. The flashing procedure requires the flashing of three binaries, the first two of which are present in the mmwave_mcuplus_sdk_<version>\tools\platform> folder. The third step is to flash the image (with an extension .appimage) of your choice (for example, CCS Debug binary or demo binary). The following code blocks shows the steps, which must be executed in the UART Boot Mode.



Flashing the appimage onto the EVM

```
@REM Step(i): updated the default.cfg file available at %MMWAVE_SDK_INSTALL_PATH%
\tools\<platform> with user's .appimage path
@REM Example ../../ti/utils/ccsdebug/%Platform%_ccsdebug.appimage
@REM Example ../../ti/utils/ccsdebug/%Platform%_ccsdebug.appimage
@REM Step(ii): cd to path
cd %MMWAVE_SDK_INSTALL_PATH%/tools/<platform>
@REM Step(iii): Command to flash the files
@REM The <COM Port> can be, for example, COM25
@REM For AWR294x path would be %MCU_PLUS_AWR294X_INSTALL_PATH%/tools/boot/uart_uniflash.py
@REM For AWR2544 path would be %MCU_PLUS_AWR2544_INSTALL_PATH%/tools/boot/uart_uniflash.py
python %MCU_PLUS_AM294X_INSTALL_PATH%/tools/boot/uart_uniflash.py
python %MCU_PLUS_AM294X_INSTALL_PATH%/tools/boot/uart_uniflash.py
cfg
```

5. Switch to the QSPI Boot Mode and power-cycle the EVM

Go back to: How to flash an image onto mmWave EVM

4.3. How to connect mmWave EVM to CCS using JTAG

Debug/JTAG capability is available via the same XDS110 micro-USB port/cable on the EVM. TI Code composer studio would be required for accessing the debug capability of the device.

🚹 FTDI


As SOP setting is also driven by FTDI cable, do not connect FTDI cable while executing any of the SDK applications.

- 1. Use the instructions present in the How to flash an image onto mmWave EVM to flash the CCS Debug binary (user will need to give the path to the CCS Debug binary: %MMWAVE_SDK_INSTALL_PATH%\ti\utils\ccsdebug\%MMWAVE_SDK_DEVICE%_ccsdebug.appimage in Step 4.c.(iv) of the flashing instructions).
- 2. Ensure JTAG mux is set to onboard XDS110, as in the figure below and device is in QSPI boot mode.



- 3. Connect micro-USB cable from EVM (Labeled with XDS_USB) to PC.
- 4. Target Configuration file for CCS (CCXML)

Create a target configuration for the EVM (for example, <<u>device>evm_xds110.ccxml</u>). Follow the steps mentioned below for the same. a. If your CCS window does not already show "Target Configurations" pane, go to *View->Target Configurations*



b. This will show the "Target Configurations" pane. right click in this pane and select "New Target Configuration".



c. Give an appropriate name to the .ccxml file you want to create for the EVM.



: 🛱 | B

d. As shown in the figure below, scroll the "Connection" list and select "Texas Instruments XDS110 USB Debug Probe" (Step A). When this is done, the "Board or Device" list will be filtered to show the possible candidates, find (Step B) and choose the mmWave device of interest (AWR294X/AWR2X44P) and check the box (Step C). Click save (Step D) to store this ccxml file. Note that if you don't find your desired device in the list, it is likely that step 4 was not performed correctly.

General Setup	Advanced Setup
This section describes the general configuration about the target.	
Connection Texas Instruments XDS110 USB Debug Probe Step A	Target Configuration: lists the co
Board or Device awr Step B	Save Configuration
AWR1443 AWR1642	Save Step D
AWR1843 AWR2943	Test Connection
☑ AWR2944 Step C ☑ AWR6443	To test a connection, all changes configuration file contains no err
AWR6843	Test Connection
	Alternate Communication
	Uart Communication $$
AWR2944 Radar	To enable host side (i.e. PC) com communication over UART, targ implementation. Please check e target application leverages TI-R enable Uart Monitor module.
Note: Support for more devices may be available from the update manager.	

asic			
General Setup			
This section descr	ibes the general configuration about the	target.	
Connection	Texas Instruments XDS110 USB Debug P	robe ~	
Board or Device	type filter text		
	AM263x_LAUNCHPAD	^	
	AM273x		
	AWR1443		
	AWR1642		
	AWR1843		
	AWR2544		
	AWR2943		
	AWR2944		
	AWR2944LC		
	AWR2X44P		
	AWR6443	~	
	AWR2X44P Radar	^	
		~	


While creating CCXML file for device AWR2E44P/AWR2944P, type "AWR2x44P" in "Board or Device" field, and select "AWR2x44P" checkbox.

介 CCS Configuration

Steps 4 and 5 above are a one-time configuration. Once a target configuration is saved, the user can simply load it again as it will be listed as an existing configuration.

🠌 Texas Instruments

5. Launch this device configuration by right-clicking on the target configuration in the "Target Configurations" pane.



- 6. This will list three cores of AWR294X R5_0, R5_1 and C66x in the Debug pane. If you don't see this pane, go to ViewDebug.
- 7. Connect to R5_0 and/or C66x in the Debug window.

		Connect Target	Ctrl+Alt+C
	-8-	3	
🏶 Debug 🛛 🖻 main.c 🛛 🗖 mss_main.c 🗖 dss_main.c		Disconnect Target	Ctrl+Alt+D
# @ demo_tc_awr294x.ccxml [Code Composer Studio - Devi		Enable Global Breakpoints	
🔎 Texas Instruments XDS110 USB Debug Probe_0/Cort		Enable Halt On Reset Connect	Target
📌 Texas Instruments XDS110 USB Debug Probe_0/Cort		Enable OS Debugging	
📌 Texas Instruments XDS110 USB Debug Probe_0/Cort		Open GEL Files View	
🔎 Texas Instruments XDS110 USB Debug Probe_0/Cort		Code Analysis	
📌 Texas Instruments XDS110 USB Debug Probe 0/C66		Code Analysis	
······································		SoC Analysis	>
	×	Hide core(s)	
		Show all cores	
		Group core(s)	

8. After connecting to either Cortex_R5_0 or C66xx_DSP core, **perform a CPU Reset** on each of the cores by selecting them one by one and clicking on "CPU Reset".

	3	- 🏷 🕅 🍕		ð	<u></u>	•	茶	▼ 3	
	э.	🖻 ms:						shift+	· ·
9.		EVM is ready to use. To load						elect 'Load P	rogram'.
		Load Program			170 19	-: 0		Ctrl+	Alt+L
		Reload Program	Load pro	gram c	onto sele	cted co	ore(s)	Ctrl+	Alt+R
	للله	Load Symbols							
	\$\$	Add Symbols							
	Ø	Verify Program							
	*	Remove All Symbols							
	Ø	C:\SDK\ti\\mmw\awı	r294x_mm	w_dem	o_dss.xe	66			

AWR2x44P

• For AWR2x44P, connect to R5_0 and/or M4_1 and/or DSP in the debug window. After connecting, follow Steps 8 and 9 above.

Go back to: CCS development mode



4.3.1. Emulation Pack Update

Refer to the mmWave SDK release notes for the emulation pack version that would be needed within CCS to connect to the EVM. Check if that particular or its later version of "TI Emulators" is available within your CCS installation. If you have an older version on your system, refer to CCS help on how to update software packages within CCS.

4.4. How to run mmWave demo with LVDS-based instrumentation

AWR294X:

Mmwave Studio CLI tool available in TI Resource Explorer should be used to capture raw ADC data and post process captured data. mmwave Studio cli has inbuilt mss application to configure, capture and post process raw ADC data.

4.5. How to Run MMWAVE SDK OOB Demo with Ethernet Streaming Enabled

4.5.1. Setting up

4.5.1.1. Connections

Make the connections as follows:

- 1. Ethernet connection between EVM and multiport router.
- 2. Ethernet connection between multiport router and PC.

4.5.1.2. Software

Ensure the following additional software are installed:

- 1. Python >=v3.7.4 (https://www.python.org/downloads/release/python-374/) with the following libraries:
 - a. socket: for socket programming in Python
 - b. struct. aids processing of captured data
 - c. ctypes: aids processing of captured data


4.5.1.3. Capturing Detected Object Data over Ethernet using OOB Demo

The pre-built binaries of the OOB Demo of MMWAVE SDK have ethernet streaming enabled (AWR294x TDM Processing chain, AWR2x44P DDM Processing chain).

- 1. Load the demo and run it.
- 2. Ensure that the demo is running and connect to the MMWAVE Demo Visualizer. The visualizer should show "Hardware Connected." like shown in the following figure (note: COM Ports might be different),

🖻 🗢 🔺 COM14:115200, COM15:892857 Hardware Connected. AWR294X

- 3. Perform the following steps in the demo visualizer to obtain the IP address of the EVM (Default is assigned with static IP 192.168.1.200). The figure also shows the steps:
 - a. Open the "Status" pane (2) in the "Plots" tab in the visualizer (1).
 - b. In the text box, type queryLocallp (3) and click on "Send Command" (4). This will query the IP address obtained by the EVM.




c. The local IP address should be displayed in the console window.

```
mmwDemo:/>queryLocalIp
Local IP is: 192.168.1.200
Done
```

🦆 Texas Instruments

4. Open a command prompt and type the command *ipconfig* to get the IP address of the newly configured network. We call this the "RemoteIP". Note the IPv4 address of the network as shown in the following figure. Ensure that the IP address is in the same subnet as the one obtained in step 3. If that is not true, follow step 5. Else, skip step 5.



- 5. Configure a static IP address for the PC. Ensure that the configured IP address is in the same subnet as the EVM IP address obtained in step 3. To do this, perform the following (these steps are given for Windows 10, the user may check how to configure a static IP address for their own system):
 - a. Go to Control Panel\Network and Internet\Network Connections. You should see the Ethernet connection that you have made between the multiport router and the PC being listed in the connections list. Right click on the connection and click on "Properties".

🛬 « Network and Internet 🤉	Network	Connections	~	5
Disable this network device	Diagno	se this connection	Rename thi	s coi
et .		Ethernet 2 Unidentified network		
Ethernet Connection (7) I2	•	Disable		<u>. </u>
		Status		
		Diagnose		
	•	Bridge Connections		
		Create Shortcut		
	•	Delete		
	•	Rename		
	•	Properties		

b. After the network properties pane opens, click on "Internet Protocol Version 4 (TCP/IPv4)" (1) and give the desired IP address (2). Ensure that this address and the EVM IP are in the same subnet.

Ethernet	3 Properties	Internet Protocol Version 4 (TCP/IPv4) Properties	×
Networking	Sharing	General	
Connect us	sing: .INK Gigabit Ethemet USB A	You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.	
		Obtain an IP address automatically	
This conne	ction uses the following item	Use the following IP address:	
🗹 👰 Fi	lient for Microsoft Networks le and Printer Sharing for Mic	IP address: 2 192 . 168 . 1 . 10 Subnet mask: 255 . 255 . 0	
🗹 👮 Q	pcap Packet Driver (NPCAP oS Packet Scheduker 1 temet Protocol Version 4 (TC	Default gateway:	
🗆 💶 M	icrosoft Network Adapter Mu licrosoft LLDP Protocol Drive	Obtain DNS server address automatically @ Use the following DNS server addresses: Preferred DNS server:	
Insti Descripti	Crimitorum	Alternate DNS server:	
wide are	ssion Control Protocol/Intem a network protocol that prov liverse interconnected netwo	Validate settings upon exit Advanced	
		OK Cance	1

c. Click on OK.

- 6. Open the python script "tcpserver.py" present in mmwave_mcuplus_sdk_<ver>\tildemo\utils. Change the HOST IP address configured in step 5 and configure it in the line "HOST =" in the Python file. For example, if the remote IP configured in step 5 is 192.168.1.10, modify the tcpserver.py file to say "HOST = '192.168.1.10'.
- 7. Execute tcpserver.py.
- 8. In the profile configuration (.cfg) file profile_<>_enet.cfg present in mmwave_mcuplus_sdk_<ver>\tildemo\<platform>\mmw\profiles folder, modify the enetStreamCfg command before sensorStart as follows enetStreamCfg <isEnabled> <remotelpD> <remotelpC> <remotelpB>



<remotelpA>, where the IP address of the PC is D.C.B.A. For example, enetStreamCfg 1 192 168 1 10, and send this configuration file out through the visualizer.

- 9. Use tcpdump / wireshark to capture the ethernet data and save it as pcap file.
- 10. Captured pcap file can be parsed to obtain the csv file using the python script available at
- mmwave_mcuplus_sdk_<ver>\ti\demo\parser_scripts\data_parser_awr2x44x.py.
 You should be able to see detected objects data in the generated csv file.

x	У	Z	velocity
0.7875	1.0119	-0.3394	0
-1.1606	0.6421	-0.0071	0
-0.6839	1.1209	-0.1875	0
-0.0622	1.3243	-0.0409	0
0.1243	2.6257	0.3569	0
1.6165	1.9379	0.8177	0
-2.2383	0.9601	-1.0514	0
	2 -1.1606 3 -0.6839 -0.0622 5 0.1243 5 1.6165	-1.1606 0.6421 -0.6839 1.1209 -0.0622 1.3243 0.1243 2.6257 1.6165 1.9379	-1.1606 0.6421 -0.0071 -0.6839 1.1209 -0.1875 -0.0622 1.3243 -0.0409 0.1243 2.6257 0.3569 1.6165 1.9379 0.8177


(i) tcpserver.py

After expected data is captured, stop the tcpserver.py execution to flush out any remaining packets. Users can modify the server and data parser script to serve their own needs.

4.6. How to test AWR2544 OOB demo with integrated PTP stack during development

4.6.1. Hardware Setup

- Connect two EVMs with CAT6 ethernet cable.
- Flash PTP stack example available at mcu_plus_sdk_awr2544_<ver>\examples\networking\tsn\gptp_cpsw_app\awr2544-evm\ on one EVM -PTP controller.
- Flash OOB demo available at mmwave_mcuplus_sdk_<ver>\ti\demo\awr2544\mmw on second EVM PTP peripheral.
- To probe GenF signal generated by the PTP peripheral EVM, few hardware changes are required.
 - Populate R236 resistor (10 ohm).
 - $^\circ~$ After populating R236, probe GenF signal from pin 33 of J19.



4.6.2. Software

- Load cfg file (mmwave_mcuplus_sdk_<ver>
- \ti\demo\awr2544\mmw\profiles\profile_3d_3Azim_1ElevTx_DDM_awr2544_2Xmode_cpts_trigger.cfg) via USER UART port on the PTP peripheral EVM.
- Below is a snapshot of GenF signal and frame start signal captured on PTP peripheral EVM.

50 C.		GenF0 (A17)			24.999	1902 ms	Duty: 50 % Free: 20 Hz width*: 40 Hz
D1 C.	Frame Start	t Signal				49.999842 ms	

A By default, frame start signal is not enabled in the software and on the hardware. To enable it on the hardware, user can populate R5 (0 ohm) resistor, and capture frame start signal at pin 33 of J7. User can configure A9 pin for PAD functionality 7.

To enable GenF signal on PTP controller EVM, follow below steps:


MAC Port Config		~	×	
CPTS Configuration		~	×	
Board Config		~	~	
Pinmux config		^	^	
CPSW pinmux		^		
1/1 added 💿		⊕ ADD	a la	
CPSW pinmux 0		ō		
RMII/RGMII	RGMII	*		
CPTS	CPTS0	- 6	à	
☑ Signals †	Pins	Pull Up/Down Slew Rate Pull Up 👻 High 👻		
CPTS0_TS_GENF0	Any 👻	Pull D 👻 High 👻		
CPTS0_TS_GENF1	Any 👻	Pull D 👻 High 👻		
CPTS0_TS_GENF2	Any 👻	Pull D 👻 High 👻	r	
CPTS0_TS_SYNC	Any 👻	Pull D 👻 High 👻	r	
MDIO	Any(MDIO0)	Ψ		
✓ Signals †↓	Pins	Pull Up/Down Slew Rate Pull Up 👻 High 👻		
CLK(MDIO_CLK)	Any(PAD_CN/U2) -	Pull D 👻 High 👻	r	
DATA(MDIO_DATA)	Any(PAD_CM/T2) -	Pull D High -	r	

4.7. How to use Custom Flash Device

This section of document provides instructions to be followed for configuring flash device other than the default flash part populated on EVM (Gigabit device GD25B64).

A These steps are provided for modifying SDK demo application to work with user flash device.


- Get flash device attributes like Manufacturer ID, Device ID, flash size, OP codes and other details from the datasheet of flash device. Refer to flashname.json file at mmwave_mcuplus_sdk_<ver>/mcu_plus_sdk_<platform>_<ver>/source/board/.meta/flash/schema for understanding JSON file format. Few example JSON files created for WINBOND (W25Q32JVSQ) flash and ISSI (IS25LP032D) flash are available at mmwave_mcuplus_sdk_<ver>/mmwave_mcuplus_sdk_<platform>_<ver>/tools/custom_flash. Alternatively, the different flash configurations can be changed manually in the sysconfig tool.
- 2. Update sysconfig files of sbl_uart_uniflash at mmwave_mcuplus_sdk_<ver>/mmwave_mcuplus_sdk_<platform>_<ver>/examples/drivers/boot /sbl_uart_uniflash/awr294x-evm/r5fss0-0_nortos/example.syscfg, sbl_qspi at mmwave_mcuplus_sdk_<ver>/mmwave_mcuplus_sdk_<platform>_<ver>/examples/drivers/boot/sbl_qspi/awr294x-evm/r5fss0-0_nortos/example.syscfg and mss.syscfg file of the demo application at mmwave_mcuplus_sdk_<ver>/mmwave_mcuplus_sdk_<ver>/ti/demo/<platform>/mmw/mss/mss.syscfg by changing to custom flash and update the flash name. Now load the new JSON file created. These changes will be reflected in the ti_board_open_close.c file that is generated by the sysconfig tool.



🦊 Texas Instruments



- 3. Rebuild the sbl_uart_uniflash example, sbl_qspi example and the Demo application. Refer to Building Demo for detailed procedure. Flash the .appimages by following How to flash an image onto mmWave EVM.
- 4. Switch to QSPI boot mode and verify if the image is flashed successfully by connecting to visualizer.



4.8. How to optimize MSS_L2 memory for SBL over ethernet example (sbl_qspi_enet)

Follow this section to optimize the SBL QSPI Enet example for conservation of MSS_L2 memory. When requiring to flash applications over ethernet that require large MSS_L2 memory, this optimization will help in storing the ethernet libraries of the sbl_qspi_enet example outside of memory region MSS_L2 so as to help in achieving increased memory for the application image by reducing the memory consumed by the sbl_qspi_enet example.

The aim of this section is to fit the necessary QSPI libraries in the beginning of MSS_L2 memory region (of size 0x20000) in release build.

- 1. Make a backup of the linker.cmd file of sbl_qspi_enet example, at mcu_plus_sdk_<platform>_<version>/examples/drivers/boot/sbl_qspi_enet /awr294x-evm/r5fss0-0_nortos/ti-arm-clang/
- 2. Replace the existing linker.cmd file with the optimized linker.cmd file provided in the path mmwave_mcuplus_sdk_<version>/tools/sbl_enet/
- 3. Build the sbl_qspi_enet application image under release mode.

This is done so that the ethernet libraries placed after 0x20000 in MSS_L2 can be overwritten by the application as this ethernet libraries are not used during loading of application from flash after the ethernet transfer is completed.

4.9. How to erase flash memory

Follow this subsection to erase flash memory using UART Uniflash tool.

- 1. Refer How to flash an image onto mmWave EVM for tool requirements and EVM setup details.
- 2. This procedure to erase flash memory has two steps.
 - a. Flash programmer binary present at mmwave_mcuplus_sdk_<version>/tools/<platform> should be flashed
 - b. Erase operation command which takes two arguments, the flash offset from which the erase operation begins and size of flash to be erased in bytes should be sent
- 3. Modify the flash offset and flash size in erase_sflash.cfg file at mmwave_mcuplus_sdk_<version>/tools/<platform> if required.
- 4. Set the device in UART boot mode. Open a command prompt and run the below commands.

Erase flash

@REM Change the path/version cd C:\ti\mmwave_mcuplus_sdk_<version>\scripts\windows @REM Remember to change the variable "MMWAVE_SDK_DEVICE" in this file! setenv.bat @REM set platform to AWR294x cd %MMWAVE_SDK_INSTALL_PATH%/tools/cplatform> @REM Step: Command to erase the flash @REM The <COM Port> can be, for example, COM25 @REM change sFlash erase size in erase_sflash.cfg python %MCU_PLUS_AWR294X_INSTALL_PATH%/tools/boot/uart_uniflash.py -p <COM Port> --cfg=erase_sflash.cfg



4.10. How to configure Automotive PHY

AWR2544 EVM is populated with DP83867 (Industrial PHY) and DP83TG720S (Automotive PHY) devices. By default Industrial PHY is enabled. To enable Automotive phy below hardware and software modifications are to be done:

Hardware:

- Populate the following resistors: R11, R240, R239, R238, R237, R245, R234, R74, R230, R225, R178, R100, R96, R247, R249 This modification enables the connection of RX, TX and MDIO, MDC lines between AWR2544 SOC and Automotive PHY.
 Remove the following resistors: R98, R101, R103, R105, R121, R122, R195, R290, R325, R336, R338, R339, R369, R413 This modification disables the connection of RX, TX and MDIO, MDC lines between AWR2544 SOC and Industrial PHY.

Software:

User can enable AUTO PHY configuration through sysconfig tool.

Open sysconfig in gui mode for any of the ethernet example and select "Auto Phy (dp83tg720)" from "TI NETWORKING -> ENET (CPSW) -> Board Config -> Phy Variant"

ILE ABOUT							RESTAR
\Xi Type Filter Text 🗙 🕊	\leftrightarrow \rightarrow Software \mapsto Enet (CPSW)					() <> @	-0 i
✓ TI DRIVER PORTING LAYER Clack 1/1 ♥ ⊕ Debug Log 1/1 ♥ ⊕ MPU ARMV7 6/16 ♥ ⊕	Enet (CPSW) (1 Added) () CONFIG_ENET_CPSW0	⊕ ADD I	FREMOVE ALL	 Problems There are no problems in the cur 	rent design.		" ×
TIMER ①	Name	CONFIG_ENET_CPSW0		< > Generated Files			~" ×
V TI DRIVERS (17) ADCBUF (+) BOOTLOADER (+)	System integration config		^	Filter: all			* X
CBUFF	DMA channel config		^	File name	Category	Include in buik	ld
CRC 🕀				ti_dpl_config.c	TI Driver Porting Layer (DPL)	-	
EDMA 1/3 🤮 🕀 EPWM 🕀	Packet Pool Config		^	ti_dpl_config.h	TI Driver Porting Layer (DPL)	-	
ESM	LWIP Interface config		^	ti_drivers_config.c	TI Drivers	-	•
GPIO 🕀	ALE Config		^	ti_drivers_config.h	TI Drivers	-	
HWA	ALE Colling			ti_drivers_open_close.c	TI Drivers		8
IPC MIBSPI	MDIO Config		^	ti_drivers_open_close.h	TI Drivers	-	8
QSPI	Host Port Config		^	ti_pinmux_config.c	TI Drivers	-	8
RTI 🕀				ti_power_clock_config.c	TI Drivers	-	
UART 1/2 ♥ ⊕ WDT ⊕	MAC Port Config		^	ti_board_config.c	TI Board Drivers	-	8
 TI BOARD DRIVERS (3) EEPROM	CPTS Configuration		^	ti_board_config.h	TI Board Drivers	-	
FLASH 🕀	Board Config		~	ti_board_open_close.c	TI Board Drivers		8
LED	Custom Board	_		ti_board_open_close.h	TI Board Drivers		8
Enet (CPSW) 1 🥑 🕀	Phy Variant	Auto Phy (dp83tg720)		ti_enet_config.c	TI Networking	-	8
	Port 1 PHY Configuration	Industrial Phy (dp83867) Auto Phy (dp83tg720)	^	ti_enet_config.h	TI Networking	-	
		Auto r ny (upostg/20)		ti_enet_open_close.c	TI Networking	-	8
	Pinmux config		^	ti_enet_open_close.h	TI Networking	-	

Figure: Auto PHY selection in sysconfig

Development Testing Procedure:

Scatter gather example has been tested using DP83TG720 Media converter EVM as shown in below.

Media converter EVM Link: https://www.ti.com/tool/DP83TG720EVM-MC

Cable used to connect AWR2544 and DP83TG720 Media converter: 1000BASE-T1 CABLE (MATENET)




Figure: Auto PHY test setup



4.10.1. OOB demo changes for Auto PHY with osc_clk_out_eth

To switch the Auto PHY clock source from the default external 25MHz XTAL to osc_clk_out_eth in OOB demo, following changes are required:

Hardware (AWR2544EVM):

- 1. Disconnect default 25MHz XTAL (Y5) connected to AUTO_PHY (DP83TG720S)
- 2. Populate Zero Ohm resistor R241
- Disconnect C121
- 4. Replace R242 with Zero Ohm resistor

Software:

- Modify profile.cfg file to set <ethOscClkEn> <driveStrength> arguments of "channelCfg" CLI command. Refer section 3.7 Configuration file format for more details.
- 2. Modify sysconfig file to choose Auto PHY. Refer Auto PHY sysconfig for further details.

4.11. How to enable BSS Logger in OOB Demo (AWR2544)

BSS firmware generates log during its execution and this log can be used for debug purpose in case of any failure or assert from BSS. By default this log feature is disabled but can be enabled during the BSS bootup sequence. This BSS log can be navigated to specified memory location of device and from there it can stream out of device using any interface (e.g. Ethernet).

In the SDK, we provide an option to stream this BSS log with the assistance of MSS via Ethernet and can be captured on the other end (e.g. on PC). Since BSS log is encrypted and can be parsed only by TI, customer needs to capture this log (only in case of BSS failure) and share with TI (via E2E). TI engineer will parse this log and assist customer to find out the cause of BSS FW failure.

Following are the required changes to generate OOB Demo binary with BSS logger enabled:

SBL changes:

The BSS firmware keeps the debug logger disabled by default. BSS logger feature can be enabled explicitly by configuring RSS_CR4_BOOT_INFO_REG5 and RSS_CR4_BOOT_INFO_REG6 before un-halting BSS core. The following registers need to be configured in SOC_rcmPopulateBSSControl API in mmwave_mcuplus_sdk_<version>/mcu_plus_sdk_awr2544_<version>/source/drivers/soc /awr2544/soc.c

RSS_CR4_BOOT_INFO_REG5[2:0] = 0x2

RSS_CR4_BOOT_INFO_REG6[31:0] = MSS L2 buffer start address allocated for BSS data logging. Valid range: 0xC0200000 - 0xC02EF7FC

- Linker file (mmwave mcuplus sdk <version>/mmwave mcuplus sdk <version>/ti/platform/awr2544/r5f linker.cmd): Allocate 2KB MSS_L2 memory from the start address configured in SBL as reserved memory in linker file.
- Enable the feature in OOB demo:

By default, the BSS Logger feature is disabled in the OOB Demo. To enable the feature, BSS_LOGGER macro has to be defined in makefile (<u>mmwave_mcuplus_sdk_<version>/mmwave_mcuplus_sdk_<version>/ti/demo/awr2544/mmw/mmw_mss.mak</u>). After these changes are done rebuilt OOB demo application

If BSS Logger is enabled, only the logger data will be transmitted over ethernet interface. Compressed 1D-FFT data will not be transmitted.

Data capture and binary file generation:

tcpdump command can be issued to capture ethernet packets. Refer Data Collection section for more details. It is recommended to capture packets on Linux OS to reduce packet drop.

The captured pcap file can be converted to .bin file by running the bssLogger.py script provided at: mmwave_mcuplus_sdk_<version>/immwave_mcuplus_sdk_<version>/ti/demo/parser_scripts. For more details, refer header section documentation in bssLogger.py file.

4.12. How to migrate examples from package to package (AWR2x44P)

Default configurations for all the SDK examples are for AWR2E44P (LOP). Refer mmwave_mcuplus_sdk_<version> /mcu_plus_sdk_awr2x44p_<version>/docs/api_guide_awr2x44p/SOC_MIGRATION.html for migrating to AWR2944P (ETS). To migrate Out Of Box demo (mmw_ddm), follow below procedure.

- 1. Update below SysConfig file headers from LOP to ETS
 - a. mmwave_mcuplus_sdk_<version>/mmwave_mcuplus_sdk_<version>/ti/demo/awr2x44P/mmw_ddm/mss/mss.syscfg
 b. mmwave_mcuplus_sdk_<version>/mmwave_mcuplus_sdk_<version>/ti/demo/awr2x44P/mmw_ddm/dss_cm4/dss_cm4.syscfg
 - c. mmwave_mcuplus_sdk_<version>/mmwave_mcuplus_sdk_<version>/ti/demo/awr2x44P/mmw_ddm/dss/dss.syscfg
- 2. Modify PACKAGE_TYPE variable to ETS in mmwave_mcuplus_sdk_<version>/mmwave_mcuplus_sdk_<version>/ti/common /mmwave_sdk_awr2x44P.mak
- 3. For newly created syscfg files which have @v2CliArgs in the header, modify the package from "FCCSP (AMX)" to "FCCSP (ALT)"
- 4. Refer to section Building Demo and rebuild demo.



4.13. How to enable using the same application after R5F core reset

The application fails after reset because while switching back to the same application, as the device only has RAM the .data section of the application is already modified, which causes some of the status bits to not maintain its integrity.

The steps to modify this is make following changes in mcu_plus_sdk_<device>_<version>\source\kernel\nortos\dpl\r5\boot_armv7r.c :

boot_armv7r.c

```
#include <stdint.h>
#include <string.h>
extern uint32_t __BSS_START;
extern uint32_t __BSS_END;
extern uint32_t __LOAD_DATA_START;
extern uint32_t __LOAD_DATA_END;
extern uint32_t ___RUN_DATA_START;
int _system_pre_init()
{
        uint32_t bss_size = ((uintptr_t)&__BSS_END - (uintptr_t)&__BSS_START);
        memset((void*)&___BSS_START, 0x00, bss_size);
        uint32_t data_size = ((uintptr_t)&_LOAD_DATA_END - (uintptr_t)&_LOAD_DATA_START);
        memcpy((void*)&__RUN_DATA_START, (void*)&__LOAD_DATA_START, data_size);
        return 1;
}
#if !defined (_clang_)
void __TI_auto_init()
}
#endif
```

Then run these commands in the folder mcu_plus_sdk_<device>_<version> :

Rebuilding the libraries

```
gmake -s -f makefile.<device> nortos_r5f.ti-arm-clang
gmake -s -f makefile.<device> freertos_r5f.ti-arm-clang
```

After that in the application linked command make similar modifications (have used a separate memory section to copy and run the application to retain the original .data section integrity) :

Linker Command File

```
GROUP {
    .data: {} palign(8) /* This is where initialized globals and static go */
    LOAD_START(__LOAD_DATA_START)
    LOAD_END(__LOAD_DATA_END)
    RUN_START(__RUN_DATA_START)
} load > MSS_L23, run > MSS_L2
/* when using multi-core application's i.e more than one R5F active, make sure
 * this memory does not overlap with other R5F's
 */
MSS_L23 : ORIGIN = 0x10260000 , LENGTH = 0x10000
MSS_L2 : ORIGIN = 0x10270000 , LENGTH = 0x30000
```

4.14. Developing using SDK

4.14.1. Build Instructions

Follow the mmwave_mcuplus_sdk_release_notes instructions to install the mmwave_mcuplus_sdk in your development environment (windows or linux). All the tools needed for mmwave_mcuplus_sdk build are installed as part of mmwave_mcuplus_sdk installer.



4.14.2. Setting up build environment

4.14.2.1. Windows

1. Create command prompt at mmwave_mcuplus_sdk_<ver> install path>/scripts/windows folder. Under this folder you should see a setenv.bat file that has all the tools environment variables set automatically based on the installation folder. Review this file and change the few build variables shown below (if needed) and save the file. Please note that the rest of the environment variables should not be modified if the standard installation process was followed.

Build variables that can be modified (if needed) in setenv.bat

A If you see the following line in the setenv.bat file then most probably the wrong installer was used (Linux installation being compiled under Windows)

set MMWAVE_SDK_TOOLS_INSTALL_PATH=__MMWAVE_SDK_TOOLS_INSTALL_PATH__

In a proper installation the __MMWAVE_SDK_TOOLS_INSTALL_PATH__ would have been replaced with the actual installation folder path

2. Run setenv.bat as shown below.

Run setenv.bat	
setenv.bat	

This should not give errors and should print the message "mmWave Build Environment Configured". The build environment is now setup.

4.14.2.2. Linux

 Open a terminal and cd to mmwave_mcuplus_sdk_<ver> install path>/scripts/unix. Under this folder you should see a setenv.sh file that has all the tools environment variables set automatically based on the installation folder. Review this file and change the few build variables shown below (if needed) and save the file. Please note that the rest of the environment variables should not be modified if the standard installation process was followed.

Build variables that can be modified (if needed) in setenv.sh

If download via CCS is needed, set below define to yes else no

- # yes: Out file created can be loaded using CCS.
- # Binary file created can be used to flash
- $\ensuremath{\texttt{\#}}$ no: Out file created cannot be loaded using CCS.
- # Binary file created can be used to flash

(additional features: write-protect of TCMA, etc)

export DOWNLOAD_FROM_CCS=yes

🠌 Texas Instruments

If you see the following line in the setenv.sh file then most probably the wrong installer was used (Windows installation being compiled under Linux)

export MMWAVE_SDK_TOOLS_INSTALL_PATH=__MMWAVE_SDK_TOOLS_INSTALL_PATH__

In a proper installation the __MMWAVE_SDK_TOOLS_INSTALL_PATH__ would have been replaced with the actual installation folder path

2. Assuming build is on a Linux 64bit machine, install modules that allows Linux 32bit binaries to run. This is needed for Image Creator binaries

sudo dpkg --add-architecture i386

3. Install build-essential package for 'make'. Install mono-complete package as one of the Image Creator binaries (out2rprc.exe) is a windows executable that needs mono to run in Linux environment

```
sudo apt-get install build-essential
sudo apt-get --assume-yes install mono-complete
```

4. Run setenv.sh as shown below.

Run setenv.sh	
source ./setenv.sh	

This should not give errors and should print the message "mmWave Build Environment Configured". The build environment is now setup.

4.14.3. Building demo

To clean build a demo, first make sure that the environment is setup as detailed in earlier section. Then run the following commands. On successful execution of the commands, the output is <demo>.xe* which can be used to load the image via CCS and <demo>.bin which can be used as the binary in the steps mentioned in section "How to flash an image onto mmWave EVM".

4.14.3.1. Building demo in Windows

```
      Building demo in windows

      REM Fill <device type> with appropriate device that supports demo in a particular release

      cd %MMWAVE_SDK_INSTALL_PATH%/ti/demo/<device type>/mmw

      REM Clean and build

      gmake clean

      gmake all

      REM For example to build the mmw demo

      cd %MMWAVE_SDK_INSTALL_PATH%/ti/demo/%MMWAVE_SDK_DEVICE%/mmw

      gmake clean

      gmake clean

      gmake clean

      gmake dll

      REM For example to build the mmw demo

      cd %MMWAVE_SDK_INSTALL_PATH%/ti/demo/%MMWAVE_SDK_DEVICE%/mmw

      gmake clean

      gmake all

      REM This will create <mmwave_sdk_device>_mmw_demo_mss.xer5f, <mmwave_sdk_device>_mmw_demo_dss.xe66 &

      <mmwave_sdk_device>_mmw_demo.appimage binaries

      RUMWAVE_SDK_INSTALL_PATH%/ti/demo/<mmwave_sdk_device>/mmw folder
```

4.14.3.2. Building demo in Linux

Building demo in linux

Fill <device type> with appropriate device that supports demo in a particular release
cd \${MMWAVE_SDK_INSTALL_PATH}/ti/demo/<device type>/mmw

Clean and build
make clean



```
make all
# Incremental build
make all
# For example to build the mmw demo
cd ${MMWAVE_SDK_INSTALL_PATH}/ti/demo/${MMWAVE_SDK_DEVICE}/mmw
make clean
make all
# This will create <mmwave_sdk_device>_mmw_demo_mss<Proc_Chain>.xer5f,
<mmwave_sdk_device>_mmw_demo_dss<Proc_Chain>.xe66 & <mmwave_sdk_device>_mmw_demo<Proc_Chain>.appimage
binaries
# under ${MMWAVE_SDK_INSTALL_PATH}/ti/demo/${MMWAVE_SDK_DEVICE}/mmw folder
```

Each demo has dependency on various drivers and control components. The libraries for those components need to be available in their respective lib folders for the demo to build successfully.

4.14.4. Advanced build

/!\

The mmwave sdk package includes all the necessary libraries and hence there should be no need to rebuild the driver, algorithms or control component libraries. In case a modification has been made to any of these modules then the following section details how to build these components.

4.14.4.1. Building datapath/control/utils components

To clean build control, datapath or utils components and unit tests, first make sure that the environment is setup as detailed in earlier section. Then run the following commands

```
Building component in windows
cd %MMWAVE_SDK_INSTALL_PATH%/ti/<component_path_under_ti>
gmake clean
gmake all
REM The command will create the following file
       lib<component>_<device_type>.aer5f library under ti/<component_path_under_ti>/lib folder
REM
REM If the module has unit test, it will also createcompRangeBias REM
                                                                          <device_type>_<component>_mss.
xer5f unit test binary under ti/<component_path_under_ti>/test/<device_type> folder
REM If the device has a DSP and the driver supports DSP then the command will also create
REM
        lib<component>_<device_type>.ae66 library for DSS under ti/<component_path_under_ti>/lib folder
REM If the module has unit test, it will also create
        <device_type>_<component>_dss.xe66 unit test binary for DSS under ti/<component_path_under_ti>/test
REM
/<device_type> folder
REM Above paths are relative to %MMWAVE_SDK_INSTALL_PATH%/
REM For example to build the dpm lib and unit test
cd %MMWAVE_SDK_INSTALL_PATH%/ti/control/dpm
gmake clean
qmake all
REM For example to build the mmwavelink lib (it does not have a unit test)
cd %MMWAVE_SDK_INSTALL_PATH%/ti/control/mmwavelink
qmake clean
gmake all
REM For example to build the acaproc dpu lib and unit test
cd %MMWAVE_SDK_INSTALL_PATH%/ti/datapath/dpc/dpu/aoaproc
gmake clean
qmake all
REM Additional build options for each component can be found by invoking make help
gmake help
```

Building component in linux



```
cd ${MMWAVE_SDK_INSTALL_PATH}/ti/<component_path_under_ti>
make clean
make all
# The command will create the following file
     lib<component>_<device_type>.aer5f library under ti/<component_path_under_ti>/lib folder
#
# If the module has unit test, it will also create
#
     <device_type>_<component>_mss.xer5f unit test binary under ti/<component_path_under_ti>/test
/<device_type> folder
# If the device has a DSP and the driver supports DSP then the command will also create
      lib<component>_<device_type>.ae66 library for DSS under ti/<component_path_under_ti>/lib folder
#
# If the module has unit test, it will also create
     <device_type>_<component>_dss.xe66 unit test binary for DSS under ti/<component_path_under_ti>/test
#
/<device_type> folder
# Above paths are relative to ${MMWAVE_SDK_INSTALL_PATH}/
# For example to build the dpm lib and unit tests
cd ${MMWAVE_SDK_INSTALL_PATH}/ti/control/dpm
make clean
make all
# For example to build the mmwavelink lib
cd ${MMWAVE_SDK_INSTALL_PATH}/ti/control/mmwavelink
make clean
make all
# For example to build the acaproc dpu lib and unit test
cd ${MMWAVE_SDK_INSTALL_PATH}/ti/datapath/dpc/dpu/aoaproc
make clean
make all
# Additional build options for each component can be found by invoking make help
gmake help
```

example output of make help for dpm

example output of make help for demo

* Makefile Targets for the DPM
clean -> Clean out all the objects
lib -> Build the Driver only
libClean -> Clean the Driver Library only
test -> Build the applicable unit tests
testClean -> Clean the unit tests

* Makefile Targets for the DEMO all -> Builds the mmw Demo (both MSS and DSS binaries) and appimage -> Cleans the mmw Demo (both MSS and DSS binaries) and appimage clean -> Builds the MSS binary for the mmw Demo mssDemo mssDemoClean -> Cleans the MSS binary for mmw Demo dssDemo -> Builds the DSS binary for the mmw Demo dssDemoClean -> Cleans the DSS binary for mmw Demo bin -> Builds the appimage for the demo binClean -> Cleans the appimage for the demo -> Builds the mmw Demo (both MSS and DSS binaries) but not the appimage mmwDemo mmwDemoClean -> Builds the mmw Demo (both MSS and DSS binaries) *******

Please note that not all components are supported for all devices and not all components have unit tests. List of supported components for each device is listed in the Release Notes.



/!∖

4.14.4.2. "Error on warning" compiler and linker setting

By default, the SDK build uses "-emit_warnings_as_errors" option to help users identify certain common mistakes in code that are flagged as warning but could lead to unexpected results. If user desires to disable this feature, then please set the flag MMWAVE_DISABLE_WARNINGS_AS_ERRORS to 1 in the above mentioned setenv.bat or setenv.sh and invoke that file again to update the build environment. User can also compile with the "MMWAVE_DISABLE_WARNINGS_AS_ERRORS=1" flag (for example, *gmake all MMWAVE_DISABLE_WARNINGS_AS_ERRORS=1*).

5. MMWAVE SDK deep dive


5.1. System Deployment

A typical mmWave application would perform these operations:

- Control and monitoring of RF front-end through mmaveLink
- Transport of external communications through standard peripherals
- Some radar data processing using DSP


Typical customer deployment for mmWave sensor is shown in the figure below:

- a. The appimage (MSS + DSS code) is downloaded from the serial flash memory attached to the mmWave device (via QSPI)
- b. Optional high level control from remote entity
- c. Sends low speed data output (objects detected) to remote entity





The above deployment can be realized using the mmWave SDK and it components in a layered structure as shown below:






5.2. Typical mmWave Radar Processing Chain


Following figure shows a typical mmWave Radar processing chain that accepts ADC data as input from mmWave Front End and then performs Range and Doppler FFT followed by non-coherent detection using CFAR. Finally angle is estimated using 3D FFT and the detected points represent the point cloud data. The point cloud data can then be post processed using higher layer algorithms such as Clustering, Tracking, Classification to represent real world targets.






5.2.1.1.1. Figure 6: Typical mmWave radar processing chain

Using mmWave SDK the above chain could be realized as shown in the following figure for devices with HWA as processing nodes. In the following figure, green arrow shows the control path and red arrow shows the data path. Blue blocks are mmWave SDK components and yellow blocks are custom application code. The hierarchy of software flow/calls is shown with embedding boxes. Depending on the complexity of the higher algorithms (such as clustering, tracking, etc) and their memory/mips consumption, they can either be partially realized inside the mmWave device or would run entirely on the external processor.




AWR294X OOB Demo



5.2.1.1.2. Figure 7: Typical mmWave radar processing chain using mmWave SDK components

Each of the mmWave device offers different processing nodes to realize the mmwave processing. AWR294X has HWA+DSP(C66x). For devices with multiple processing nodes, the mmWave detection processing chain can exploit them as needed for performance and scalable reasons. Shown below is an example of detection processing chain that uses various data processing units (DPUs) to perform the typical mmwave processing up to the point cloud. The mmwave data representation in mmWave device memory forms an interface layer between the various DPUs. Each DPU can be realized independently using HWA or DSP processing node - the choice is either driven by usecase or availability of that processing node on a given mmWave device. The various mmWave SDK components shown below are described in the section "mmWave SDK - TI components" below.



5.2.1.1.4. Figure 8: Scalable data processing chain using mmWave SDK

Please refer to the code and documentation inside the mmwave_mcuplus_sdk_<ver>\ti\demo\<platform>\mmw folder for more details and example code on how this chain is realized using mmWave SDK components.


What must be noted is that in SDK 4.1.0 datapath processing, is done using HWA running on MSS or DSS, not DSP alone (without using the HWA). Also, the ADC data over the csirx can either be directly put into the HWA memory (as is supported by the current demo), or can be first placed into an intermediate memory and then routed to the HWA using the EDMA or transferred out of the device (not supported by the current demo).

5.3. Typical Programming Sequence

The above processing chain can be split into two distinct blocks: RF control path and data path.

5.3.1. RF Control Path

The control path in the above processing chain is depicted by the following blocks.




5.3.1.1.1. Figure 9: Typical mmWave radar control flow

Following set of figures shows how an application programming sequence would look like for setting up the typical control path - init, config, start. This is a high level diagram simplified to highlight the main software APIs and may not show all the processing elements and call flow. For an example implementation of this call flow, please refer to the code and documentation inside the mmwave_mcuplus_sdk_<ver>\ti\demo\<platform>\mmw folder.


5.3.1.2. Single RF Control (MSSRADARSS or DSSRADARSS)

In this scenario, the RF control path runs on either Master subsystem (Cortex-R5F) or DSP subsytem (C66x) and the application can simply call the mmwave APIs in the SDK in isolation mode to realize most of the functionality.











5.3.1.2.2. Figure 11: mmWave Isolation mode: Detailed Control Flow (Config sequence)




5.3.1.2.3. Figure 12: mmWave Isolation mode: Detailed Control Flow (start sequence)

5.3.1.3. Co-operative RF control ((MSS+DSS)<->RADARSS)


In this scenario the control path can runs in "co-operative" mode where RF control APIs can be interchangeably called by either domains (but the sequence of API needs to be maintained). One such deployment could have the RF init and config initiated by the MSS and the start is initiated by the DSS after the data path configuration is complete. In the figures below, control path runs on MSS entirely and MSS is responsible for properly configuring the RADARSS (RF) and DSS (data processing). The mmWave unit tests provide a sample implementation of this co-operative mode.







5.3.1.3.2. Figure 14: mmWave Co-operative Mode: Detailed Control Flow (Config sequence)






5.3.1.3.3. Figure 15: mmWave Co-operative Mode: Detailed Control Flow (Start sequence)

5.3.2. Data Path

The mmwave detection processing can be split into following layers of application code, control/management layer to manipulate the data processing elements, processing chain that ties up individual modules to create a data flow and the low level data processing modules and interfaces.



5.3.2.1.1. Figure 16: Typical mmWave Detection Processing Layers

mmWave devices present a few options on how the data processing layers can be realized using the various control/processing nodes within the device. To allow ease of programming across these deployment types, data path manager (DPM) presents a simplified API structure to the application while hiding the complexity of inter task and inter processor communications. As can be seen from the following figures, application would just need to call the various DPM APIs to control the processing chain (seen as function calls in 'blue' in the ladder diagrams below) and re-act to the outcome of these APIs in the report callback. Data processing chains (DPCs) also present a standardized API structure to the application via DPM and encapsulate the realization of the data flow using data processing units (DPUs) within while presenting simple IOCTL based interface to configure and trigger the data flow. Based on the usecase and the mmWave device hardware capabilities, application can choose from one of the following deployments:

- DPC runs on the same core as control core and the application can control the DPC via DPM in local mode. (See local domain config and processing figures below)
- DPC runs on another core which is different from the controlling core and the application can control the DPC via DPM in remote mode. (See remote domain config and processing figures below)
- DPC is split between two cores and the application can control the DPC via DPM in distributed mode. (See distributed domain config and processing figures below)


The following ladder diagrams show the flow for init, two different forms of config (one initiated on local core and other on remote core), start trigger, chirps/frame events and stop trigger. The choice of MSS and DSS responsibilities are shown as one of the possible examples - their roles can be interchanged as per application needs. These ladder diagrams don't show the corresponding MMWAVE/RF control calls to show independence between RF control and datapath control. Having said that, typical application would follow the following flow for these two form of controls:

- mmWave init and DPM init (order doesn't matter)
- mmWave config and DPM IOCTL for DPC config (order doesn't matter)
- DPM start and then mmWave start (note this is recommended as DPC should be in started state before the real time frame/chirp H/W events
 occur due to mmWave start)
- mmWave stop and then DPM stop (note this is recommended as DPC should be stopped after the real time frame/chirp H/W events stop due to mmWave stop)


5.3.2.2. Data processing flow with local domain control

In this deployment, the core (MSS or DSS) that runs the actual data processing chain (DPC) also controls it. Application calls DPM APIs for init, data processing IOCTL for configuration, start and stop. DPM reports back status from DPC using the application registered report callback function. Application provides an execution context (task) for the DPM/DPC to run. DPC provides back the processing results (point cloud, tracked objects, etc) to the application in this execution context.

🐌 Texas Instruments








5.3.2.2.2. Figure 18: Data processing flow with local domain control (start/chirp/frame/stop)


5.3.2.3. Data processing flow with remote domain control

In this deployment, the data processing chain runs on a chosen data core while the control for it exists on the other core. Application code on control core and data core calls DPM APIs for init and syncing with each other. The control core calls data processing IOCTL for configuration, start and stop APIs. The H/W events are received on the data core. DPM reports back status from DPC using the application registered report callback function on both control and data cores. DPC provides back the processing results (point cloud, tracked objects, etc) to the data core application code which can send the result to the control core using DPM send result API.

🐌 Texas Instruments









5.3.2.3.2. Figure 20: Data processing flow with remote domain control (start/chirp/frame/stop)

5.3.2.4. Distributed Data processing flow and control

In this deployment, the data processing chain is split across cores along with the control. Application code on both cores call DPM APIs for init and syncing with each other. Either core can call data processing IOCTL for configuration, start and stop APIs. DPM reports back status from DPC using the application registered report callback function on both cores. Partial results from the DPC running on one core can be passed onto the DPC running on other core using the DPM relay result API. DPC can provide back the final processing results (point cloud, tracked objects, etc) to the same core's application code which can then send the result to the application running on other core using DPM send result API. Following ladder diagrams shows just one of the many ways of splitting the DPC across two cores.



5.3.2.4.1. Figure 21: Distributed Data processing flow and control (init/config)



5.3.2.4.2. Figure 22: Distributed Data processing flow and control (start/chirp/frame/stop)

🐌 Texas Instruments

5.4. Software hooks for power optimization

This section is applicable for AWR294X and AWR2X44P only.

AWR294X: The power measurement example at mmwave_mcuplus_sdk_<ver>/ti/demo/awr294x/power_measurement demonstrates the usage of power optimization techniques. It uses TDM processing chain for object detection.

AWR2X44P: The mmw demo (TDM / DDM) at mmwave_mcuplus_sdk_<ver>/ti/demo/awr2x44P has the power optimization techniques integrated in it and can be enabled using the below mentioned CLIs.

Refer demo documentation for more details.

There are possibilities of reducing power by techniques such as clock gating of unused peripherals, underclocking, clock gating or power gating during IDLE time.

The power optimization hooks and supporting functions can be enabled by the user through CLI commands.

5.4.1.1. CLI commands for enabling power optimization hooks

CLI Command	Command Details	Command Parameters	Usage in example
powerMeasHwaDynamicClockGating	Clock gates the unused computation engines in HWA.	<enable> 0 - Disabled 1 - Enabled</enable>	Supported
powerMeasHwaStateAfterFrameProc	Clock gates or power gates HWA after the AoA frame processing is completed. Clock is ungated in frame start ISR. It is powered up as soon as DSP wakes up.	<enable> 0 - No optimization 1 - HWA Power gating enabled 2 - HWA Clock gating enabled</enable>	Supported In the provided example, HWA Power gating can only be enabled when DSP is power gated. User should ensure HWA is powered up and configurations are done before the frame start so that the processing chain is not affected.
			AWR2X44P SW supports only HWA clock gating (Option 1 is not supported).
powerMeasDspStateAfterFrameProc AWR294X; Once the DSP powers up, it starts execution from the reset vector. AWR2X44P: • This software provides context save-restore feature for optimized DSP power gating. • With this, DSP resumes execution from the last saved context on power up, instead of executing the entire boot up sequence. This helps in more power saving by reducing the DSP wake up time every frame.	Clock gates or power gates DSP core after the set DSP activity time elapses.	<enable> 0 - No optimization 1 - DSP Power gating enabled 2 - DSP Under clocking enabled (Switches to XTAL after DSS Loading Time)</enable>	Supported DSP Loading should not be 0 for enabling clock or power gating.
		<wakeuptime> Time at which DSP is powered up by MSS in milliseconds</wakeuptime>	Applicable only when DSP is Power gated. Ensure DSP is powered up and initialized before the start of next frame. Option supported only in AWR294X
		<cgwithpd> 0 - Clock is not gated when DSP is powered down</cgwithpd>	Applicable only when DSP is Power Gated. Option supported only in AWR294X



		1 - DSP clock is gated after it is powered down and restored by MSS when it is powered up	
powerMeasPerClockGating	Unused peripherals are clock gated.	<enable> 0 - Disabled 1 - Enabled</enable>	Supported Provided example clock gates the below peripherals: MSS: SPIA , I2C, MII100, MII10 DSS: RTIB, SCIA, CBUFF CSIRX, OBSCLKOUT, PMICCLKOUT, TRCCLKOUT RSS: CSI2A
powerMeasMssLoading	Loads MSS for a given percentage of frame period. Useful for measuring power at fixed MSS activity. MSS performs multiplication operation during MSS active	<enable> 0 - Disabled 1 - Enabled <percent></percent></enable>	Supported
	time when no other task is running. This command is valid for AWR294X device only.	MSS activity in percentage	
powerMeasDspLoading	Loads DSS for a given percentage of frame period. Useful for measuring power at fixed DSS activity. DSS performs dummy dot product operation during DSS active time when no other task is running.	<pre><enable> 0 - Disabled 1 - Enabled <percent> DSS activity in percentage</percent></enable></pre>	Supported Supported Ensure that frame processing is complete
	This command is valid for AWR294X device only.		within the DSS activity time
powerMeasDigTempRead	Prints DSP, HWA and HSM temperature values. Useful for monitoring temperature during power measurement. This command is valid for AWR294X device only.	None	Supported
digTempRead	Prints DSP, HWA and HSM temperature values. Useful for monitoring temperature during power measurement. This command is valid for AWR2X44P device only.	None	Supported
powerMeasBssPrintTemp	Prints BSS temperature Useful for monitoring temperature during power measurement. This command is valid for AWR294X device only.	None	Supported
anaTempRead	Prints BSS temperature Useful for monitoring temperature during power measurement. This command is valid for AWR2X44P device only.	None	Supported
		<enablecal></enablecal>	Supported



Runtime Calibration Configuration	0 - Disable run time calibrations	
This command is valid for	1 - Enable run time calibrations	
AWR294X device only.	<enableperiodicity></enableperiodicity>	Supported
	0 - Disable periodic calibrations	
	1 - Enable periodic calibrations	
	<periodicity></periodicity>	Valid only if periodicity is enabled
	In number of frames	

5.5. mmWave SDK - TI components

The mmWave SDK functionality broken down into components are explained in next few subsections. For detailed documentation on each of these modules, refer to the top level documentation located at mmwave_mcuplus_sdk_<ver>/docs/mmwave_sdk_module_documentation.html.

Device Support	AWR294X	AWR2544	AWR2X44P
Demo Directory	ti\demo\awr294x\mmw\	ti\demo\awr2544\mmw\	ti\demo\awr2x44P\
Binary prefix	awr294x_mmw_demo	awr2544_mmw_demo	awr2x44P_mmw_demo
EVM	AWR294X	AWR2544	AWR2X44P
Platform selection in Visualizer	AWR294X	Not Supported	AWR294X
mmWave API/RF control	R5F (MSS)	R5F (MSS)	R5F (MSS)
Instrumentation via LVDS based streaming	Yes	Yes	Yes
Ethernet-based streaming of object data	Yes	Yes (Compressed 1D FFT data)	Yes
Range Proc DPU	HWA based DPU (driven by DSP)	NA	HWA based DPU (driven by DSP)
Doppler Proc DPU	HWA based DPU (driven by DSP)	NA	HWA based DPU (driven by DSP)
CFAR DPU	HWA based DPU (driven by DSP)	NA	HWA based DPU (driven by DSP)
AoA DPU	HWA based DPU (driven by DSP)	NA	HWA based DPU (driven by DSP)
Range Proc DDMA DPU	HWA based DPU (driven by DSP)	NA	HWA based DPU (driven by M4/DSP)
Doppler Proc DDMA DPU	HWA based DPU (driven by DSP)	NA	HWA based DPU (driven by M4/DSP)
Range CFAR Proc DDMA DPU	HWA based DPU (driven by DSP)	NA	HWA based DPU (driven by M4/DSP)
Range Proc Real2X DPU	NA	HWA based DPU (driven by R5F)	NA

5.5.1. Demos

5.5.1.1. mmWave Demo

This demo is located at mmwave_mcuplus_sdk_<ver>/ti/demo/<platform>/mmw folder. The millimeter wave demo shows some of the radar sensing and object detection capabilities of the SoC using the drivers in the mmWave SDK (Software Development Kit). It allows user to specify the chirping profile and displays the detected objects and other information in real-time. A detailed explanation of this demo is available in the demo's docs folder and can be browsed via mmwave_mcuplus_sdk_<ver>/ docs/mmwave_sdk_module_documentation.html. This section captures the high level layout of the demo supported on various mmWave devices. For details on individual components (control layer, datapath layer, etc), refer to the remaining sub-sections under "mmWave SDK - TI components".

5.5.2. Drivers

Please refer to the MCU_PLUS_SDK documentation (mcu_plus_sdk_<platform>_<version>/docs/api_guide_<platform>/index.html)for more details.

5.5.3. mmWaveLink

mmWaveLink is a control layer and primarily implements the protocol that is used to communicate between the Radar Subsystem (RADARSS) and the controlling entity which can be either Master subsystem (MSS R5F) and/or DSP subsystem (DSS C66x). It provides a suite of low level APIs that the application (or the software layer on top of it) can call to enable/configure/control the RADARSS. It provides a well defined interface for the application to plug in the correct communication driver APIs to communicate with the RADARSS. It acts as driver for Radar SS and exposes services of Radar SS. It includes APIs to configure HW blocks of Radar SS and provides communication protocol for message transfer between MSS/DSS and RADAR SS.


The mmwavelink comes as a part of the DFP package. Please refer to the folder mmwave_dfp_<version>\docs for more information.

5.5.4. mmWave API

mmWaveAPI is a higher layer control running on top of mmWaveLink and LLD API (drivers API). It is designed to provide a layer of abstraction in the form of simpler and fewer set of APIs for application to perform the task of mmWave radar sensing. In mmwave devices with dual cores, it also



provides a layer of abstraction over IPC to synchronize and pass configuration between the MSS and DSS domains. The source code for mmWave API layer is present in the mmwave_mcuplus_sdk_<ver>\ti\control\mmwave folder. Documentation of the API is available via doxygen placed at mmwave_mcuplus_sdk_<ver>\ti\control\mmwave\docs\doxygen\html\index.html and can be easily browsed via mmwave_mcuplus_sdk_ver>\ti\control\mmwave\docs\doxygen\html\index.html and can be easily browsed via mmwave_mcuplus_sdk_ver>\ti\control\tildex.html and can be easily browsed via mmwave_mcuplus_sdk_ver>\tildex doxygen browsed via mmwave_mcuplus



5.5.4.1.1. Figure 24: mmWave API - Internal software design

There are two modes of configurations which are provided by the mmWave module.

5.5.4.2. Full configuration

The "full" configuration mode implements the basic chirp/frame sequence of mmWave Front end and is the recommended mode for application to use when using the basic chirp/frame configuration. In this mode the application will use the entire set of services provided by the mmWave control module. These features includes:-

- Initialization of the mmWave Link
- Synchronization services between the MSS and DSS
- Asynchronous Event Management
- Start & Stop services
- Configuration of the RADARSS for Frame, advanced frame, advance chirp with legacy frame, advance chirp with advance frame & Continuous mode
- Configuration synchronization between the MSS and DSS

In the full configuration mode; it is possible to create multiple profiles with multiple chirps. The following APIs have been added for this purpose:-

Chirp Management:

- MMWave_addChirp
- MMWave_delChirp

Profile Management:

- MMWave_addProfile
- MMWave_delProfile

Advance Chirp Management:

- MMWave_addAdvChirpParam
- MMWave_addAdvChirpLUTData
- MMWave_delAdvChirp

mmWave Front End Calibrations

mmWave API, by default, enables all init/boot time time calibrations for mmWave Front End. There is a provision for user to provide custom calibration mask in MMWave_open API and/or to provide a buffer that has pre-stored calibration data.

When application requests the one-time and periodic calibrations in MMWave_start API call, mmWave API enables all the available onetime and periodic calibrations for mmWave Front End.

0



mmWave API doesn't expose the mmwavelink's LDO bypass API (rIRfSetLdoBypassConfig/rIRfLdoBypassCfg_t) via any of its API. If this functionality is needed by the application (either because of the voltage of RF supply used on the TI EVM/custom board or from monitoring point of view), user should refer to mmwavelink doxygen (mmwave_mcuplus_sdk_<ver>\ti\control\mmwavelink\docs\doxygen\html\index. html) on the usage of this API and call this API from their application before calling MMWave_open().

∧ mmWave_open

Although mmWave_close API is provided, it is recommended to perform mmWave_open only once per power-cycle of the sensor.

5.5.5. Datapath Interface (DPIF)

DPIF defines the standard interface points in the detection processing chain. Key interfaces defined in this layer are:

- Input ADC data
- Radar Cube
- Detection Matrix
- Point cloud and its side info

The source code for DPIF is present in the mmwave_mcuplus_sdk_<ver>\ti\datapath\dpif folder.


5.5.6. Data Processing Units (DPUs)

Data Translating function(s) from one interface point to the other are called "Data Processing Units". Splitting the data processing chain into processing units promote re-use of certain processing blocks across multiple chains. Detailed documentation on these modules can be easily browsed via mmwave_mcuplus_sdk_<ver>/ docs/mmwave_sdk_module_documentation.html .

- Range Processing (ADC data to Radar Cube): This processing unit performs (1D FFT+ optional DC Range Calib) processing on the chirp (RF) data during the active frame time and produces the processed data in the radarCube. This processing unit is standardized in the mmWave SDK. It provides implementation based on HWA. HWA based implementation can be instantiated either on R5F or C66x. The source code for Range DPU is present in the mmwave_mcuplus_sdk_<ver>tildatapath\dpu\rangeproc folder. Documentation of the API is available via doxygen and placed at mmwave_mcuplus_sdk_<ver>tildatapath\dpu\rangeproc\docs\doxygen\html\index.html. The component's unit test code, running on top of FreeRTOS is also provided as part of the package: mmwave_mcuplus_sdk_<ver>tildatapath\dpu\rangeproc\test\.
- Doppler Processing (Radar Cube to Detection Matrix): This processing unit performs (2D FFT + Energy Sum) processing on the radar Cube during the inter frame and produced detection matrix. In addition to this, when static clutter removal is enabled, this processing unit reads Range FFT out data from the radar cube and performs static clutter removal, before performing the 2D FFT + Energy Sum processing. This processing unit is offered as reference implementation and users of SDK could either re-use these as is in their application/processing chain or create variations of these units based on their specific needs. HWA based implementation can be instantiated either on R5F or C66x. DSP based implementation incorporates static clutter algorithm for optimal memory/mips usage and user can skip using the standalone static clutter DPU. The source code for Doppler DPU is present in the mmwave_mcuplus_sdk_<ver> ti\datapath\dpc\dpu\dopplerproc\docs\doxygen\htm\index.html.
- CFAR + AoA (Detection Matrix to Point Cloud): They are offered as two independent DPUs and collectively run CFAR algorithm, peak grouping, field-of-view filtering, doppler compensation, max velocity enhancement and angle (azimuth+elevation) estimation on the detection matrix during inter frame to produce the point cloud. These processing units are offered as reference implementation and users of SDK could either re-use these as is in their application/processing chain or create variations of these units based on their specific needs. HWA based implementation can be instantiated either on R5F or C66x.
 - The source code for CFAR DPU is present in the mmwave_mcuplus_sdk_<ver>\ti\datapath\dpc\dpu\cfarproc folder. Documentation
 of the API is available via doxygen and placed at mmwave_mcuplus_sdk_<ver>\ti\datapath\dpc\dpu\cfar
 proc\docs\doxygen\html\index.html. The component's unit test code, running on top of FreeRTOS is also provided as part of the
 package: mmwave_mcuplus_sdk_<ver>\ti\ datapath\dpc\dpu\cfarproc \ test\.
 - The source code for AoA DPU is present in the mmwave_sdk_<ver>\ti\datapath\dpc\dpu\aoaproc folder. Documentation of the API is available via doxygen and placed at mmwave_mcuplus_sdk_<ver>\ti\datapath\dpc\dpu\aoaproc\docs\doxygen\html\index.html. The component's unit test code, running on top of FreeRTOS is also provided as part of the package:
 mmwave_mcuplus_sdk_<ver>\ti\ datapath\dpc\dpu\aoaproc\ test\.

Each DPU presents the following high level design:






5.5.6.1.1. Figure 25: DPU - Internal software design

- All external DPU APIs start with the prefix DPU_. DPU unique name follows next.
 Ex: DPU_RangeProcHWA_init
- Standard external APIs: init, config, process, ioctl, deinit are provided by each DPU.
 - Init: one time initialization of DPU
 - Config: complete configuration of the DPU: hardware resources, static and dynamic (if supported by DPU)
 - static config: config that is static during ongoing frames
 - dynamic config: config that can be changed from frame to frame but only when process is not ongoing ideally interframe time after DPC has exported the results for the frame
 - Process: the actual processing function of the DPU
 - ° loctl: control interface that allows higher layer to switch dynamic configuration during interframe time
 - De-init: de-initialization of DPU
- All memory allocations for I/O buffers and scratch buffers are outside the DPU since mmWave applications rely on memory overlay technique for optimization and that is best handled at application level
- All H/W resources must be allocated by application and passed to the DPU. This helps in keeping DPU platform agnostic as well as allows
 application to share the resources across DPU when DPU processing doesn't overlap in time.
- DPUs are OS agnostic and use OSAL APIs for needed OS services.

A typical call flow for DPUs could be represented as follows. The timing of config and process API calls with respect to chirp/frame would vary depending on the DPU functionality, its usage in the chain, DPC implementation and overlap of hardware resources.






5.5.7. Data Path Manager (DPM)

DPM is the foundation layer that enables the "scalability" aspect of the architecture. This layer absorbs all the messaging complexities (cross core and intra core) and provide standard APIs for integration at the application level and also for integrating any "data processing chain". Application layer will be able to call the DPM APIs from any domain (MSS or DSS) and control the configuration and execution of the "data processing chain". The APIs offered by DPM will be available on both MSS and DSS. The various deployments that it can cater to (but not limited to) are:

- Datapath control on R5F and datapath execution is split between R5F/HWA and DSP (Distributed)
- Datapath control on R5F and datapath execution is on R5F using HWA (Local)
- Datapath control on R5F and datapath execution is on DSP (with and without HWA) (Remote)



- Datapath control on DSP and datapath execution is on DSP+HWA (Local)
- Datapath control on DSP and datapath execution is on DSP (Local)



5.5.7.1.1. Figure 27: Datapath manager (DPM) - internal software design

The source code for DPM is present in the mmwave_mcuplus_sdk_<ver>\ti\control\dpm folder. Documentation of the API is available via doxygen and placed at mmwave_mcuplus_sdk_<ver>\ti\control\dpm \docs\doxygen\html\index.html. The component's unit test code, running on top of FreeRTOS is also provided as part of the package: mmwave_mcuplus_sdk_<ver>\ti\control\dpm \test\.

5.5.8. Data processing chain (DPC)

DPC is a separate layer within the datapath that encapsulates all the data processing needs of a mmwave application and provides a well defined interface for integration with the application. In the SDK, there is a reference implementation that corresponds to the generic "object detection" chain which was already a part of the OOB demo in past releases. This chain will conform to the standard DPM dictated API definitions. Internally this layer will use the functionality exposed by Data processing units (DPUs), datapath interface and datapath manager (DPM) to realize the data flow needed for the "object detection" chain. The source code for object detection DPC is present in the

mmwave_mcuplus_sdk_<ver>\ti\datapath\dpc\objectedetection folder. Documentation of the API is available via doxygen placed at mmwave_mcuplus_sdk_<ver>\ti\datapath\dpc\objectedetection\<deployment_type>\docs\doxygen\html\index.html and can be easily browsed via mmwave_mcuplus_sdk_<ver>/ docs/mmwave_sdk_module_documentation.html . The component's unit test code, running on top of FreeRTOS is also provided as part of the package mmwave_mcuplus_sdk_<ver>\ti\ datapath\dpc\objectedetection\objectedet

5.5.9. mmWaveLib

mmWaveLib is a collection of algorithms that provide basic functionality needed for FMCW radar-cube processing. It contains optimized library routines for C66x DSP architecture only. This component is not available for cortex R5F (MSS). These routines do not encapsulate any data movement/data placement functionality and it is the responsibility of the application code to place the input and output buffers in the right memory (ex: L2) and use EDMA as needed for the data movement. The source code for mmWaveLib is present in the mmwave_mcuplus_sdk_<ver>vpackages\tilalg\mmwavelib folder. Documentation of the API is available via doxygen placed at

mmwave_mcuplus_sdk_<ver>\packages\tilalg\mmwavelib\docs\doxygen\html\index.html and can be easily browsed via mmwave_mcuplus_sdk_<ver> /docs/mmwave_sdk_module_documentation.html. The component's unit test code, running on top of FreeRTOS is also provided as part of the package: mmwave_mcuplus_sdk_<ver>\packages\tilalg\mmwavelib\test\.

Functionality supported by the library:

- Collection of algorithms that provide basic functionality needed for FMCW radar-cube processing.
 - Windowing (16-bit complex input, 16 bit complex output, 16-bit windowing real array)
 - Windowing (16-bit complex input, 32 bit complex output, 32-bit windowing real array)
 - log2 of absolute value of 32-bit complex numbers
 - vector arithmetic (accumulation)
 - CFAR-CA, CFAR-CASO, CFAR-CAGO (logarithmic input samples)
 - 16-point FFT of input vectors of length 8 (other FFT routines are provided as part of DSPLib)
 - single DFT value for the input sequences at one specific index
 - Twiddle table generation for 32x32 and 16x16 FFTs: optimized equivalent functions of dsplib for generating twiddle factor
 - FFT Window coefficients generation
 - DFT sine/cosine table generation for DFT single bin calculation
 - Single bin DFT with windowing.
 - Variation of the windowing functions with I/Q swap since most of the fixed point FFT functions in DSPLib only support one format of complex types.
- CFAR algorithms
 - Floating-point CFAR-CA:
 - mmwavelib_cfarfloat_caall supports CFAR cell average, cell accumulation, SO, GO algorithms, with input signals in floating point formats;
 - mmwavelib_cfarfloat_caall_opt implements the same functionality as mmwavelib_cfarfloat_caall except with less cycles, but the detected objects will not be in the ascending order.



- mmwavelib_cfarfloat_wrap implements the same functionality as mmwavelib_cfarfloat_caall except the noise samples for the samples at the edges are the circular rounds samples at the other edge.
- mmwavelib_cfarfloat_wrap_opt implements the same functionality as mmwavelib_cfarfloat_wrap except with less cycles, but the detected objects will not be in the ascending order.
- CFAR-OS: Ordered-Statistic CFAR algorithm
 - mmwavelib_cfarOS accepts fixed-point input data (16-bit log-magnitude accumulated over antennae). Search window size
 is defined at compile time.
- Peak pruning for CFAR post-processing
 - mmwavelib_cfarPeakPruning: Accepts detection matrix and groups neighboring peaks into one.
 - mmwavelib_cfarPeakQualifiedInOrderPruning: Accepts the list of CFAR detected objects and groups neighboring peaks into one.
 - mmwavelib_cfarPeakQualifiedPruning: Same as mmwavelib_cfarPeakQualifiedInOrderPruning, but with no assumption for the order of cfar detected peaks
- Floating-point AOA estimation:
 - mmwavelib_aoaEstBFSinglePeak implements Bartlett beamformer algorithm for AOA estimation with single object detected, it also outputs the variance of the detected angle.
 - mmwavelib_aoaEstBFSinglePeakDet implements the save functionality as mmwavelib_aoaEstBFSinglePeak without the variance of detected angle calculation.
 - mmwavelib_aoaEstBFMultiPeak also implements the Bartlett beamformer algorithm but with multiple detected angles, it also
 outputs the variances for every detected angles.
 - mmwavelib_aoaEstBFMultiPeakDet implements the same functionality as mmwavelib_aoaEstBFMultiPeak but with no variances output for every detected angles.
- DBscan Clustering:
 - mmwavelib_dbscan implements density-based spatial clustering of applications with noise (DBSCAN) data clustering algorithm.
 - mmwavelib_dbscan_skipFoundNeiB also implements the DBSCAN clustering algorithm but when expanding the cluster, it skips the already found neighbors.
- Clutter Removal:
 - mmwavelib_vecsum: Sum the elements in 16-bit complex vector.
 - mmwavelib_vecsubc: Subtract const value from each element in 16-bit complex vector.
- Windowing:
 - mmwavelib_windowing16xl6_evenlen: Supports multiple-of-2 length(number of input complex elements), and mmwavelib_windowing16x16 supports multiple-of-8 length.
 - mmwavelib_windowing16x32: This is updated to support multiple-of-4 length(number of input complex elements). It was multiple-of-8 previously.
- Floating-point windowing:
 - mmwavelib_windowing1DFltp: support fixed-point signal in, and floating point signal out windowing, prepare the floating point data for 1D FFT.
 - mmwavelib_chirpProcWin2DFxdpinFltOut, mmwavelib_dopplerProcWin2DFxdpinFltOut: prepare the floating point data for 2D FFT, with fixed point input. The difference is mmwavelib_chirpProcWin2DFxdpinFltOut is done per chip bin, while mmwavelib_dopplerProcWin2DFxdpinFltOut is done per Doppler bin.
 - mmwavelib_windowing2DFltp: floating point signal in, floating point signal out windowing to prepare the floating point data for 2D FFT.
- Vector arithmetic
 - Floating-point and fixed point power accumulation: accumulates signal power. Alternate API to right shift the output vector along with accumulation is also provided.
 - ° Histogram: mmwavelib_histogram right-shifts unsigned 16-bit vector and calculates histogram.
 - Right shift operation on signed 16-bit vector or signed 32-bit vector
 - mmwavelib_shiftright16 shifts each signed 16-bit element in the input vector right by k bits.
 - mmwavelib_shiftright32 shifts each signed 32-bit element in the input vector right by k bits.
 - mmwavelib_shiftright32to16 right shifts 32-bit vector to 16-bit vector
 - Complex vector element-wise multiplication.
 - mmwavelib_vecmul16x16: multiplies two 16-bit complex vectors element by element. 16-bit complex output written in place to first input vector.
 - mmwavelib_vecmul16x32, mmwave_vecmul16x32_anylen : multiplies a 16-bit complex vector and a 32-bit complex vector element by element, and outputs to the 32-bit complex output vector.
 - mmwave_vecmul32x16c: multiplies 32bit complex vector with 16bit complex constant.
 - Sum of absolute value of 16-bit vector elements
 - mmwavelib_vecsumabs returns the 32-bit sum.
 - Max power search on 32-bit complex data
 - mmwavelib_maxpow outputs the maximum power found and returns the corresponding index of the complex sample
 mmwavelib_powerAndMax : Power computation combined with max power search
 - Peak search for Azimuth estimation on 32-bit float vector
 - mmwavelib_multiPeakSearch : Multiple peak search in the azimuth FFT output
 - mmwavelib_secondPeakSearch : Second peak search in the azimuth FFT output
 - DC (antenna coupling signature) Removal on 32-bit float complex vector
 - Vector subtraction for 16-bit vectors
- Matrix utilities

Matrix transpose for 32-bit matrix: Similar to DSPLib function but optimized for matrix with rows larger than columns

5.5.10. Group Tracker

The algorithm is designed to track multiple targets, where each target is represented by a set of measurement points (point cloud output of CFAR detection layer). Each measurement point carries detection information, for example, range, angle, and radial velocity. Instead of tracking individual reflections, the algorithm predicts and updates the location and dispersion properties of the group. The group is defined as the set of measurements (typically, few tens; sometimes few hundreds) associated with a real life target. This algorithm is supported for both R5F and C66x. The source code for grack is present in the mmwave_mcuplus_sdk_<ver>\packages\ti\alg\gtrack folder. Documentation of the API is available via doxygen placed at mmwave_mcuplus_sdk_<ver>\packages\ti\alg\gtrack\doxygen<2d|3D>\html\index.html and can be easily browsed via mmwave_mcuplus_sdk_<ver>\docs\mmwave_sdk_module_documentation.html.. The component's unit test code, running on top of FreeRTOS is also provided as part of the package: mmwave_mcuplus_sdk_<ver>\packages\ti\alg\gtrack\test\.



5.5.11. CCS Debug Utility

This is a simple binary that can flashed onto the board to facilitate the development phase of mmWave application using TI Code Composer Studio (CCS). See section CCS Development mode for more details. There is an executable for both R5F (MSS) and C6 (DSS) and is combined into one metalmage for flashing along with RADARSS firmware. When the appimage for CCS Debug is flashed onto the EVM, the cores can be connected to, reset, and have programs be loaded to them on Code Composer Studio.

Platform	Metaimage Content
AWR294x	R5F(MSS) + C66(DSS) + RSS Patch
AWR2544	R5F(MSS) + RSS Patch
AWR2x44P	R5F(MSS) + DSS_CM4 + C66(DSS) + RSS Patch

5.5.12. HSI Header Utility

An optional utility library is provided for user to create a header that it can attach to the data being shipped over LVDS. This library accepts the CBUFF session configuration and creates a header with appropriate information filled in and passes it back to the calling application. The calling application can then supply this created header to CBUFF APIs. This config inside the header is intended to help user parse the LVDS on the receiving end. The source code for this utility is present in the mmwave_mcuplus_sdk_<ver>\packages\ti\utils\hsiheader\docs\doxygen\html\index.html and can be easily browsed via mmwave_mcuplus_sdk_<ver>\packages\ti\utils\hsiheader\docs\doxygen\html\index.html and can be easily browsed via mmwave_mcuplus_sdk_<ver>\packages\ti\utils\hsiheader\docs\doxygen\html\index.html and can be easily browsed via mmwave_mcuplus_sdk_<ver>\docs\mmwave_sdk_module_documentation.html. Note that HSI Header Utility is currently available for the CBUFF streaming test case but not the OOB Demo for AWR294X.

5.5.13. PMIC Read Write Utility (AWR2544, AWR294X and AWR2X44P)

This is a generic application which can be used to configure PMIC. It can perform the following functions based on user input:

- 1. Read all registers: Reads and prints all PMIC register contents on UART interface
- 2. Write to a register: Writes to user provided register address and reads back register content to verify written value.
- 3. Read a register: Read and print user provided register address on UART interface

The source code for this utility is present in the mmwave_mcuplus_sdk_<ver>\ti\utils\test\pmic_read_write folder. Documentation is available via doxygen placed at mmwave_mcuplus_sdk_<ver>\ti\utils\test\pmic\docs\doxygen\html\index.html and can be browsed via mmwave_mcuplus_sdk_<ver>\docs\mmwave_sdk_module_documentation.html.

5.5.14. Secondary Bootloader

A simple metaimage creation utility is provided in the SDK (mmwave_mcuplus_sdk_<ver>\scripts\unix\generateMetaImage.sh for UNIX and mmwave_mcuplus_sdk_<ver>\scripts\windows\generateMetaImage.bat for Windows). The source code for the SBL comes as a part of the SDK can be found in the <sdk_path>\packages\ti\boot\sbl folder. Please refer to the SDK documentation for more details.

5.5.15. mmWave SDK - System Initialization

The source code for Pinmux module is generated by sysconfig. Please refer mmwave_mcuplus_sdk_<ver>/mcu_plus_sdk_<platform>_<ver>/docs /api_guide_<platform>/SYSCONFIG_INTRO_PAGE.html for details.

5.5.16. Usecases

5.5.16.1. Data Path tests using Test vector method

The data path processing on mmWave device for 1D, 2D and 3D processing consists of a coordinated execution between the MSS, HWA/DSS and EDMA. This is demonstrated as part of the object detection processing chain and millimeter wave demo. The demo runs in real-time and has all the associated framework for RADARSS control etc with it.

The unit tests located at mmwave_mcuplus_sdk_<ver>\ti\datapath\dpc \objectdetection\<chain_type>\test) are stand-alone tests that allow data path processing chain to be executed in non real-time. This allows developer to use it as a debug/development aid towards eventually making the data path processing real-time with real chirping. Developer can easily step into the code and test against knowns input signals. The core data path processing source code in object detection chain and the processing modules (DPUs) is shared between this test and the mmw demo. Most of the documentation is therefore shared as well and can be looked up in the object detection DPC and mmw demo documentation.

The tests also provide a test generator, which allows user to set objects artificially at desired range, doppler and azimuth bins, and noise level so that output can be checked against these settings. It can generate one frame of data. The test generation and verification are integrated into the tests, allowing developer to run a single executable that contains the input vector and also verifies the output (after the data path processing chain), thereby declaring pass or fail at the end of the test. The details of test generator can be seen in the doxygen documentation of these tests located at mmwave_mcuplus_sdk_<ver>/ti\datapath\dpc \objectdetection\<chain_type>\test\docs\doxygen\html\index.html and can be easily browsed via mmwave_mcuplus_sdk_<ver>/ docs/mmwave_sdk_module_documentation.html .

🐌 Texas Instruments

6. Appendix

6.1. Memory usage

The map files of demo and driver unit test application captures the memory usage of various components in the system. They are located in the same folder as the corresponding .xer5f/.xe66 and .bin files. Additionally, the doxygen for mmW demo summarizes the usage of various memories available on the device across the demo application and other SDK components. Refer to the section "Memory Usage" in the mmwave_mcuplus_sdk_<ver>\ti\demo\cplatform>\mmw\docs\doxygen\html\index.html documentation.

6.2. Shared memory usage by SDK demos

Unlike earlier devices like the 18xx, AWR294X do not have a specific HSRAM (Handshake RAM). For the purpose of the demo, 32 KB of the L3 memory (defined in mmwave_mcuplus_sdk_<ver>\ti\common\sys_common.h) is reserved as shared memory between the MSS and the DSS so that the MSS can read the results populated post the DPC execution.

mmWave Device Image Creator

Refer mmwave_mcuplus_sdk_<ver>/mcu_plus_sdk_<platform>_<ver>/docs/api_guide_<platform>/TOOLS_BOOT.html for details.

6.3. Range Bias (TDM Demo) and Rx Channel Gain/Offset Measurement and Compensation

Refer to the section "Range Bias and Rx Channel Gain/Offset Measurement and Compensation" in the mmwave_mcuplus_sdk_<ver>\ti\datapath\dpc\objectdetection\<chain_type>\docs\doxygen\html\index.html documentation for the procedure and internal implementation details. To execute the procedure using Visualizer GUI, here are the steps:

- Set the target as explained in the demo documentation and update the mmwave_mcuplus_sdk_<ver>\tildemo\cplatform>\mmw\profiles\<chain_type>\prof
- mmwave_mcuplus_sdk_<ver>\ti\demo\<platform>\mmw\profiles\<chain_type>\profile_calibration.cfg appropriately.
- Set up Visualizer and mmW demo as mentioned in the section Running the Demos.
- Use the "Load Config From PC and Send" button on plots tab to send the mountain added and button on plots tab to send the
- mmwave_mcuplus_sdk_<ver>\ti\demo\<platform>\mmw\profiles\<chain_type>\profile_calibration.cfg.
 The Console messages window on the Configure tab will dump the "compRangeBiasAndRxChanPhase (TDM)" and "compRxChanPhase (DDM)" to be used for subsequent runs where compensation is desired.
- Copy and save the string for that particular mmWave sensor to your PC.
 - TDM:
 - You can use "compRangeBiasAndRxChanPhase" command in the "Advanced config" tab in the Visualizer and tune any running profile in real time. Alternatively, you can add this to your custom profile configs and use it via the "Load Config From PC and Send" button.
 - DDM:
 - You can add "antennaCalibParams" command to your custom profile configs and use it via the "Load Config From PC and Send" button.

6.4. Guidelines on optimizing memory usage

Depending on requirements of a given application, there may be a need to optimize memory usage, particularly given the fact that the mmWave devices do not have external RAM interfaces to augment on-chip memories. Below is a list of some optimizations techniques, some of which are illustrated in the mmWave SDK demos (mmW demo). It should be noted, however, that the demo application memory requirements are dictated by requirements like ease/flexibility of evaluation of the silicon etc, rather than that of an actual embedded product deployed in the field to meet specific customer user cases.

- 1. On R5F, compile your application with ARM thumb option (depending on the compiler use). If using the TI ARM compiler, the option to do thumb is code_state=16. Another relevant compiler option (when using TI compiler) to play with to trade-off code size versus speed is -- opt_for_speed=0-5. For more information, refer to ARM Optimizing Compiler User's Guide. The pre-built drivers in the SDK are already built with the thumb option. The demo code and BIOS libraries are also built with thumb option. Note the code_state=16 flag and the ti.targets. arm.elf.R5Ft target in the mmwave_mcuplus_sdk_<ver>til
- 2. On C66X, compile portions of code that are not in compute critical path with appropriate -mfX option. The -mf3 options is presently used in the SDK drivers, demos and BIOS cfg file. This option does cause compiler to favor code size over performance and hence some cycles impact are to be expected. However, on mmWave device, using mf3 option only caused about 1% change in the CPU load during active and interframe time and around 3-5% increase in config cycles when benchmarked using driver unit tests. For more details on the "mf" options, refer to The TI C6000 compiler user guide at C6000 Optimizing Compiler Users Guide. Another option to consider is -mo (this is used in SDK) and for more information, see section "Generating Function Subsections (--gen_func_subsections Compiler Option)" in the compiler user guide.
- 3. Even with aggressive code size reduction options, the C66X tends to have a bigger footprint of control code than the same C code compiled on R5F. So if feasible, partition the software to use C66X mainly for compute intensive signal-processing type code and keep more of the control code on the R5F. An example of this is in the mmw demo, where we show the usage of mmwave API to do configuration (of RADARSS) from R5F instead of the C66X (even though the API allows usage from either domain). In mmw demo, this prevents linking of mmwave (in mmwave_mcuplus_sdk_<ver>\ti\control) and mmwavelink (in mmwave_mcuplus_sdk_<ver>\ti\control) code that is involved in configuration (profile config, chirp config etc) on the C66X side as seen from the .map files of mss and dss located along with application binary.
- 4. If there is no requirement to be able to restart an application without reloading, then following suggestions may be used:
 - a. one time/first time only program code can be overlaid with data memory buffers used after such code is executed. Note: Ability to place code at function granularity requires to use the aforementioned -mo option.



- b. the linker option --ram model may be used to eliminate the .cinit section overhead. For more details, see compiler user guide referenced previously. Presently, ram model cannot be used on R5F due to bootloader limitation but can be used on C66X. The SDK uses ram model when building C66X executable images (unit tests and demos).
- 5. On C66X, smaller L1D/L1P cache sizes may be used to increase static RAM. The L1P and L1D can be used as part SRAM and part cache. Smaller L1 caches can increase compute time due to more cache misses but if appropriate data/code is allocated in the SRAMs, then the loss in compute can be compensated (or in some cases can also result in improvement in performance). In the demos, the caches are sized to be 16 KB, allowing 16 KB of L1D and 16 KB of L1P to be used as SRAM. Typically, the L1D SRAM can be used to allocate some buffers involved in data path processing whereas the L1P SRAM can be used for code that is frequently and more fully accessed during data path processing. Thus we get overall 32 KB more memory. The caches can be reduced all the way down to 0 to give the full 32 KB as SRAM: how much cache or RAM is a decision each application developer can make depending on the memory and compute (MIPS) needs.
- 6. When modeling the application code using mmW demo as reference code, it might be useful to trim the heaps in mmW demo to claim back the unused portion of the heaps and use it for code/data memory. Ideally, a user can run their worst case profile that they would like to support using mmW demo, record the heap usage/free metrics for (L1D, L2)/TCMB and L3 heaps on 'sensorStart'. These values can then be used to resize or re-allocate heap globals (example: gDPC_ObjDetTCM, gMmwL3, etc) in mmwave_mcuplus_sdk_<ver>\ti\demo\<platform>\mmw. The freed up space in DSS could be used as follows:

- a. Free heap space in L1D could be used to move some of the L2 buffers to L1D. The freed L2 space can be used for code/data.
- b. Free heap space in L2 could be trimmed by changing the heap's global variable (ex: gMmwL2) definition and used for code/data memory (note that code memory by default is L2 so no other change is required to get more code space).
- c. Free heap space in L3 could be trimmed by changing the heap's global variable (ex: gMmwL3) definition and used for code/data space.

When using TI compilers for both R5F and C66x, the map files contain a nice module summary of all the object files included in the application. Users can use this as a guide towards identifying components/source code that could be optimized. See one sample snapshot below:

ULE SUMMARY			
Module	code	e ro	data rw data
	col/dom/lib/li	bdom awr	2012 2066
C:/mmwave_app_sdk/ti/cont: dpm_msg.oe66	2592	80	0
	-		
dpm_msg.oe66	2592	80	0
dpm_msg.oe66 dpm_core.oe66	2592 2080	80 32	0 0
dpm_msg.oe66 dpm_core.oe66 dpm_mailbox.oe66	2592 2080 736	80 32 20	0 0 24
dpm_msg.oe66 dpm_core.oe66 dpm_mailbox.oe66 dpm_pipe.oe66	2592 2080 736 704	80 32 20 16	0 0 24 0

6.5. How to add a .const (table) beyond L3 heap in mmWave application where overlay is enabled

To achieve L3 heap overlaid with the code to be copied into L1P at init time, L3 heap is in PAGE 1 and code is in Page 0. PAGE 0 is the only loadable page whereas PAGE 1 is just a dummy page to allocate uninitialized sections to implement overlay. As a result the ".const" section (which is loadable section) cannot simply be allocated to PAGE 1 to go after the heap. If the .const is allocated in PAGE 0, then it will overlap the heap and will be overwritten once heap is allocated. To resolve this, the HIGH feature of the linker could be used is used to push the const table to the highest address ensuring no overlap with L3 heap. The suggested changes would be as follows:

1. Shrink the L3 heap by the size of the table (but L3 heap must still be bigger than the size of the L1P cache).

2. Place the table in a named section and allocate the named section in the HIGH space of PAGE 0 of L3RAM.

This ensures that the table will be allocated at the high address and will not be overlapping with L3 heap or the L1P intended code which are located at the low address.

Sample code is shown below.

```
In application C file:
#define TABLE_LENGTH 4
#define TABLE_ALIGNMENT 8 /* bytes */
/*! L3 RAM buffer, shrunk by table */
#pragma DATA_SECTION(gMmwL3, ".l3data");
#pragma DATA_ALIGN(gMmwL3, 8);
uint8_t gMmwL3[<DSS L3 RAM size> - TABLE_LENGTH*sizeof(float) - TABLE_ALIGNMENT];
#pragma DATA_SECTION(gArray, ".l3data_garray");
#pragma DATA_ALIGN(gArray, TABLE_ALIGNMENT);
```



const float gArray[TABLE_LENGTH] = {1.5, 3.2, 0.8, -9.6}; In linker command file: .l3data_garray: load=L3SRAM PAGE 0 (HIGH)

6.6. Enabling L3 cache for DSP/C66x on mmWave devices

In a given usecase for mmWave devices, if L3 RAM is not fully utilized for Radar Cube storage, then the remaining free L3 memory could ideally be used for code and other internal data storages for the application. However, access to L3 memory from DSP/C66x core in mmWave devices is slower than accessing L1/L2. The cache-based memory system of C66x can be efficiently used in such cases. Refer to C66x DSP Cache User Guide (https://www.ti.com/lit/ug/sprugy8/sprugy8.pdf) for more details on the L1P/L1D/L2 two-level hierarchy that exists within the C66x memory architecture. L1P, L1D and L2D can be partitioned into SRAM and cache. L1P, L1D and L2 cache size can be set through linker command file -please refer to mmwave_mcuplus_sdk_<ver>/ti/platform/<platform>/c66x_linker.cmd for more details. L2 SRAM addresses are always cached in L1P and L1D. However, external memory addressed (ex: code/data in L3) by default are configured as non-cacheable in L1D and L2 caches. Cacheability for external memory addressed (ex: L3) must first be explicitly enabled by the user using the MAR registers. Note that L1P cache is not affected by this configuration and always caches external memory addresses.

- Cache writeback: To maintain cache coherency between different masters (CPU, DMA, R5F, etc), content in cache needs to be written back to memory after it is changed before triggering the other master to access that memory location.
- Cache Invalidate: Before reading the content from the physical memory that was updated by another master, the content in cache needs to be invalidated, so that updated data from memory can be loaded in cache.
- Code in L3: mmWave code can be placed from L2 to L3 (via linker command file) with no explicit need for cache enablement and/or cache operations during real time. The only setting that needs to be adjusted is the size of L1P cache and that should be balanced against the need for L1P SRAM to place real time optimized functions (and avoid any cache misses, etc).
- Data in L3: If data cache is enabled for L3 memory via the MAR registers, then at first, one needs to take care of cache invalidates and writebacks for existing data structures in L3 memory. Radarcube and detection matrix are the primary data structures placed in L3 memory in case of a typical mmwave application on our device. Typically Radarcube is accessed (read/write) only via EDMA during the Range and Doppler FFT. Post that, it is more common for the DSP core to access the radarcube directly (i.e. no EDMA) and primarily it is a read access. In such scenario, the Radarcube can be invalidated at the end of current frame but before the start of next frame (i.e. when EDMA master begins to access radarcube). If the Radarcube was modified by the core directly (write operation) during the interframe time, then cache writeback_invalidate is needed at the end of current frame but before the start of next frame. Same consideration would apply for detection matrix. Next, mmWave internal data structures that are accessed purely by DSP can also be moved from L2 to L3 (via linker command file). No explicit cache writeback/invalidations are required for such structures. If user chooses to place the frame results structures in L3 (point cloud, etc) which are shared with MSS (R5F), then cache writeback+invalidate needs to be performed before signaling the MSS about availability of frame results. <u>Note</u>: If the analysis of L3 data access pattern between the DSP, MSS and EDMA shows that cache writeback /invalidate on entire L1D cache might be a better option than calling such API on individual structures.

6.7. SDK Demos: miscellaneous information

A detailed explanation of the mmW demo is available in the demo's docs folder:

mmwave_mcuplus_sdk_<ver>\ti\demo\<platform>\mmw\docs\doxygen\html\index.html. Some miscellaneous details are captured here:

- In demos that use HWA as the only processing node and elevation is enabled during run-time via configuration file, the number of detected objects are limited by the amount of HWA memory that is available for post processing.
- Output packet of mmW demo data over UART is in TLV format and its length is a multiple of 32 bytes. This enables post processing elements on the remote side (PC, etc) to process TLV format with header efficiently.

6.8. CCS Debugging of real time application

It is relatively easier to debug code before real-time starts because single-stepping or adding break-points does not affect the debugging since there is no real-time data and deadline to process the data. But once real-time starts, which is after sensor is started, such debugging can be intrusive and problematic. Below are some tips that may be helpful in real-time debugging, some of them are relevant to the out of box demos but may be applied in user applications if relevant.

6.8.1. Inter-chirp debugging

In out of box demos and many application specialized demos based on the SDK provided by TI (through the TI resource explorer), the inter-chirp processing is based on HWA or DSP but not a mix of the two. In the case of HWA which also is what is used for processing in the current demo, the CPU/CPUs are idling with respect to inter-chirp processing so there is no need to halt. If one intends to stop and examine the state of HWA-EDMA during any of the intermediate processing steps, the design would have to be changed to issue a HWA or EDMA interrupt to the CPU that configured these (typically MSS CPU) at this intermediate and the interrupt could read out some state and store in global variables that could be examined later. If code is halted using a break-point in the interrupt, the EDMA will automatically halt but HWA will not unless HWA is waiting on EDMA, so HWA could continue to run even if the CPU is halted. The current radar SoCs do not have the feature to halt the HWA when any of the CPUs are halted.

In case of DSP doing the inter-chirp processing, there can be a need to single-step/break the processing. However, (unlike the MSS CPU) when DSP is halted, the RadarSS (front end) doesnt halt and the chirping activity does not stop. Because of this, the DSP will miss the chirp processing deadline and the code is typically written to throw an exception. So basically halted debug is not useful unless a single chirp is configured and problem can be recreated with a single chirp. There might be other limitations in the demo code that may prevent a single chirp configuration (e.g minimum number of doppler bins). Other techniques shown in below sections (real-time logging, using non real-time unit test bench) may be more practical but have their time debugging in the active chirping period is low.

6.8.2. Inter-frame debugging



As there is no RadarSS chirping activity when MSS CPU is halted, it is possible to do halted debug in MSS during inter-frame debugging without running out of real-time. But on DSP, the device behavior is the opposite i.e. the chirping will continue even if DSP is in halted state, so stepping in the DSP will cause an inter-frame deadline miss exception when running the out of box demo and other special demos that are implemented similarly. One technique that may be helpful in this situation is if the problem can be observed in the first frame itself, configure the chirping profile to do only one frame (frameCfg CLI command). This way after the active frame period, there is no chirp overrun (of the next frame) pressure when single-stepping in the inter-frame processing.

6.8.3. Using non-real time chain test code


See section "Data Path tests using Test vector method" on details about the non-real time chain that is provided with the mmWave SDK. Users can use these tests to step through the OOB processing chain in non-real time mode and debug or learn the components of the OOB processing chain.

6.8.4. Viewing hardware registers

During debug, there may be a need to examine registers of HWA, EDMA, external I/O peripherals etc. These can be done using View->Registers menu and when a core is selected, the register view will display all registers that the core can see organized into various categories. An example is shown below:

M Expressions 🗠 Variables 🛙	🛙 Registers 💷 🖣	Breakpoints	e 🍪 📬 I
Name	Value	Description	
> # Undefined_Registers			
> # All_Banked_Registers			
> # Debug_Registers			
> # System_Registers			
> # MSS_VIM_R5A		MSS VIM CR5 CORE A	
> # MSS_VIM_R5B		MSS VIM CR5 CORE B	
> # MSS_IOMUX		MSS IOMUX Module Registers	
> # MSS_RCM		MSS RCM Module Registers	
> ## MSS_CTRL		MSS CTRL Module Registers	
> ## MSS_TOPRCM		MSS TOPRCM Module Registers	
> ## MSS_PCR1		MSS PCR1 Module Registers	
> ## TOP_PBIST		TOP PBIST Module Registers	
> MSS_R5SS_STC		MSS R5SS STC Module Registers	
> MSS_DCCA		MSS DCCA Module Registers	
> MSS_DCCB		MSS DCCB Module Registers	
 MSS_DCCC 		MSS DCCC Module Registers	
> IIII DCCGCTRL	0x00005555	Starts / stops the counters clea	
✓ IIII DCCREV	0x40000204	Module version [Memory M	
111 NU2	0	Reserved	
IIII SCHEME	100	SCHEME (RO)	
89 NU1	00	Reserved	
IN FUNC	0000000000	00 Functional release number - (RO)	
NN RTL	00001	Design Release Number - (RO)	
W MAJOR	000	Major Revision Number - (RO)	
CUSTOM	0	Indicates a special version of the mo	
## MINOR	00100	Minor revision number (RO)	
> ## DCCCNTSEED0	0x00000000	Seed value for the counter atta	
> IIII DCCVALIDSEED0	0x00000000	Seed value for the timeout cou	
> IIII DCCCNTSEED1	0x00000000	Seed value for the counter atta	

Individual hardware entities can be expanded further in the view to see registers specific to the hardware entity. The following picture illustrates viewing a certain PARAM set in instance #0 of the EDMA (TPCC0), note how the bit fields are automatically parsed and displayed in a user friendly manner which saves the burden of manually parsing or developing special parsing tools and facilitates quick debugging. Default number formats of bit fields are binary which is not always convenient, this can be changed by selecting the field/fields and right-clicking to see the number format menu as shown in the example below where the A and B counts of EDMA are about to be chosen for Decimal format. Once chosen, the GUI will remember the user choice for that specific field so user does not have to repeat this action in future debug sessions.



In the above picture, one can also see the "Watch" menu item. If this is selected, then the two fields of interest will appear in the Expressions view, this is a convenient way to see some fields of interest during debug without having to navigate the register structure again (although when a particular structure such as PARAM set #16 above is expanded, if the top level TPCC0 is shrunk and expanded again, the PARAM #16 is shown expanded as before because GUI remembers sub-structure expansion/non-expansion state).

6.8.5. Viewing expressions/memory in real time




When debugging real time application (for example: mmw demo) in CCS, if the continuous refresh of variables in the Expression or Memory browser window is enabled without enabling the silicon real-time mode as shown in the picture, the code may crash at a random time showing the message in the console window. To avoid this crash, please put CCS in to "Silicone Real-time" mode after selecting the target core.

Continuous refresh:

2 -	Continuous ref	resh Quick Access	🖹 🗟 🎭
(x)= Variables 🙀 Expressions 🔀 🛄 Registers	selected	a 🕫 🖻 🕂 🗶 🔆 🚱 🖄 🖻	🏟 🗸 🗖 🗖
Expression	Туре	Value	Address ^
b chirpIntHandle	void *	0x0000000	0x008160F4
frameStartIntHandle	void *	0x0000000	0x008160F8
M- LoggingPufferAusitable	unsigned char	1 '\\01'	0-009160EC

Crash in Console window:



Enable "Silicone Real-time" mode:

 tpr12_xds110.ccxml [Code Composer Studio - Device Debugging] Group 1 Enable Silicon Real-time Mode Texas Instruments XDS110 USB Debug Probe_0/CS_DAP_0 Group 2 Texas Instruments XDS110 USB Debug Probe_0/Cortex_R5_0 (Disconnected : Suspended) Texas Instruments XDS110 USB Debug Probe_0/C66xx_DSP (Disconnected : Suspended) 	File Edit View Project Too	ls Run Scripts Window Help
 tpr12_xds110.ccxml [Code Composer Studio - Device Debugging] Group 1 Enable Silicon Real-time Mode Texas Instruments XDS110 USB Debug Probe_0/CS_DAP_0 Group 2 Texas Instruments XDS110 USB Debug Probe_0/Cortex_R5_0 (Disconnected : Suspended) Texas Instruments XDS110 USB Debug Probe_0/C66xx_DSP (Disconnected : Suspended) 	📑 🔫 🗒 🚱 🕒 🗉 🗖 🤉 🤋	\$ _R = \$ & \$ @ \ne \$ \$ @ \ne \$ & \$ \ne \$ \ne \$ * \$ \ne \$ \ne \$ \ne \$ \ne \$ \$ \ne \$ \ne \$ \$
 Group 1 Enable Silicon Real-time Mode Texas Instruments XDS110 USB Debug Probe_0/CS_DAP_0 Group 2 Texas Instruments XDS110 USB Debug Probe_0/Cortex_R5_0 (Disconnected : Suspended) Texas Instruments XDS110 USB Debug Probe_0/C66xx_DSP (Disconnected : Suspended) 	† Debug ⊠	nable Silicon Real-time Mode (service critical interrupts when halte
 Group 1 Texas Instruments XDS110 USB Debug Probe_0/CS_DAP_0 Group 2 Texas Instruments XDS110 USB Debug Probe_0/Cortex_R5_0 (Disconnected : Suspended) Texas Instruments XDS110 USB Debug Probe_0/C66xx_DSP (Disconnected : Suspended) 	✓ ♥ tpr12_xds110.ccxml [Co	de Composer Studio - Device Debugging]
 Texas Instruments XDS110 USB Debug Probe_0/CS_DAP_0 Group 2 Texas Instruments XDS110 USB Debug Probe_0/Cortex_R5_0 (Disconnected : Suspended) Texas Instruments XDS110 USB Debug Probe_0/C66xx_DSP (Disconnected : Suspended) 	👻 🔗 Group 1	
* Texas Instruments XDS110 USB Debug Probe_0/Cortex_R5_0 (Disconnected : Suspended) * Texas Instruments XDS110 USB Debug Probe_0/C66xx_DSP (Disconnected : Suspended)	Texas Instruments	
× [®] Texas Instruments XDS110 USB Debug Probe_0/C66xx_DSP (Disconnected : Suspended)	👻 🔅 Group 2	
	📌 Texas Instruments	; XDS110 USB Debug Probe_0/Cortex_R5_0 (Disconnected : Suspended)
	📌 Texas Instruments	xDS110 USB Debug Probe_0/C66xx_DSP (Disconnected : Suspended)
🔋 🗞 Non Debuggable Devices	> ೫ Non Debuggable De	evices
✓ Texas Instruments XDS110 USB Debug Probe_0/Cortex_R5_1 (Disconnected : Unknown)	📌 Texas Instruments XI	DS110 USB Debug Probe_0/Cortex_R5_1 (Disconnected : Unknown)
Tayas Instruments VDS110 LISP Debug Brobe O/Cortey MA O (Disconnected + Unknown)	. 🙆 Toyac Instruments VE	SS110 USP Dabug Draha O/Cartay MA O (Disconnected + Unknown)

6.9. Shared memory

AWR294X and AWR2X44P devices don't have a separate shared Handshake RAM (HSRAM) memory. Hence part of the L3 RAM that is to be populated in one core and read in the other needs to be made shareable.

6.10. Size of Enum

If a variable of enum type is used to exchange information between ARM and DSP core, then it is necessary to make sure the enum size matches for the same variable compiled on the two cores. TI ARM compiler's default type for enum is packed, which causes the underlying enumeration type to be the smallest integer type that accommodates the enumeration constants. By default, the TI C6000 (DSP) compiler uses a 32-bit integer to store enum objects with enumeration values smaller than 32 bits. This could cause an enum define that takes values 1 to 4 (for example) to be of size 1 byte on R5F and of size 4 bytes on C66x. For devices where DSP and ARM coexist such as , they must be set to ensure that enum types are consistent between ARM and DSP. In mmWave SDK command makefile, flags R5F_XSFLAGS_ENUM_TYPE and R5F_CFLAGS_ENUM_TYPE are used in conjunction to enforce that enum types are compiled as 32bit integers. It is necessary that all libraries and the application code for a given core are



specified to the compiler.

compiled with the same compiler option for enum type else there will be a linker warning and one will encounter errors that cannot be detected until run time.

Linker warning for incompatible enumeration type warning #16027-D: object files have incompatible enumeration types ("xxxx" = packed, "yyyy" = 32-bit) (xxxx and yyyy will be the names of actual object files that do not have matching enum type) Please note that the R5F custom application using mmwave SDK pre-built libraries should be compiled with "--enum_type=int" option

TEXAS INSTRUMENTS