



### Remove These Resistors if Supplying External Signals to Motor Driver



Input Voltage VM: 2.5V to 11V

## Texas Instruments

## DRV8839EVM Dual Half H Bridge Driver

**DRV8839EVM**

Rev

E1

DWG No.