



Getting Started with the EVM Application

The supported operating systems for the EVM application are Windows XP and Windows 7 with administrative rights.

Windows XP instructions

1. Install the USB driver: [\USB Driver\CDM v2.10.00 WHQL Certified.exe](#).
2. Connect the USB cable between the computer and the EVM.
3. Run the application: [\Application\CPG004-5_DRV88xxEVM_R1p1.exe](#).
4. Click the “Connect” button at the top of the application.

Windows 7 instructions

1. Make sure to be logged in as an administrator.
2. Install the USB driver: [\USB Driver\CDM v2.10.00 WHQL Certified.exe](#).
3. Connect the USB cable between the computer and the EVM.
4. Go to folder [\Application\](#), right-click file [CPG004-5_DRV88xxEVM_R1p1.exe](#), and select Properties. Go to the Compatibility tab, check “Run this program in compatibility mode for”, select “Windows XP (Service Pack 3)”, and OK.
5. Now run [CPG004-5_DRV88xxEVM_R1p1.exe](#) and click “Yes” to any pop-up window.
6. Click the “Connect” button at the top of the application.

Note: if there's a COM Port pop-up warning, the port number needs to be changed in Device Manager. To do this, open Start/Control Panel/System, [WinXP: Hardware tab,] Device Manager button, expand Ports, double click USB Serial Port, Port Settings tab, Advanced button, select COM4 from the dropdown menu, OK, OK. Then rerun the application.

For detailed EVM usage instructions, download the User's Guide from the device EVM webpage.